

TÜV RHEINLAND ENERGY GMBH



Report on the performance test of the 48iQ ambient air quality measuring system for carbon monoxide manufactured by Thermo Fisher Scientific

TÜV Report 936/21242986/D
Cologne, 4 February 2019

www.umwelt-tuv.de



tre-service@de.tuv.com

TÜV Rheinland Energy GmbH and its Ambient Air Quality department in particular
is accredited for the following activities:

- Determination of emissions and ambient air quality affected by air pollutants and odorous substances,
- Inspection of correct installation, functionality and calibration of continuous emission monitoring systems including systems for data evaluation and remote monitoring of emissions,
- Measurements in combustion chambers;
- Performance testing of measuring systems for continuous monitoring of emissions and air quality as well as electronic data evaluation and remote monitoring systems for emissions
- Determination of the stack height and air quality forecasts for hazardous and odorous substances;
- Determination of emissions and ambient air quality affected by noise and vibration, determination of sound power levels and noise measurements at wind turbines;

according to EN ISO/IEC 17025.

The accreditation will expire on 10-12-2022 and covers the scope specified in the annex to certificate D-PL-11120-02-00.

Reproduction of extracts from this test report is subject to prior written consent.

TÜV Rheinland Energy GmbH
D - 51105 Köln, Am Grauen Stein,
Tel: + 49 (0) 221 806-5200. fax: +49 (0) 221 806-1349

Blank page



Report on the performance test of the 48iQ ambient air quality measuring system for carbon monoxide manufactured by Thermo Fisher Scientific

| | |
|-----------------------------|--|
| AMS designation: | 48iQ |
| Manufacturer: | Thermo Fisher Scientific 27, Forge Parkway Franklin, MA 02038 USA |
| Test period: | April 2018 to October 2018 |
| Date of report: | 4 February 2019 |
| Report Number: | 936/21242986/D |
| Editor: | Dipl.-Ing. Martin Schneider Phone: +49 221 806-1614 martin.schneider@de.tuv.com |
| Scope of the report: | Report: 119 pages Manual 119 Manual 261 pages Total 369 pages |

Blank page

Table of contents

| | |
|---|----|
| 1. SUMMARY AND CERTIFICATION PROPOSAL..... | 12 |
| 1.1 Summary Overview | 12 |
| 1.2 Certification proposal..... | 13 |
| 1.3 Summary report on test results..... | 14 |
| 2. TASK DEFINITION..... | 20 |
| 2.1 Nature of the test..... | 20 |
| 2.2 Objectives | 20 |
| 3. DESCRIPTION OF THE AMS TESTED | 21 |
| 3.1 Measuring principle | 21 |
| 3.2 AMS scope and set-up | 23 |
| 3.3 AMS adjustment | 25 |
| 4. TEST PROGRAMME | 26 |
| 4.1 General remarks..... | 26 |
| 4.2 Laboratory test | 27 |
| 4.3 Field test..... | 27 |
| 5. REFERENCE MEASUREMENT METHOD | 28 |
| 5.1 Method of measurement..... | 28 |
| 6. TEST RESULTS IN ACCORDANCE WITH VDI 4202, PART 1 (2018)..... | 29 |
| 6.1 7.3 General requirements | 29 |
| 6.1 7.3.1 Measured value display | 29 |
| 6.1 7.3.2 Calibration inlet | 30 |
| 6.1 7.3.3 Easy maintenance | 31 |
| 6.1 7.3.4 Functional check..... | 32 |
| 6.1 7.3.5 Set-up times and warm-up times..... | 33 |

| | | |
|-----|---|----|
| 6.1 | 7.3.6 Instrument design | 34 |
| 6.1 | 7.3.7 Unintended adjustment | 35 |
| 6.1 | 7.3.8 Data output | 36 |
| 6.1 | 7.3.9 Digital interface | 37 |
| 6.1 | 7.3.10 Data transmission protocol..... | 38 |
| 6.1 | 7.3.11 Measuring range | 39 |
| 6.1 | 7.3.12 Negative output signals..... | 40 |
| 6.1 | 7.3.13 Failure in the mains voltage | 41 |
| 6.1 | 7.3.14 Operating states..... | 42 |
| 6.1 | 7.3.15 Switch-over | 43 |
| 6.1 | 7.3.16 Instrument software..... | 44 |
| 6.1 | 7.4 Requirements on performance characteristics in the laboratory | 45 |
| 6.1 | 7.4.1 General requirements | 45 |
| 6.1 | 7.4.2 Test requirements | 46 |
| 6.1 | 7.4.3 Response time and memory effect..... | 48 |
| 6.1 | 7.4.4 Short-term drift..... | 49 |
| 6.1 | 7.4.5 Repeatability standard deviation | 50 |
| 6.1 | 7.4.6 Linearity | 51 |
| 6.1 | 7.4.7 Sensitivity coefficient to sample gas pressure | 52 |
| 6.1 | 7.4.8 Sensitivity coefficient to sample gas temperature..... | 53 |
| 6.1 | 7.4.9 Sensitivity coefficient to surrounding temperature | 54 |
| 6.1 | 7.4.10 Sensitivity coefficient to electrical voltage..... | 55 |
| 6.1 | 7.4.11 Cross sensitivity | 56 |
| 6.1 | 7.4.12 Averaging effect..... | 57 |
| 6.1 | 7.4.13 Difference between sample and calibration port..... | 58 |
| 6.1 | 7.4.14 Converter efficiency | 59 |

| | | |
|-----|---|-----|
| 6.1 | 7.4.15 Residence time in the analyser | 60 |
| 6.1 | 7.5 Requirements on performance characteristics for testing in the field..... | 61 |
| 6.1 | 7.5.1 General requirements | 61 |
| 6.1 | 7.5.2 Location for the field test | 62 |
| 6.1 | 7.5.3 Test requirements | 63 |
| 6.1 | 7.5.4 Long-term drift | 64 |
| 6.1 | 7.5.5 Reproducibility standard deviation under field conditions | 65 |
| 6.1 | 7.5.6 Inspection interval | 66 |
| 6.1 | 7.5.7 Availability | 67 |
| 6.1 | 7.5.8 Converter efficiency | 68 |
| 6.1 | 7.6 Type approval and calculation of the measurement uncertainty | 69 |
| 7. | TEST RESULTS IN ACCORDANCE WITH STANDARD EN 14626 (2012)..... | 70 |
| 7.1 | 8.4.3 Response time | 70 |
| 7.1 | 8.4.4 Short-term drift | 74 |
| 7.1 | 8.4.5 Repeatability standard deviation | 78 |
| 7.1 | 8.4.6 Lack of fit of linearity of the calibration function | 81 |
| 7.1 | 8.4.7 Sensitivity coefficient to sample gas pressure | 86 |
| 7.1 | 8.4.8 Sensitivity coefficient to sample gas temperature | 88 |
| 7.1 | 8.4.9 Sensitivity coefficient to surrounding temperature | 90 |
| 7.1 | 8.4.10 Sensitivity coefficient to electrical voltage..... | 93 |
| 7.1 | 8.4.11 Interferents..... | 95 |
| 7.1 | 8.4.12 Averaging test..... | 98 |
| 7.1 | 8.4.13 Difference sample/calibration port..... | 101 |
| 7.1 | 8.5.4 Long-term drift | 103 |
| 7.1 | 8.5.5 Reproducibility standard deviation for CO under field conditions..... | 106 |
| 7.1 | 8.5.6 Inspection interval | 109 |

| | | | |
|-----|-------|---|-----|
| 7.1 | 8.5.7 | Period of availability of the analyser | 110 |
| 7.1 | 8.6 | Calculation of the total uncertainty according to EN 14626 (2012) | 112 |
| 8. | | RECOMMENDATIONS FOR USE IN PRACTICE | 117 |
| 9. | | BIBLIOGRAPHY | 118 |
| 10. | | APPENDICES | 119 |

List of tables

| | | |
|-----------|---|-----|
| Table 1: | Measuring ranges tested | 12 |
| Table 2: | 48iQ instrument characteristics (manufacturer's specifications) | 25 |
| Table 3: | Certification ranges VDI 4202-1 and EN 14626 | 39 |
| Table 4: | Response time of the 48iQ ambient air monitor for carbon monoxide | 72 |
| Table 5: | Individual results of the response time for carbon monoxide | 73 |
| Table 6: | Results for the short-term drift..... | 75 |
| Table 7: | Individual results for the short-term drift 1 st Test gas application: | 76 |
| Table 8: | Individual results for the short-term drift 2 nd Test gas application: | 77 |
| Table 9: | Repeatability standard deviation at zero and reference point..... | 79 |
| Table 10: | Individual test results obtained for the repeatability standard deviation | 80 |
| Table 11: | Deviation from the analytical function for carbon monoxide | 82 |
| Table 12: | Individual results of the lack-of-fit test..... | 85 |
| Table 13: | Sensitivity coefficient of sample gas pressure | 87 |
| Table 14: | Individual results of the sensitivity to changes in sample gas pressure..... | 87 |
| Table 15: | Sensitivity coefficient to sample gas temperature | 89 |
| Table 16: | Individual results for the determination of the sensitivity to sample gas temperature..... | 89 |
| Table 17: | Sensitivity coefficients to surrounding temperature..... | 91 |
| Table 18: | Individual test results for the sensitivity coefficient to ambient temperature | 92 |
| Table 19: | Sensitivity coefficient to electrical voltage..... | 94 |
| Table 20: | Individual results of the sensitivity coefficient to electrical voltage | 94 |
| Table 21: | Interferents in accordance with EN 14626 | 96 |
| Table 22: | Influence of the tested interferents ($c_t = 8.6 \mu\text{mol/mol}$) | 96 |
| Table 23: | Individual results for testing interferents | 97 |
| Table 24: | Results of the averaging test..... | 99 |
| Table 25: | Individual results of the averaging test | 100 |
| Table 26: | Results of determining the difference between sample/calibration inlet | 101 |
| Table 27: | Individual results for testing the difference between sample and calibration port | 102 |
| Table 28: | Results for the long-term drift at zero point..... | 104 |
| Table 29: | Results for the long-term drift at reference point..... | 104 |
| Table 30: | Individual results for differences | 105 |
| Table 31: | Determination of the reproducibility standard deviation on the basis of complete field test data..... | 107 |
| Table 32: | Availability of the 48iQ measuring system | 111 |
| Table 33: | Relevant performance characteristics and criteria according to EN 14626 | 113 |
| Table 34: | Expanded uncertainty from the results obtained in the laboratory tests for analyser 1 | 115 |
| Table 35: | Expanded uncertainty from the results obtained in the laboratory and field tests for analyser 1 | 115 |
| Table 36: | Expanded uncertainty from the results obtained in the laboratory tests for analyser 2 | 116 |
| Table 37: | Expanded uncertainty from the results obtained in the laboratory and field tests for analyser 2 | 116 |

List of figures

| | |
|--|-----|
| Figure 1: View of the 48iQ analyser | 21 |
| Figure 2: Flow schematic..... | 22 |
| Figure 3: Inside View of the Instrument – Top View | 24 |
| Figure 4: Inside View of the Instrument – Side View | 24 |
| Figure 5: Software version of the tested 48iQ instruments..... | 26 |
| Figure 6: Tested 48iQ instruments with measured value display | 29 |
| Figure 7: Diagram illustrating the response time | 71 |
| Figure 8: Analytical function obtained from the group averages for system 1..... | 83 |
| Figure 9: Analytical function obtained from the group averages for system 2..... | 83 |
| Figure 10: Test of the averaging effect ($t_{so} = t_{zero} = 45$ s.) | 99 |
| Figure 11: Diagram illustrating the reproducibility standard deviation under field conditions 108 | |
| Figure 12: Certificate of accreditation according to EN ISO/IEC 17025:2005 | 120 |

Blank page

1. Summary and certification proposal

1.1 Summary Overview

Thermo Fisher Scientific commissioned TÜV Rheinland Energy GmbH to carry out performance testing for the 48iQ measuring system for carbon monoxide. The test was performed in respect of the following standards and requirements:

- VDI Guideline 4202 part 1: Performance test, declaration of suitability, and certification of point-related measuring systems for gaseous air pollutants of April 2018
- EN 14626: Ambient air – Standard method for the measurement of the concentration of carbon monoxide by non-dispersive infrared spectroscopy of August 2012

The 48iQ measuring system uses non-dispersive infrared photometry to measure carbon monoxide. This measuring principle conforms to the EU reference method. The tests were performed in the laboratory and in a three-months field test in Cologne. The following measuring range was tested:

Table 1: Measuring ranges tested

| Measured components: | Measuring range in [mg/m ³] ¹⁾ | Measuring range in [ppm] or [μmol/mol] |
|----------------------|---|--|
| Carbon monoxide | 0–100 | 0–86 |

¹⁾ The specifications refer to 20 °C and 101.3 kPa

The minimum requirements were satisfied during the performance test.

TÜV Rheinland Energy GmbH therefore recommend the measuring system's approval as a performance-tested measuring system for continuous monitoring of CO ambient air pollutants.

Report on the performance test of the 48iQ ambient air quality measuring system for carbon monoxide manufactured by Thermo Fisher Scientific,
Report No.: 936/21242986/D

1.2 Certification proposal

Based on the positive results obtained, the following recommendation on the announcement of the AMS as a certified system is put forward:

AMS designation:

48iQ for carbon monoxide

Manufacturer:

Thermo Fisher Scientific, Franklin, USA

Field of application:

For continuous monitoring of CO concentrations in ambient air in stationary use.

Measuring ranges during performance testing:

| Component | Certification range | Unit |
|-----------------|---------------------|-------------------|
| Carbon monoxide | 0–100 | mg/m ³ |

Software version:

Version: 1.6.0.32120

Restrictions

None

Note:

This report on the performance test is available online at www.gal1.de.

Test Report:

TÜV Rheinland Energy GmbH, Cologne

Report No.: 936/21242986/D dated 4 February 2019

1.3 Summary report on test results

| Performance criterion | Requirement | Test result | Satisfied | Page |
|--------------------------------------|---|---|----------------|------|
| 7 Performance criteria | | | | |
| 7.3 General requirements | | | | |
| 7.3.1 Measured value display | The measuring system shall have an operative measured value display as part of the instrument. | The measuring system has an operative measured value display at the instrument front. | yes | 29 |
| 7.3.2 Calibration inlet | The measuring system may have a test gas inlet separate from the sample gas inlet. | The measuring system has a test gas inlet separate from the sample gas inlet at the instrument back. | yes | 30 |
| 7.3.3 Easy maintenance | Maintenance should be possible without larger effort, if possible from outside. | Maintenance takes reasonable effort and is possible with standard tools from the outside. | yes | 31 |
| 7.3.4 Functional check | Particular instruments required to this effect shall be considered as part of the measuring system and be applied in the corresponding sub-tests and included in the assessment. | The tested measuring system does not have internal devices for operating the functional check. | not applicable | 32 |
| 7.3.5 Set-up times and warm-up times | The instruction manual shall include specifications in this regard. | Set-up times and warm-up times have been determined. | yes | 33 |
| 7.3.6 Instrument design | The instruction manual shall include specifications in this regard. | Specifications made in the instruction manual concerning instrument design are complete and correct. | yes | 34 |
| 7.3.7 Unintended adjustment | Shall secure measuring system against that. | The measuring system is secured against unintended and unauthorised adjustment of instrument parameters by way of a password. | yes | 35 |
| 7.3.8 Data output | The output signals shall be provided digitally and/or as analogue signals. | Measured signals are provided as analogue (0–20 mA, 4–20 mA or 0–1 V, 0–10 V) and digital signals (via TCP/IP, RS 232, USB). | yes | 36 |
| 7.3.9 Digital interface | The digital interface shall allow the transmission of output signals, status signals, and others. Access to the measuring system shall be secured against unauthorised access. | Digital transmission of measured values operates correctly. | yes | 37 |

| Performance criterion | Requirement | Test result | Satisfied | Page |
|-------------------------------------|---|---|-----------|------|
| 7.3.10 Data transmission protocol | Shall meet the requirements stipulated in Table 1 of VDI Guideline 4202 part 1. | By default, the measuring system comes with an installed Modbus protocol. Measured and status signals are transmitted correctly. Customers of Thermo Fisher Scientific can look up commands on the internet. | yes | 38 |
| 7.3.11 Measuring range | The upper limit of measurement shall be greater or equal to the upper limit of the certification range. | The measuring range is set to 0–86 ppm (100 mg/m ³) for carbon monoxide by default. Supplementary measuring ranges up to 0–10,000 ppm are possible. The measuring system's upper limit of measurement exceeds the upper limit of the certification range in each case. | yes | 39 |
| 7.3.12 Negative output signals | May not be suppressed (life zero). | The measuring system also provides negative output signals. | yes | 40 |
| 7.3.13 Failure in the mains voltage | Uncontrolled emission of operation and calibration gas shall be avoided; instrument parameters shall be secured by buffering against loss; when mains voltage returns, the instrument shall automatically reach the operation mode and start the measurement. | On return of mains voltage, the instrument returns to normal operating mode and automatically resumes measuring. | yes | 41 |
| 7.3.14 Operating states | The measuring system shall allow their control by telemetrically transmitted status signals. | The measuring system provides various ports to ensure comprehensive monitoring and control via an external computer. | yes | 42 |
| 7.3.15 Switch-over | Switch-over between measurement and functional check and/or calibration shall be possible telemetrically. | In principle, it is possible to monitor all tasks necessary for a functional check on the instrument itself or telemetrically. | yes | 43 |
| 7.3.16 Instrument software | Shall be displayed when switched on. Changes affecting instrument functions shall be communicated to the test laboratory. | The instrument's software version is displayed. Software changes are communicated to the test laboratory. | yes | 44 |

| Performance criterion | Requirement | Test result | Satisfied | Page |
|---|--|---|-----------|------|
| 7.4 Requirements on performance characteristics for testing in the laboratory | | | | |
| 7.4.1 General requirements | The manufacturer's specifications in the instruction manual shall not contradict the results of the performance test. | Tests were performed using the performance characteristics specified in VDI standard 4202, part 1 (2018) and standard EN 14626 (2012) | yes | 45 |
| 7.4.2 Test requirements | Has to comply with the requirements set out in VDI standard 4202-1:2018. | Tests were performed using the performance characteristics specified in VDI standard 4202, part 1 (2018) and standard EN 14626 (2012) | yes | 46 |
| Section 8.4 provides a summary of the evaluation of performance characteristics determined in the laboratory. | | | | |
| 7.5 Requirements on performance characteristics for testing in the field | | | | |
| 7.5.1 General requirements | Has to comply with the requirements set out in VDI standard 4202-1:2018. | Tests were performed using the performance characteristics specified in VDI standard 4202, part 1 (2018) and standard EN 14626 (2012) | yes | 61 |
| 7.5.2 Location for the field test | The monitoring station for the field test is to be chosen according to the requirements of 39. BImSchV such that the expected concentrations of the measured components to be measured correspond to the designated task. The equipment of the monitoring station shall allow the implementation of the field test and shall fulfil all requirements considered to be necessary during measurement planning. | The field test location was selected in compliance with the 39 th BImSchV. | yes | 62 |
| 7.5.3 Test requirements | The measuring systems shall be installed in the monitoring station and, after connecting to the existing or separate sampling system, activated properly. The adjustments of the measuring system shall meet the specifications of the manufacturer. All adjustments are to be documented in the test report. | During the field test, the measuring system was operated and serviced according to the manufacturer's instructions. | yes | 63 |
| Section 8.5 provides a summary of the evaluation of performance characteristics determined in the laboratory. | | | | |

| Performance criterion | Requirement | Test result | Satisfied | Page |
|---|---|--|-----------|------|
| 8.4 Procedures for the determination of the performance characteristics during the laboratory test according to EN 14626 | | | | |
| 8.4.3 Response time | Rise and fall response time \leq 180 s each. Difference between rise and fall response time \leq 10 s. | The measured values remained considerably below the maximum permissible response time of 180 s at all times. The maximum response time determined for system 1 was 48.5 s, for system 2, it was 48.5 s. | yes | 70 |
| 8.4.4 Short-term drift | The short-term drift at zero must be \leq 0.1 $\mu\text{mol/mol/12 h}$. The short-term drift at span level must be \leq 0.6 $\mu\text{mol/mol/12 h}$. | For instrument 1 the value for the short-term drift at zero point was 0.04 $\mu\text{mol/mol}$, for instrument 2 it was 0.01 $\mu\text{mol/mol}$. Short-term drift at reference point was 0.20 $\mu\text{mol/mol}$ for instrument 1 and 0.12 $\mu\text{mol/mol}$ for instrument 2. | yes | 74 |
| 8.4.5 Repeatability standard deviation | The performance criteria are as follows: Repeatability standard deviation at zero shall not exceed 0.3 $\mu\text{mol/mol}$. At a sample gas concentration at the reference point it shall not exceed 0.4 $\mu\text{mol/mol}$. | For instrument 1 the value for the repeatability standard deviation at zero point was 0.02 $\mu\text{mol/mol}$, for instrument 2 it was 0.02 $\mu\text{mol/mol}$. Repeatability standard deviation at reference point was 0.01 $\mu\text{mol/mol}$ for instrument 1 and 0.03 $\mu\text{mol/mol}$ for instrument 2. | yes | 78 |
| 8.4.6 Lack of fit of linearity of the calibration function | The deviation from the linearity of the calibration function at zero shall not exceed 0.5 $\mu\text{mol/mol}$. At concentrations above zero, it shall not exceed 4% of the measured value. | The deviation from the linear regression line for instrument 1 is 0.13 $\mu\text{mol/mol}$ at zero point and no more than 1.33% of the target value for concentrations above zero. The deviation from the linear regression line for instrument 2 is -0.01 $\mu\text{mol/mol}$ at zero point and no more than 1.24% of the target value for concentrations above zero. | yes | 81 |
| 8.4.7 Sensitivity coefficient to sample gas pressure | The sensitivity coefficient to sample gas pressure shall be \leq 0.7 $\mu\text{mol/mol/kPa}$. | For instrument 1, the sensitivity coefficient to sample gas pressure is 0.02 $\mu\text{mol/mol/kPa}$. For instrument 2, the sensitivity coefficient to sample gas pressure is 0.02 $\mu\text{mol/mol/kPa}$. | yes | 86 |

| Performance criterion | Requirement | Test result | Satisfied | Page |
|--|--|--|-----------|------|
| 8.4.8 Sensitivity coefficient to sample gas temperature | The sensitivity coefficient to sample gas temperature shall be $\leq 0.3 \mu\text{mol/mol/K}$. | For instrument 1, the sensitivity coefficient to sample gas temperature is $0.06 \mu\text{mol/mol/K}$. For instrument 2, the sensitivity coefficient to sample gas temperature is $0.10 \mu\text{mol/mol/K}$. | yes | 88 |
| 8.4.9 Sensitivity coefficient to surrounding temperature | The sensitivity coefficient to surrounding temperature shall be $\leq 0.3 \mu\text{mol/mol/K}$. | The sensitivity coefficient to the surrounding temperature did not exceed the performance criterion specified at $0.3 \mu\text{mol/mol/K}$. For the purpose of uncertainty calculation, the largest value is used for both instruments. For instrument 1, this is $0.021 \mu\text{mol/mol/K}$ and for instrument 2 it is $0.081 \mu\text{mol/mol/K}$. | yes | 90 |
| 8.4.10 Sensitivity coefficient to electrical voltage | The sensitivity coefficient to electrical voltage shall not exceed $0.3 \mu\text{mol/mol/V}$. | At no test item did the sensitivity coefficient to electrical voltage exceed the value of $0.3 \mu\text{mol/mol/V}$ specified in standard EN 14626. For the purpose of uncertainty calculation, the largest value is used for both instruments. For instrument 1, this is $0.00 \mu\text{mol/mol/V}$ and for instrument 2, it is $0.00 \mu\text{mol/mol/V}$. | yes | 93 |
| 8.4.11 Interferents | Interferents at zero and at concentration c_t (at the level of the 1-hour limit value = $8.6 \mu\text{mol/mol}$ for CO). Deviations for interferents shall not exceed $0.5 \mu\text{mol/mol}$ for CO ₂ , NO and NO ₂ and $1.0 \mu\text{mol/mol}$ for H ₂ O. | Cross-sensitivity at zero point was $0.05 \mu\text{mol/mol}$ for system 1 and $0.14 \mu\text{mol/mol}$ for system 2 for H ₂ O, $-0.03 \mu\text{mol/mol}$ for system 1 and $-0.22 \mu\text{mol/mol}$ for system 2 for CO ₂ , $-0.11 \mu\text{mol/mol}$ for system 1 and $-0.05 \mu\text{mol/mol}$ for system 2 for NO, $-0.04 \mu\text{mol/mol}$ for system 1 and $-0.04 \mu\text{mol/mol}$ for system 2 for N ₂ O. Cross-sensitivity at the limit value c_t was $0.02 \mu\text{mol/mol}$ for system 1 and $0.00 \mu\text{mol/mol}$ for system 2 for H ₂ O, $-0.11 \mu\text{mol/mol}$ for system 1 and $-0.08 \mu\text{mol/mol}$ for system 2 for CO ₂ , $-0.10 \mu\text{mol/mol}$ for system 1 and $-0.07 \mu\text{mol/mol}$ for system 2 for NO, $-0.07 \mu\text{mol/mol}$ for system 1 and $0.00 \mu\text{mol/mol}$ for system 2 for N ₂ O. | yes | 95 |
| 8.4.12 Averaging test | The averaging effect shall not exceed 7% of the measured value. | At -1.2% for system 1 and 2.0% for system 2, the performance criterion defined in EN 14626 is fully complied with. | yes | 98 |

| Performance criterion | Requirement | Test result | Satisfied | Page |
|---|--|--|-----------|------|
| 8.4.13 Difference sample/calibration port | The difference between the sample and calibration ports shall not exceed 1%. | At -0.06% for system 1 and -0.08% for system 2, the performance criterion defined in EN 14626 is fully complied with. | yes | 101 |
| 8.5 Determination of the performance characteristics during the field test according to EN 14626 | | | | |
| 8.5.4 Long-term drift | The long-term drift at zero point shall not exceed $\leq 0.5 \mu\text{mol/mol}$. Long-term drift at span level shall not exceed 5% of the certification range. | Maximum long-term drift at zero point DI_z was at $0.43 \mu\text{mol/mol}$ for instrument 1 and $0.33 \mu\text{mol/mol}$ for instrument 2. Maximum long-term drift at reference point DI_s was at 2.75% for instrument 1 and 0.75% for instrument 2. | yes | 103 |
| 8.5.6 Inspection interval | The period of unattended operation of the AMS shall be at least 2 weeks. | The necessary maintenance tasks determine the period of unattended operation. In essence, these include contamination checks, plausibility checks and checks of potential status/error warnings. The external particle filter needs replacing at the measurement site after having been subjected to dust loading. EN 14626 requires checking of zero and span points at least once every two weeks. | yes | 109 |
| 8.5.5 Reproducibility standard deviation for CO under field conditions | Reproducibility standard deviation under field conditions shall not exceed 5% of the mean value over a period of three months. | The reproducibility standard deviation for carbon monoxide under field conditions was 1.52% as a percentage of the mean value over the three-months field test period. Thus, the requirements of EN 14626 are satisfied. | yes | 106 |
| 8.5.7 Period of availability of the analyser | Availability of the analyser shall be at least 90%. | The availability is 100%. Thus, the requirement of EN 14626 is satisfied. | yes | 110 |

2. Task Definition

2.1 Nature of the test

Thermo Fisher Scientific commissioned TÜV Rheinland Energy GmbH to submit the 48iQ air quality monitor to performance testing. The test was carried out as a complete performance test.

2.2 Objectives

The AMS is designed to determine carbon monoxide concentrations in ambient air in the following concentration ranges:

| Component | Certification range | Unit |
|-----------------|---------------------|-------------------|
| Carbon monoxide | 0–100 | mg/m ³ |

The 48iQ air quality monitor uses non-dispersive infrared photometry to determine carbon monoxide.

The task was to carry out performance testing in line with the applicable standards and taking into consideration the latest developments in the field.

The test was performed on the basis of the following standards:

- VDI Guideline 4202 part 1: Automated measuring systems for air quality monitoring – Performance test, declaration of suitability, and certification of point-related measuring systems for gaseous air pollutants
- EN 14626: Ambient air – Standard method for the measurement of the concentration of carbon monoxide by non-dispersive infrared spectroscopy of August 2012

3. Description of the AMS tested

3.1 Measuring principle

The 48iQ measuring system is a continuous emission monitoring system for carbon monoxide. The instrument uses the non-dispersive infrared photometric method as its measuring principle. It was designed for the continuous measurement of carbon monoxide in ambient air.



Figure 1: View of the 48iQ analyser

The 48iQ analyser is based on the principle that carbon monoxide (CO) absorbs infrared radiation at a wavelength of 4.6 microns. The gas filter correlation technique allows to selectively determine the absorption uniquely caused by CO by the ratio of sample-absorbed light to a filtered reference measurement.

Light from a broadband infrared source passes through a gas filter wheel alternating between N₂ and CO filled cells and passes through a narrow bandpass interference filter before passing into the volume containing sample gas. Light that passes through the N₂ cell is absorbed by CO in the sample gas normally as the sample signal; light that passes through the CO cell is already blocked where CO absorbs, and so is unchanged by sample CO as the reference. Das Verhältnis von Probe zu Referenz wird mit hoher Geschwindigkeit erfasst und um die Lichtstärke und andere Veränderungen korrigiert, um eine präzise Messung zu erhalten.

The sample is drawn into the 48iQ through the sample bulkhead. It is pulled by a single stage pump through the 48iQ DMC Bench where CO is detected and then through a capillary which regulates the flow intake to approximately 1 l/min while monitoring and maintaining ambient pressure on the optical bench side.

The 48iQ outputs the CO concentration to the front panel display and the analogue outputs, and also makes the data available over the serial or Ethernet connection.




Figure 2: Flow schematic

3.2 AMS scope and set-up

The 48iQ carbon monoxide analyser uses the NDIR technology to measure carbon monoxide. The sample to be analysed is led inside the measurement module via an external dust filter. The 49iQ system components include:

- Optical bench: The optical bench is an airtight bench that contains the sample gas. It also includes the mirrors that reflect infrared light multiple times across the sample path before detection, to maximize absorption. Heaters are used to maintain the optical bench at a constant temperature.
A bandpass filter limits the light entering the optical bench to a narrow band of the infrared within which CO absorbs.
- Filter wheel motor A gas filter wheel contains samples of CO and N₂ gas with a chopper disk. The wheel is rotated so that infrared light is periodically interrupted to produce a modulated signal upon detection. Differentiating the light through the CO and N₂ components of the wheel, in the presence of CO in the optical bench, allow the determination of sample CO absorption and concentration. The chopper motor rotates the gas filter wheel and chopper disk at a uniform speed. A separate optical switch assembly detects the position of the filter wheel for synchronizing the modulated signal and for checking the chopper motor speed.
- Detector Preamp The detector/preamplifier assembly converts infrared light, carrying modulation and CO sample absorption, into an amplified electrical signal that undergoes processing.
- Infrared Source The infrared light source is a special wire-wound resistor operated at high temperature to generate broadband infrared radiation.
- Common electronics: The common electronics contain the core computational and power routing hardware for the 48iQ, and is replicated throughout other iQ series products. It also contains front panel display, the USB ports, the Ethernet port, and the optional I/O interfaces. All electronics operate from a universal VDC supply. The system Controller Board (SCB) contains the main processor, power supplies, and a sub-processor, and serves as the communication hub for the instrument.
- Peripherals Support system The peripheral support system operates these additional devices that are needed, but do not require special feedback control or processing. The chassis fan provides air cooling of the active electronic components. Internal vacuum pump for generating air/sample through the instrument.
- Flow/Pressure DMC The Flow/Pressure DMC is used measure instrument pressures that assure proper flow regulation and for sample pressure within the measurement bench for pressure corrections and compensation. The DMC includes two pressure sensors.




Figure 3: Inside View of the Instrument – Top View




Figure 4: Inside View of the Instrument – Side View

Table 2 lists a number of important instrument characteristics of the 48iQ.

Table 2: 48iQ instrument characteristics (manufacturer's specifications)

| | |
|-----------------------|--|
| Measured range: | Max 0–10,000 ppm (selectable) |
| Units: | ppm or mg/m ³ |
| Measured compounds: | Carbon monoxide |
| Sample flow rate | ~1.0 l/min (during the test) |
| Outputs: | <ul style="list-style-type: none">• USB port• TCP/IP Ethernet connection• RS232/RS485• Analogue outputs |
| Input voltage: | 230 V or 115 V 50Hz or 60 Hz |
| Power: | 140 W; 275 W max. |
| Dimension (l x w x h) | 609 x 425 x 221 mm / ~ 15 kg |

3.3 AMS adjustment

The measuring system was commissioned according to manufacturer instructions. No internal adjustment cycle was activated during performance testing. Instrument internal averaging time was 60 s.

4. Test programme

4.1 General remarks

Two identical 48iQ instruments with the following serial numbers were submitted to performance testing:

Instrument 1: SN 1180540007 and

Instrument 2: SN 1171780048

The tests were performed with software version „1.6.0.32120“.

The test comprised a laboratory test to determine the performance characteristics as well as a field test over a period of several months.

In this report, the heading for each performance criterion cites the requirements according to the relevant standards ([1, 2, 3]) including its chapter number and wording.



Figure 5: Software version of the tested 48iQ instruments

4.2 Laboratory test

The laboratory test was performed using two complete and identical systems type 48iQ, serial numbers 1180540007 and SN: 1171780048. Standards [1] and [2] specify the following test programme for the laboratory test:

- Description of instrument functions
- General requirements
- Calibration line fit
- Short-term drift
- Repeatability standard deviation
- Sensitivity to sample gas pressure
- Sensitivity to sample gas temperature
- Sensitivity to surrounding temperature
- Sensitivity to supply voltage
- Cross sensitivities
- Averaging effect
- Response time
- Difference sample/calibration inlet

Measured values were recorded using an external data logger.
Chapters 6 and 7 summarizes the results of the laboratory tests.

4.3 Field test

The field test was performed between 23/07/2018 and 29/10/2018 using two identical 48iQ measuring systems. The instruments used were identical with those used for laboratory testing. The serial numbers were:

instrument 1: SN 1180540007
instrument 2: SN 1171780048

The following test programme was determined for the field test:

- Long-term drift
- Period of unattended operation
- Availability
- Reproducibility standard deviation

Measured values were recorded using an external data logger.
Chapters 6 and 7 summarizes the results of the field tests.

5. Reference Measurement Method

5.1 Method of measurement

Test gases used for adjustment purposes during the test

Certified carbon monoxide test gases were used to verify performance parameters. The specified test gases were used during the entire test and, where necessary, were diluted with the help of a (type Hovacal) mass flow controller.

| | |
|---|---|
| Zero gas: | synthetic air |
| Test gas CO: | 203 mg/m³ in synth. air |
| Number of test gas cylinder: | 15892 |
| Manufacturer / date of manufacture: | Praxair / 16/04/2014 |
| Stability guarantee / certified: | 60 months |
| Checking of the certificate by / on: | 24/09/2014 / proprietary lab |
| Measurement uncertainty as per calibration certificate: | 2% |
| Test gas CO: | 101.8 ppm in synth. air |
| Number of test gas cylinder: | 16135 |
| Manufacturer / date of manufacture: | Praxair / 13/05/2016 |
| Stability guarantee / certified: | 60 months |
| Checking of the certificate by / on: | 09/08/2016 / proprietary lab |
| Rel. uncertainty according to certificate: | 2% |

6. Test results in accordance with VDI 4202, part 1 (2018)

6.1 7.3 General requirements

6.1 7.3.1 Measured value display

The measuring system shall have an operative measured value display as part of the instrument.

6.2 Equipment

No additional equipment is required.

6.3 Testing

It was checked whether the measuring system has a measured value display.

6.4 Evaluation

The measuring system has an operative measured value display at the instrument front.

6.5 Assessment

The measuring system has an operative measured value display at the instrument front.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Figure 6 shows the tested AMS with integrated measured value display.



Figure 6: Tested 48iQ instruments with measured value display

6.1 **7.3.2 Calibration inlet**

The measuring system may have a test gas inlet separate from the sample gas inlet.

6.2 **Equipment**

No additional equipment is required.

6.3 **Testing**

We tested whether the instrument includes a test gas inlet separate from the sample gas inlet.

6.4 **Evaluation**

The measuring system has a test gas inlet separate from the sample gas inlet at the instrument back.

6.5 **Assessment**

The measuring system has a test gas inlet separate from the sample gas inlet at the instrument back.

Criterion satisfied? yes

6.6 **Detailed presentation of test results**

Chapter

7.1 8.4.13 Difference sample/calibration port explains the functionality of the separate sample gas inlet.

6.1 7.3.3 Easy maintenance

Necessary maintenance of the measuring systems should be possible without larger effort, if possible from outside.

6.2 Equipment

No additional equipment is required.

6.3 Testing

The necessary regular maintenance was performed in accordance with the instruction manual.

6.4 Evaluation

The user is advised to perform the following maintenance activities:

1. Checking the operational status
The operational status may be monitored and checked by visual inspections of the instrument's display or via an external PC connected to the AMS.
2. Checking and replacement of the external particle filter at the sample gas inlet
The frequency at which the particle filter needs to be replaced depends on the dust concentrations in ambient air.

6.5 Assessment

Maintenance takes reasonable effort and is possible with standard tools from the outside.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Maintenance was performed during the test in accordance with the activities and procedures described in the operation manual. Complying with the procedures described in the manual, no difficulties were identified. All maintenance activities were possible without any difficulties using standard tools.

6.1 7.3.4 Functional check

If the operation or the functional check of the measuring system require particular instruments, they shall be considered as part of the measuring system and be applied in the corresponding sub-tests and included in the assessment.

The performance of test gas generators, which are part of the measuring system, shall be checked by comparing it to the requirements for test gases used for continuous quality assurance. They have to provide a status signal indicating that they are ready for operation. It must be possible to control them directly or remotely.-

6.2 Equipment

Operation manual

6.3 Testing

The tested measuring system does not have internal devices for operating the functional check. The current operating status of the measuring system is continuously monitored and any issues will be flagged via a series of different error messages.

The functional check of the instruments was performed using external test gases.

6.4 Evaluation

The tested measuring system does not have internal devices for operating the functional check. The current operating status is continuously monitored and any issues will be flagged via a series of different error messages.

External monitoring of the zero and reference point using test gases is possible.

6.5 Assessment

The tested measuring system does not have internal devices for operating the functional check.

Criterion satisfied? not applicable

6.6 Detailed presentation of test results

Not applicable.

6.1 7.3.5 Set-up times and warm-up times

The set-up times and warm-up-times shall be specified in the instruction manual.

6.2 Equipment

Operation manual and additional clock

6.3 Testing

The measuring systems were set up following the manufacturer's instructions. Set-up times and warm-up times were recorded separately.

Necessary constructional measures prior to the installation such as the installation of a sampling system in the analysis room were not taken into account.

6.4 Evaluation

The manual does not specify the set-up time. It will of course depend on the situation given at the site of installation as well as the local voltage supply. Since the 48iQ is a compact analyser, the set-up time is mainly determined by the following tasks:

- Connecting the AMS to supply voltage;
- Connecting the tubing (sampling, discharged air).

Commissioning and changing positions in the laboratory on various occasions (installation in/removal from the climatic chamber) as well as the installation at the field test location resulted in a set-up time of ~30 minutes.

When switching the AMS on in a completely cold state, it takes about 90 minutes to reach a stable reading.

The measuring system has to be installed at a location where it is protected from weather conditions, e.g. in an air-conditioned measurement container.

6.5 Assessment

Set-up times and warm-up times have been determined.

It is possible to operate the measuring system at different locations with limited effort. Set-up time is 30 minutes and warm-up time ranges between 1 and 2 hours depending on the necessary stabilisation.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable.

6.1 7.3.6 Instrument design

The instruction manual shall include specifications of the manufacturer regarding the design of the measuring system. The main elements are:

Instrument shape (e.g. bench mounting, rack mounting, free mounting)

Mounting position (e.g. horizontal or vertical mounting)

Safety requirements

Dimensions

Weight

Power consumption

Preventing condensation within the analyser.

6.2 Equipment

Operation manual and a measuring system for recording energy consumption (Gossen Metrawatt) and scales.

6.3 Testing

The instrument design of the measuring systems handed over for testing was compared to the description provided in the manual. The energy consumption specified was verified during normal operation in the field test over 24h.

6.4 Evaluation

The measuring system is intended for horizontal mounting (e.g. on a table or in a rack) sheltered from weather conditions. The temperature at the site of installation must be between 0 °C and 30 °C.

The dimensions and weight of the measuring system correspond to the information provided in the operation manual.

The manufacturer specifies a maximum power consumption of 275 W. During start-up (warm-up) a short-term consumption of 250 W was recorded. During normal operation, energy consumption is 140 W.

6.5 Assessment

Specifications made in the instruction manual concerning instrument design are complete and correct.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not required for this performance criterion

6.1 7.3.7 Unintended adjustment

It shall be possible to secure the adjustment of the measuring system against illicit or unintended adjustment during operation. Alternatively, the user manual shall specifically note that the measuring system may only be installed in a secured area.

6.2 Equipment

The test of this criterion did not require any further equipment.

6.3 Testing

The measuring system can be operated via a display at its front with touch panel or via a PC connected to the measuring system directly or via a network.

The instrument provides an internal feature (password protection) to secure it against illicit or unintended adjustment. It is only possible to change parameters or adjust the measuring system after entering the password.

6.4 Evaluation

On entering the correct password, it is possible to change instrument parameters affecting measurement characteristics via the control panel and via an external computer.

6.5 Assessment

The measuring system is secured against unintended and unauthorised adjustment of instrument parameters by way of a password.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not required for this performance criterion

6.1 7.3.8 Data output

The output signal shall be provided digitally and/or as analogue signals (e.g. 4 mA to 20 mA).

6.2 Equipment

Analogue Yokogawa data logger, PC

6.3 Testing

The measuring system provides the following transmission routes: Modbus, RS232, RS485, USB, digital outputs, TCP/IP network. Moreover, the measuring system also provides an option to output analogue signals (V or mA).

6.4 Evaluation

Measured signals are displayed on the back of the instrument as follows:

Output: 0–20 mA, 4–20 mA or 0–1 V, 0–10 V, selectable concentration range

Digital: Modbus, RS232, RS485, USB, digital inputs and outputs, TCP/IP network

6.5 Assessment

Measured signals are provided as analogue (0–20 mA, 4–20 mA or 0–1 V, 0–10 V) and digital signals (via TCP/IP, RS 232, USB).

The instrument provides additional interfaces (e.g. analogue outputs) for connecting additional measuring or other peripheral instruments.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not required for this performance criterion

6.1 7.3.9 Digital interface

The digital interface shall allow the transmission of output signals, status signals, and information like instrument type, measurement range, and measured component and unit. The digital interface shall be described fully in respective standards and guidelines.

Access to the measuring system via digital interfaces, e.g. for data transmission, shall be secured against unauthorised access, e.g. by a password.

6.2 Equipment

A PC

6.3 Testing

The measuring system provides the following transmission routes: Modbus, RS232, RS485, USB, 10 digital outputs, TCP/IP network. Moreover, the measuring system also provides an option to output analogue signals (V or mA).

6.4 Evaluation

Digital measured signals are provided as follows:

Modbus, RS232, RS485, USB, TCP/IP network

Digital output signals were checked. All relevant pieces of information such as measured signals, status signals, measured component, measuring range, unit and instrument information can be transmitted digitally.

Digital data retrieval always requires entry of the correct password.

6.5 Assessment

Digital transmission of measured values operates correctly.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not required for this performance criterion

6.1 7.3.10 Data transmission protocol

The measuring system shall contain at minimum one data transmission protocol for the digital transmission of the output signal.

Every data transmission protocol provided by the manufacturer for the measuring system shall allow the correct transmission of the data and detect errors in the transmission. The data transmission protocol including the used commands is to be documented in the instruction manual. The data transmission protocol shall allow to transmit at minimum the following data:

identification of the measuring system

identification of measured components

Unit

output signal with time signature (date and time)

operation and error status

operating commands for remote control of the measuring systems

All data are to be transmitted as clear text (ASCII characters).

6.2 Equipment

A PC

6.3 Testing

By default, the measuring system comes with an installed Modbus protocol.

6.4 Evaluation

By default, the measuring system comes with an installed Modbus protocol. Measured and status signals are transmitted correctly.

6.5 Assessment

By default, the measuring system comes with an installed Modbus protocol. Measured and status signals are transmitted correctly. Customers of Thermo Fisher Scientific can look up commands on the internet.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not required for this performance criterion

6.1 7.3.11 Measuring range

The upper limit of measurement of the measuring systems shall be greater or equal to the upper limit of the certification range.

6.2 Equipment

The test of this criterion did not require any further equipment.

6.3 Testing

We compared the upper limit of measurement to the upper limit of the certification range to verify whether the former was larger or equal to the latter.

6.4 Evaluation

In theory, it is possible to set the measuring system to measuring ranges of up to 0–10,000 ppm.

Possible measuring range: 10.000 ppm

Upper limit of the certification range for CO: 100 mg/m³ (86 ppm)

6.5 Assessment

The measuring range is set to 0–86 ppm (100 mg/m³) for carbon monoxide by default. Supplementary measuring ranges up to 0–10,000 ppm are possible.

The measuring system's upper limit of measurement exceeds the upper limit of the certification range in each case.

Criterion satisfied? yes

6.6 Detailed presentation of test results

VDI standard 4202, part 1 and standard EN 14626 define the following minimum requirements for the certification ranges of continuous air quality monitoring systems for carbon monoxide:

Table 3: Certification ranges VDI 4202-1 and EN 14626

| Measured components: | CR lower limit | CR upper limit | Limit value | Evaluation period |
|----------------------|----------------------|----------------------|----------------------|-------------------|
| | in mg/m ³ | in mg/m ³ | in mg/m ³ | |
| Carbon monoxide | 0 | 100 | 10 | 8 h |

6.1 7.3.12 Negative output signals

Negative output signals or measured values may not be suppressed (life zero).

6.2 Equipment

The test of this criterion did not require any further equipment.

6.3 Testing

The possibility of displaying negative signals was tested both in the laboratory and in the field test.

6.4 Evaluation

The AMS displays negative values.

6.5 Assessment

The measuring system also provides negative output signals.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable.

6.1 7.3.13 Failure in the mains voltage

In case of malfunction of the measuring system or failure in the mains voltage uncontrolled emission of operation and calibration gas shall be avoided. The measurement parameters shall be secured by buffering against loss caused by failure in the mains voltage. When mains voltage returns, the instrument shall automatically reach the operation mode and start the measurement according to the operating instructions.

6.2 Equipment

Not required for this performance criterion

6.3 Testing

A simulated failure in the mains voltage served to test whether the instrument remained fully functional and reached operation mode on return of the mains voltage.

6.4 Evaluation

Since the measuring systems do not rely on operation and calibration gases, uncontrolled emission of gases is not possible.

Once the measuring system resumes operation after a power failure it is in warm-up mode until it reaches an appropriate operating temperature again. How long it will take up to fully warm up again will depend on the ambient conditions and the temperature of the system when switching it back on again. After completion of the warm-up phase, the measuring system will switch back automatically into the mode which had been active before the failure in mains voltage. The warm-up phase is signalled via various temperature alerts.

6.5 Assessment

On return of mains voltage, the instrument returns to normal operating mode and automatically resumes measuring.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable.

6.1 7.3.14 Operating states

The measuring system shall allow the control of important operating states by telemetrically transmitted status signals.

6.2 Equipment

Computer for data acquisition

6.3 Testing

The measuring system possesses various interfaces such as RS232, USB, digital and analogue inputs and outputs, TCP/IP network. A simple connection can be established between the analyser (48iQ) and an external computer via a web browser. This enables telemetrically transferring data, adjusting configurations and displaying the analyser reading on the computer screen. In this mode it is possible to access and operate all the information and features from the analyser display via the computer. Moreover, "remote operation" provides a useful tool for checking instrument operational and parameter values.

6.4 Evaluation

The measuring system allows for comprehensive monitoring and control via various connectors.

6.5 Assessment

The measuring system provides various ports to ensure comprehensive monitoring and control via an external computer.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable.

6.1 7.3.15 Switch-over

Switch-over between measurement and functional check and/or calibration shall be possible telemetrically by computer control or manual intervention.

6.2 Equipment

Not required for this performance criterion

6.3 Testing

It is possible to monitor and control the AMS on the instrument itself or telemetrically.

6.4 Evaluation

All operating procedures which do not require on-site practical handling may be performed both by the operator on the instrument itself or telemetrically.

6.5 Assessment

In principle, it is possible to monitor all tasks necessary for a functional check on the instrument itself or telemetrically.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable.

6.1 7.3.16 Instrument software

The measuring system shall be able to display the version of the instrument software.

6.2 Equipment

Not required for this performance criterion

6.3 Testing

It was tested whether the software version can be displayed on the instrument. The AMS manufacturer was informed of his obligation to communicate any changes to the instrument software to the test laboratory.

6.4 Evaluation

The current software version is displayed when switching on the instrument. Furthermore, it can be accessed via menu item "configuration" at any time.

The tests were performed with software version "1.6.0. 32120".

6.5 Assessment

The instrument's software version is displayed. Software changes are communicated to the test laboratory.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Figure 5 shows the software version displayed by the measuring system.

6.1 7.4 Requirements on performance characteristics in the laboratory

6.1 7.4.1 General requirements

The performance characteristics which shall be determined during testing in the laboratory and their related performance criteria for measured components according to 39. BImSchV are given in Table A1 of VDI 4202-1.

The certification range for other components is to be defined. Performance criteria are to be defined by drawing from Table A1 of standard VDI 4202-1 (2018). These definitions shall be cleared with the relevant body before testing.

The determination of the performance characteristics shall be done according to the procedures de-scribed in Section 8.4 of VDI guideline 4202-1.

6.2 Equipment

Not required for this performance criterion

6.3 Testing

Tests were performed using the performance characteristics specified in VDI standard 4202, part 1 (2018) and standard EN 14626 (2012).

6.4 Evaluation

Not applicable.

6.5 Assessment

Tests were performed using the performance characteristics specified in VDI standard 4202, part 1 (2018) and standard EN 14626 (2012)

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable.

6.1 7.4.2 Test requirements

Before operating the measuring system, the instruction manual of the manufacturer shall be followed particularly with regard to the set-up of equipment and the quality and quantity of the consumable supplies necessary.

The measuring system shall be allowed to warm up for the duration specified by the manufacturer before undertaking any tests. If the warm-up time is not specified, a minimum of 4 h applies.

If auto-scale or self-correction functions are arbitrary, these functions shall be turned off during the laboratory test.

If auto-scale or self-correction functions are not arbitrary but treated as “normal operating conditions”, times and values of the self-correction shall be available for the test laboratory. The values of the auto-zero and auto-drift corrections are subject to the same restrictions as given in the performance characteristics.

Before applying test gases to the measuring system, the test gas system shall have been operated for a sufficiently long time in order to stabilize the concentrations applied to the measuring system. The measuring system shall be tested using an implemented particle filter.

Most measuring systems are able to display the output signal as running average of an adjustable period. Some measuring systems adjust the integration time as a function of the frequency of the fluctuations of the concentration of the measured component automatically. These options are typically used for equalisation of the output data. It does not have to be proved that the selected value for the averaging period or the use of an active filter affects the result of testing the averaging period and the response time.

The adjustments of the measuring system shall meet the specifications of the manufacturer. All adjustments are to be documented in the test report.

For the determination of the various performance characteristics, suitable zero and test gases shall be used.

Parameters: During the test for each individual performance characteristic, the values of the following parameters shall be stable within the specified range given in Table 3 of standard VDI 4202-1.

Test gas: For the determination of the various performance characteristics, test gases traceable to national or international standards shall be used.

6.2 Equipment

Not required for this performance criterion

6.3 Testing

Tests were performed using the performance characteristics specified in VDI standard 4202, part 1 (2018) and standard EN 14626 (2012).

6.4 Evaluation

The warm-up time described in the manual was observed.

Neither auto-scale nor self-correction functions were activated during the laboratory test.

The system for test gas application ran smoothly; tests were performed with the internal upstream particle filters.

The averaging time was set to 60 s for testing. No equalisation filters were activated.

Test gases used comply with the requirements of VDI 4202-1.

6.5 Assessment

Tests were performed using the performance characteristics specified in VDI standard 4202, part 1 (2018) and standard EN 14626 (2012)

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable.

6.1 7.4.3 Response time and memory effect

The response time (rise) of the measuring system shall not exceed 180 s.

The response time (fall) of the measuring system shall not exceed 180 s.

The difference between the response time (rise) and response time (fall) of the measuring system shall not exceed 10% of response time (rise) or 10 s, whatever value is larger.

6.2 Equipment

Not applicable

6.3 Testing

Determination and evaluation of the response time corresponds exactly to determining the response time in accordance with standard EN 14626 (2012). The reader is therefore referred to chapter 7.1 8.4.3 Response time.

6.4 Evaluation

See chapter 7.1 8.4.3 Response time

6.5 Assessment

See chapter 7.1 8.4.3 Response time

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 **7.4.4 Short-term drift**

The short-term drift at zero point shall not exceed 0.1 µmol/mol.

The short-term drift at reference point shall not exceed 0.60 µmol/mol.

6.2 **Equipment**

Not applicable

6.3 **Testing**

Determination and evaluation of the short-term drift corresponds exactly to determining the short term drift in accordance with standard EN 14626 (2012). The reader is therefore referred to chapter 7.1 8.4.4 Short-term drift.

6.4 **Evaluation**

See chapter 7.1 8.4.4 Short-term drift

6.5 **Assessment**

See chapter 7.1 8.4.4 Short-term drift

Criterion satisfied? yes

6.6 **Detailed presentation of test results**

Not applicable in this instance.

6.1 7.4.5 Repeatability standard deviation

The repeatability standard deviation at zero point shall be $\leq 0.3 \mu\text{mol/mol}$ of the upper limit of the certification range.

The repeatability standard deviation at span point shall be $\leq 0.4 \mu\text{mol/mol}$ of the upper limit of the certification range.

6.2 Equipment

Not applicable

6.3 Testing

Performing and evaluating the repeatability standard deviation at zero point corresponds exactly to determining the repeatability standard deviation in accordance with standard EN 14626 (2012). The reader is therefore referred to chapter 7.1 8.4.5 Repeatability standard deviation.

6.4 Evaluation

See chapter 7.1 8.4.5 Repeatability standard deviation.

6.5 Assessment

See chapter 7.1 8.4.5 Repeatability standard deviation

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.4.6 Linearity

*The analytical function describing the relationship between the measured values and the desired values shall be linear. Reliable linearity is
The deviation from the linearity of the calibration function at zero shall not exceed 0.5 µmol/mol. At concentrations above zero, it shall not exceed 4% of the measured value.*

6.2 Equipment

Not applicable

6.3 Testing

Performing and evaluating the linearity corresponds exactly to determining the lack of fit in accordance with standard EN 14626 (2012). The reader is therefore referred to chapter 7.1 8.4.6 Lack of fit of linearity of the calibration function.

6.4 Evaluation

See chapter 7.1 8.4.6 Lack of fit of linearity of the calibration function.

6.5 Assessment

See chapter 7.1 8.4.6 Lack of fit of linearity of the calibration function.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.4.7 Sensitivity coefficient to sample gas pressure

The sensitivity coefficient of sample gas pressure at reference point shall not exceed 0.7 (μmol/mol)/kPA.

6.2 Equipment

Not applicable

6.3 Testing

Performing and evaluating the sensitivity coefficient of sample gas pressure corresponds exactly to determining the sensitivity coefficient to sample gas pressure in accordance with standard EN 14626 (2012). The reader is therefore referred to chapter 7.1 8.4.7 Sensitivity coefficient to sample gas pressure.

6.4 Evaluation

See chapter 7.1 8.4.7 Sensitivity coefficient to sample gas pressure

6.5 Assessment

See chapter 7.1 8.4.7 Sensitivity coefficient to sample gas pressure
Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.4.8 Sensitivity coefficient to sample gas temperature

The sensitivity coefficient of sample gas temperature shall not exceed 0.3 (μmol/mol)/kPA.

6.2 Equipment

Not applicable

6.3 Testing

Performing and evaluating the sensitivity coefficient of sample gas temperature corresponds exactly to determining the sensitivity coefficient to sample gas temperature in accordance with standard EN 14626 (2012). The reader is therefore referred to chapter 7.18.4.8 Sensitivity coefficient to sample gas temperature.

6.4 Evaluation

See chapter 7.18.4.8 Sensitivity coefficient to sample gas temperature

6.5 Assessment

See chapter 7.18.4.8 Sensitivity coefficient to sample gas temperature

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.4.9 Sensitivity coefficient to surrounding temperature

The sensitivity coefficient of surrounding temperature shall not exceed 0.3 (μmol/mol)/kPA.

6.2 Equipment

Not applicable

6.3 Testing

Performing and evaluating the sensitivity coefficient of surrounding temperature corresponds exactly to determining the sensitivity coefficient to the surrounding temperature in accordance with standard EN 14626 (2012). The reader is therefore referred to chapter 7.1 8.4.9 Sensitivity coefficient to surrounding temperature.

6.4 Evaluation

See chapter 7.1 8.4.9 Sensitivity coefficient to surrounding temperature

6.5 Assessment

See chapter 7.1 8.4.9 Sensitivity coefficient to surrounding temperature
Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.4.10 Sensitivity coefficient to electrical voltage

The sensitivity coefficient of electrical voltage shall not exceed 0.3 (μmol/mol)/V.

6.2 Equipment

Not applicable

6.3 Testing

Performing and evaluating the sensitivity coefficient of electrical voltage corresponds exactly to determining the sensitivity coefficient to electrical voltage in accordance with standard EN 14626 (2012). The reader is therefore referred to chapter 7.1 8.4.10 Sensitivity coefficient to electrical voltage.

6.4 Evaluation

See chapter 7.1 8.4.10 Sensitivity coefficient to electrical voltage

6.5 Assessment

See chapter 7.1 8.4.10 Sensitivity coefficient to electrical voltage

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.4.11 Cross sensitivity

The change in the measured value caused by interfering components in the sample gas shall not exceed the requirements of Table A of VDI 4202, part 1 (April 2018), at zero and reference point.

For measuring principles deviating from EN standards the absolute values of the sum of the positive and the sum of negative deviations caused by interfering components in the sample gas shall not exceed 3% of the upper limit of the certification range at zero and reference point. A value c_i at 70% to 80% of the upper limit of the certification range shall be used as reference point.

6.2 Equipment

Not applicable

6.3 Testing

Performing and evaluating cross sensitivity corresponds exactly to determining interferences in accordance with standard EN 14626 (2012). The reader is therefore referred to chapter 7.1 8.4.11 Interferences

6.4 Evaluation

See chapter 7.1 8.4.11 Interferences

6.5 Assessment

See chapter 7.1 8.4.11 Interferences

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.4.12 Averaging effect

The measuring system shall enable hourly averages.

The averaging effect shall not exceed 7% of the measured value.

6.2 Equipment

Not applicable

6.3 Testing

See chapter 7.1 8.4.12 Averaging test

6.4 Evaluation

See chapter 7.1 8.4.12 Averaging test

6.5 Assessment

See chapter 7.1 8.4.12 Averaging test
Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.4.13 Difference between sample and calibration port

If a measuring system, standardly or optionally, possesses a test gas inlet separated from the sample gas inlet, this configuration shall be tested.

The difference between the measured values obtained by feeding gas at the sample gas and test gas inlet shall not exceed 1 %.

6.2 Equipment

Not applicable

6.3 Testing

Determination and evaluation of the difference between sample and calibration port corresponds exactly to determining the difference sample/calibration port in accordance with standard EN 14626 (2012). The reader is therefore referred to chapter 7.1 8.4.13 Difference sample/calibration port.

6.4 Evaluation

See chapter 7.1 8.4.13 Difference sample/calibration port

6.5 Assessment

See chapter 7.1 8.4.13 Difference sample/calibration port

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.4.14 Converter efficiency

In case of measuring systems with a converter, the converter efficiency shall be at least 98 % in the laboratory test.

6.2 Equipment

Not applicable

6.3 Testing

The tested measuring system does not have a converter.

6.4 Evaluation

Not applicable.

6.5 Assessment

Not applicable since the measuring system does not have a converter.

Criterion satisfied? Not applicable

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.4.15 Residence time in the analyser

If the residence time has influence on the output signal, like for NO_x and ozone measuring systems, it is necessary to calculate the residence time from the volume flow and the volume of the gas lines and other relevant components of the measuring system and the particle filter casing.

In the case of NO_x and O₃ measurements, the residence time shall not exceed 3 s.

6.2 Equipment

Not applicable

6.3 Testing

The analyser under test does not measure NO_x or ozone. Thus, the criterion does not apply here.

6.4 Evaluation

Not applicable.

6.5 Assessment

This criterion is not applicable since the measuring system does not measure NO_x or ozone.
Criterion satisfied? not applicable

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.5 Requirements on performance characteristics for testing in the field

6.1 7.5.1 General requirements

The performance characteristics which shall be determined during testing in the field and their related performance criteria for measured components according to 39. BImSchV are given in Table A1 of VDI 4202-1 (2018).

The certification range for other components is to be defined. Performance criteria are to be defined by drawing from Table A1 of VDI 4202-1 (2018) These definitions shall be cleared with the relevant body before testing.

The determination of the performance characteristics shall be done according to the procedures de-scribed in Section 8.5 of VDI 4202-1 (2018).

6.2 Equipment

Not required for this performance criterion

6.3 Testing

Tests were performed using the performance characteristics specified in VDI standard 4202, part 1 (2018) and standard EN 14626 (2012).

6.4 Evaluation

Not applicable.

6.5 Assessment

Tests were performed using the performance characteristics specified in VDI standard 4202, part 1 (2018) and standard EN 14626 (2012)

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable.

6.1 7.5.2 Location for the field test

The monitoring station for the field test is to be chosen according to the requirements of 39. BImSchV such that the expected concentrations of the measured components to be measured correspond to the designated task. The equipment of the monitoring station shall allow the implementation of the field test and shall fulfil all requirements considered to be necessary during measurement planning.

6.2 Equipment

Not required for this performance criterion

6.3 Testing

The field test location was selected in compliance with the 39th BImSchV.

6.4 Evaluation

The field test location was selected in compliance with the 39th BImSchV. The measuring station for the field test was located at a car park on the premises of TÜV Rheinland.

6.5 Assessment

The field test location was selected in compliance with the 39th BImSchV.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable.

6.1 7.5.3 Test requirements

The measuring systems shall be installed in the monitoring station and, after connecting to the existing or separate sampling system, activated properly.

The adjustments of the measuring system shall meet the specifications of the manufacturer. All adjustments are to be documented in the test report.

The measuring systems shall be maintained during the field test, following the manufacturer's specifications, and shall be checked with suitable test gases regularly.

If the measuring system contains auto-scale or self-correction functions and they are treated as "normal operating conditions", these functions shall be turned on during the field test. Values of the self-correction shall be available to the test laboratory. The values of the auto-zero and auto-drift corrections for the inspection interval (long-term drift) are subject to the same restrictions as given in the performance characteristics.

6.2 Equipment

Not required for this performance criterion

6.3 Testing

For the purpose of field testing, the measuring system was mounted in a measuring station and connected to the existing sampling system. The measuring system was then commissioned following the manufacturer's instructions in the manual.

Neither self-correction nor auto-zero functions were activated during the field test.

6.4 Evaluation

During the field test, the measuring system was operated and serviced according to the manufacturer's instructions. Neither self-correction nor auto-zero functions were activated.

6.5 Assessment

During the field test, the measuring system was operated and serviced according to the manufacturer's instructions.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable.

6.1 7.5.4 Long-term drift

The long-term drift at zero point shall not exceed 0.5 µmol/mol.

The long-term drift at reference point shall not exceed 5 % of the upper limit of the certification range.

6.2 Equipment

Not applicable

6.3 Testing

Determination and evaluation of the long-term drift corresponds exactly to determining the long term drift in accordance with standard EN 14626 (2012). The reader is therefore referred to chapter 7.1 8.5.4 Long-term drift.

6.4 Evaluation

See chapter 7.1 8.5.4 Long-term drift.

6.5 Assessment

See chapter 7.1 8.5.4 Long-term drift.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.5.5 Reproducibility standard deviation under field conditions

The standard deviation from paired measurements under field conditions shall be determined with two identical measuring systems by paired measurements in the field test.

The standard deviation under field conditions shall not exceed 5% of the mean value over a period of three months.

6.2 Equipment

Not applicable

6.3 Testing

Performing and evaluating the standard deviation from paired measurements corresponds exactly to determining the reproducibility standard deviation in accordance with standard EN 14626 (2012). The reader is therefore referred to Chapter 7.1 8.5.5 Reproducibility standard deviation for CO under field conditions.

6.4 Evaluation

See Chapter 7.1 8.5.5 Reproducibility standard deviation for CO under field conditions

6.5 Assessment

See Chapter 7.1 8.5.5 Reproducibility standard deviation for CO under field conditions

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.5.6 Inspection interval

The inspection interval of the measuring system shall be determined during the field test and specified. The maintenance interval should be three months, if possible, but at least two weeks.

6.2 Equipment

Not required for this performance criterion

6.3 Testing

Performing and evaluating the inspection interval corresponds exactly to determining the period of unattended operation in accordance with standard EN 14626 (2012). The reader is therefore referred to chapter 7.1 8.5.6 Inspection interval.

6.4 Evaluation

See chapter 7.1 8.5.6 Inspection interval.

6.5 Assessment

See chapter 7.1 8.5.6 Inspection interval.

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 7.5.7 Availability

The availability of the measuring system shall be determined during the field test and shall be at least 95%.

6.2 Equipment

Not applicable

6.3 Testing

Determination and evaluation of the availability corresponds exactly to determining the period of availability of the analyser in accordance with standard EN 14626 (2012). This is why we refer to Chapter 7.1 8.5.7 Period of availability of the analyser.

6.4 Evaluation

See Chapter 7.1 8.5.7 Period of availability of the analyser

6.5 Assessment

See Chapter 7.1 8.5.7 Period of availability of the analyser

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

6.1 **7.5.8 Converter efficiency**

At the end of the field test, the converter efficiency shall be at least 95 %.

6.2 **Equipment**

Not applicable

6.3 **Testing**

The tested measuring system does not have a converter.

6.4 **Evaluation**

Not applicable.

6.5 **Assessment**

Not applicable since the measuring system does not have a converter.

Criterion satisfied? not applicable

6.6 **Detailed presentation of test results**

Not applicable in this instance.

6.1 7.6 Type approval and calculation of the measurement uncertainty

The type approval of the measuring system requires the following:

- 1) *The value of each individual performance characteristic tested in the laboratory shall fulfil the criterion stated in Table C1 of VDI 4202-1 (2018).*
- 2) *The expanded uncertainty calculated from the standard uncertainties due to the values of the specific performance characteristics obtained in the laboratory tests shall fulfil the criterion as stated Table C1 of VDI 4202-1 (2018). This criterion is the maximum uncertainty of individual measurements for continuous measurements at the 1-hour limit value. The relevant specific performance characteristics and the calculation procedure are given in Annex F of standard VDI 4202-1 (2018).*
- 3) *The value of each individual performance characteristic tested in the laboratory shall fulfil the criterion stated in Table A1 of VDI 4202-1 (2018).*
- 4) *The expanded uncertainty calculated from the standard uncertainties due to the values of the specific performance characteristics obtained in the laboratory and field tests shall fulfil the criterion as stated Table C1 of VDI 4202-1 (2018). This criterion is the maximum uncertainty of individual measurements for continuous measurements at the 8-hour limit value. The relevant specific performance characteristics and the calculation procedure are given in Annex F of standard VDI 4202-1 (2018).*

6.2 Equipment

Not applicable

6.3 Testing

Uncertainty calculation was performed in line with standard EN 14626 (2012) and is presented in 7.1 8.6 Calculation of the total uncertainty in accordance with standard EN 14626 (2012) according to Annex E of EN 14626 (2012).

6.4 Evaluation

Uncertainty calculation was performed in line with standard EN 14626 (2012) and is presented in 7.1 8.6 Calculation of the total uncertainty in accordance with standard EN 14626 (2012) according to Annex E of EN 14626 (2012).

6.5 Assessment

Uncertainty calculation was performed in line with standard EN 14626 (2012) and is presented in 7.1 8.6 Calculation of the total uncertainty in accordance with standard EN 14626 (2012).

Criterion satisfied? yes

6.6 Detailed presentation of test results

Not applicable in this instance.

7. Test Results in accordance with Standard EN 14626 (2012)

7.1 8.4.3 Response time

Rise and fall response time ≤ 180 s each. Difference between rise and fall response time ≤ 10 s.

7.2 Testing

The determination of the response time shall be carried out by applying to the analyser a step function in the concentration from less than 20 % to about 80 % of the maximum of the certification range of NO and vice versa.

The change from zero gas to span gas and vice versa needs to be made almost instantaneously, with the use of a suitable valve. The valve outlet shall be mounted direct to the inlet of the analyser, and both zero gas and span gas shall have the same amount of gas in excess, which is vented by the use of a tee. The gas flows of both zero gas and span gas shall be chosen in such a way that the dead time in the valve and tee can be neglected compared to the lag time of the analyser system. The step change is made by switching the valve from zero gas to span gas. This event needs to be timed and is the start ($t = 0$) of the (rise) lag time for the dead time (rise) as shown in Figure 7. When the reading shows 98% of the applied concentration, the span gas can be changed to zero gas again; this event is the start ($t = 0$) of the (fall) lag time. When the reading shows 2% of the applied concentration, the whole cycle as shown in Figure 7 is complete.

The elapsed time (response time) between the start of the step change and reaching 90% of the analyser final stable reading of the applied concentration shall be measured. The whole cycle shall be repeated four times. The average of the four response times (rise) and the average of the four response times (fall) shall be calculated.

The difference in response times shall be calculated according to:


$$t_d = \bar{t}_r - \bar{t}_f$$

Where T_d is the difference between response time (rise) and response time (fall), in s;

t_r is the response time (rise) (average of the four response times - rise), in s;

t_f is the response time (fall) (average of the four response times - fall), in s.

t_r , t_f and t_d shall comply with the performance criteria indicated above.



Key

- Y analyser response
- X time
- 1 lag time
- 2 rise time
- 3 response time (rise)
- 4 fall time
- 5 response time (fall)

Figure 7: Diagram illustrating the response time

7.3 Testing

The test was performed in line with the requirements of EN 14626 mentioned before. An external data logger was used to record data.

7.4 Evaluation

Table 4: Response time of the 48iQ ambient air monitor for carbon monoxide

| | requirement | device 1 | | device 2 | |
|------------------------|--------------|----------|---|----------|---|
| average rise t_r [s] | ≤ 180 s | 48.5 | ✓ | 48.5 | ✓ |
| average fall t_f [s] | ≤ 180 s | 47.5 | ✓ | 47.5 | ✓ |
| difference t_d [s] | ≤ 10 s | 1.0 | ✓ | 1.0 | ✓ |

For carbon monoxide system 1, the maximum t_r was 48.5, the maximum t_f was 47.5 and t_d 1 s.

For carbon monoxide system 2, the maximum t_r was 48.5, the maximum t_f was 47.5 and t_d 1 s.

7.5 Assessment

The measured values remained considerably below the maximum permissible response time of 180 s at all times. The maximum response time determined for system 1 was 48.5 s, for system 2, it was 48.5 s.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Table 5: Individual results of the response time for carbon monoxide

| 80% | | device 1 | | | | | |
|-----------------|-------------|-------------|--------------|--------------|--------------|-------------|-------------|
| measuring range | 68.97 | rise | | | fall | | |
| | | 0.0 0.00 | 0.9 62.07 | 1.0 68.97 | 1.0 68.97 | 0.1 6.90 | 0.0 0.00 |
| cycle 1 | t = 0 | 10:22:00 | 10:22:48 | 10:23:00 | 10:28:00 | 10:28:47 | 10:29:00 |
| | delta t | | 00:00:48 | | | 00:00:47 | |
| | delta t [s] | | 48 | | | 47 | |
| cycle 2 | t = 0 | 10:36:00 | 10:36:49 | 10:37:00 | 10:42:00 | 10:42:48 | 10:43:00 |
| | delta t | | 00:00:49 | | | 00:00:48 | |
| | delta t [s] | | 49 | | | 48 | |
| cycle 3 | t = 0 | 10:49:00 | 10:49:48 | 10:50:00 | 10:55:00 | 10:55:48 | 10:56:00 |
| | delta t | | 00:00:48 | | | 00:00:48 | |
| | delta t [s] | | 48 | | | 48 | |
| cycle 4 | t = 0 | 11:02:00 | 11:02:49 | 11:03:00 | 11:08:00 | 11:08:47 | 11:09:00 |
| | delta t | | 00:00:49 | | | 00:00:47 | |
| | delta t [s] | | 49 | | | 47 | |

| 80% | | device 2 | | | | | |
|-----------------|-------------|-------------|--------------|--------------|--------------|-------------|-------------|
| measuring range | 68.97 | rise | | | fall | | |
| | | 0.0 0.00 | 0.9 62.07 | 1.0 68.97 | 1.0 68.97 | 0.1 6.90 | 0.0 0.00 |
| cycle 1 | t = 0 | 10:22:00 | 10:22:48 | 10:23:00 | 10:28:00 | 10:28:47 | 10:29:00 |
| | delta t | | 00:00:48 | | | 00:00:47 | |
| | delta t [s] | | 48 | | | 47 | |
| cycle 2 | t = 0 | 10:36:00 | 10:36:49 | 10:37:00 | 10:42:00 | 10:42:48 | 10:43:00 |
| | delta t | | 00:00:49 | | | 00:00:48 | |
| | delta t [s] | | 49 | | | 48 | |
| cycle 3 | t = 0 | 10:49:00 | 10:49:49 | 10:50:00 | 10:55:00 | 10:55:48 | 10:56:00 |
| | delta t | | 00:00:49 | | | 00:00:48 | |
| | delta t [s] | | 49 | | | 48 | |
| cycle 4 | t = 0 | 11:02:00 | 11:02:48 | 11:03:00 | 11:08:00 | 11:08:47 | 11:09:00 |
| | delta t | | 00:00:48 | | | 00:00:47 | |
| | delta t [s] | | 48 | | | 47 | |

7.1 8.4.4 Short-term drift

Short-term drift at zero shall not exceed 0.1 µmol/mol/12 h.

The short-term drift at reference level shall not exceed 0.60 µmol/mol/12 h.

7.2 Testing

After the required stabilisation period, the analyser shall be adjusted at zero and span level (around 70% to 80% of the maximum of the certification range). Wait the time equivalent to one independent reading and then record 20 individual measurements, first at zero and then at span concentration. From these 20 measurements, the average is calculated for zero and span level.

The analyser shall be kept running under the laboratory conditions. After a period of 12 h, zero and span gas is fed to the analyser. Wait the time equivalent to one independent reading and then record 20 individual measurements, first at zero and then at span concentration. The averages for zero and span level shall be calculated.

The short-term drift at zero and span level shall be calculated as follows:

$$D_{s,z} = (C_{z,2} - C_{z,1})$$

Where:

$D_{s,z}$ is the 12-hour drift at zero;

$C_{z,1}$ is the average concentration of the measurements at zero at the beginning of the drift period;

$C_{z,2}$ is the average concentration of the measurements at zero at the end of the drift period,

$D_{s,z}$ shall comply with the performance criterion indicated above.

$$D_{s,s} = (C_{s,2} - C_{s,1}) - D_{s,z}$$

Where:

$D_{s,s}$ is the 12-hour drift at span;

$C_{s,1}$ is the average concentration of the measurements at span level at the beginning of the drift period;

$C_{s,2}$ is the average concentration of the measurements at span level at the end of the drift period.

$D_{s,s}$ shall comply with the performance criterion indicated above.

7.3 Testing

The test was performed in line with the requirements of EN 14626 mentioned before. Pursuant to EN 14626, the test shall be performed at a concentration level of 70% to 80% of the certification range for carbon monoxide.

7.4 Evaluation

Table 6 indicates the measured value determined for the short-term drift.

Table 6: Results for the short-term drift

| | requirements | device 1 | | device 2 | |
|--|--------------|----------|---|----------|---|
| average at zero at the beginning [$\mu\text{mol/mol}$] | - | 0.05 | | -0.07 | |
| average at zero at the end [$\mu\text{mol/mol}$] | - | 0.09 | | -0.05 | |
| average at span at the beginning [$\mu\text{mol/mol}$] | - | 65.32 | | 64.92 | |
| average at span at the end [$\mu\text{mol/mol}$] | - | 65.56 | | 65.05 | |
| 12-hour drift at zero $D_{s,z}$ [$\mu\text{mol/mol}$] | $\leq 0,1$ | 0.04 | ✓ | 0.01 | ✓ |
| 12-hour drift at span $D_{s,s}$ [$\mu\text{mol/mol}$] | $\leq 0,6$ | 0.20 | ✓ | 0.12 | ✓ |

7.5 Assessment

For instrument 1 the value for the short-term drift at zero point was 0.04 $\mu\text{mol/mol}$, for instrument 2 it was 0.01 $\mu\text{mol/mol}$.

Short-term drift at reference point was 0.20 $\mu\text{mol/mol}$ for instrument 1 and 0.12 $\mu\text{mol/mol}$ for instrument 2.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Table 7 and Table 8 present the individual test results.

Table 7: Individual results for the short-term drift 1st Test gas application:

| at beginning | | |
|----------------|-------------------------|-------------------------|
| zero level | | |
| | device 1 | device 2 |
| time | [$\mu\text{mol/mol}$] | [$\mu\text{mol/mol}$] |
| 09:36:00 | 0.0 | -0.1 |
| 09:37:00 | 0.0 | -0.1 |
| 09:38:00 | 0.0 | -0.1 |
| 09:39:00 | 0.1 | -0.1 |
| 09:40:00 | 0.1 | -0.1 |
| 09:41:00 | 0.1 | -0.1 |
| 09:42:00 | 0.0 | -0.1 |
| 09:43:00 | 0.1 | -0.1 |
| 09:44:00 | 0.1 | -0.1 |
| 09:45:00 | 0.1 | -0.1 |
| 09:46:00 | 0.1 | -0.1 |
| 09:47:00 | 0.1 | -0.1 |
| 09:48:00 | 0.1 | -0.1 |
| 09:49:00 | 0.1 | -0.1 |
| 09:50:00 | 0.1 | -0.1 |
| 09:51:00 | 0.1 | -0.1 |
| 09:52:00 | 0.1 | -0.1 |
| 09:53:00 | 0.1 | -0.1 |
| 09:54:00 | 0.1 | -0.1 |
| 09:55:00 | 0.1 | -0.1 |
| average | 0.0 | -0.1 |

| at beginning | | |
|----------------|-------------------------|-------------------------|
| span level | | |
| | device 1 | device 2 |
| time | [$\mu\text{mol/mol}$] | [$\mu\text{mol/mol}$] |
| 10:01:00 | 65.3 | 64.9 |
| 10:02:00 | 65.3 | 64.8 |
| 10:03:00 | 65.3 | 64.8 |
| 10:04:00 | 65.3 | 64.9 |
| 10:05:00 | 65.3 | 64.9 |
| 10:06:00 | 65.4 | 64.9 |
| 10:07:00 | 65.4 | 64.9 |
| 10:08:00 | 65.3 | 65.0 |
| 10:09:00 | 65.3 | 64.8 |
| 10:10:00 | 65.3 | 64.9 |
| 10:11:00 | 65.4 | 64.9 |
| 10:12:00 | 65.4 | 64.9 |
| 10:13:00 | 65.3 | 64.9 |
| 10:14:00 | 65.3 | 64.9 |
| 10:15:00 | 65.3 | 64.9 |
| 10:16:00 | 65.3 | 64.9 |
| 10:17:00 | 65.3 | 64.9 |
| 10:18:00 | 65.4 | 65.0 |
| 10:19:00 | 65.4 | 65.1 |
| 10:20:00 | 65.3 | 65.0 |
| average | 65.3 | 64.9 |

Table 8: Individual results for the short-term drift 2nd Test gas application:

| after 12h | | |
|----------------|------------|-------------|
| zero level | | |
| | device 1 | device 2 |
| time | [µmol/mol] | [µmol/mol] |
| 21:36:00 | 0.1 | 0.0 |
| 21:37:00 | 0.1 | -0.1 |
| 21:38:00 | 0.1 | -0.1 |
| 21:39:00 | 0.1 | -0.1 |
| 21:40:00 | 0.1 | -0.1 |
| 21:41:00 | 0.1 | -0.1 |
| 21:42:00 | 0.1 | -0.1 |
| 21:43:00 | 0.1 | -0.1 |
| 21:44:00 | 0.1 | -0.1 |
| 21:45:00 | 0.1 | -0.1 |
| 21:46:00 | 0.1 | -0.1 |
| 21:47:00 | 0.1 | -0.1 |
| 21:48:00 | 0.1 | -0.1 |
| 21:49:00 | 0.1 | -0.1 |
| 21:50:00 | 0.1 | -0.1 |
| 21:51:00 | 0.1 | -0.1 |
| 21:52:00 | 0.1 | -0.1 |
| 21:53:00 | 0.1 | -0.1 |
| 21:54:00 | 0.1 | -0.1 |
| 21:55:00 | 0.1 | -0.1 |
| average | 0.1 | -0.1 |

| after 12h | | |
|----------------|-------------|-------------|
| span level | | |
| | device 1 | device 2 |
| time | [µmol/mol] | [µmol/mol] |
| 22:01:00 | 65.5 | 65.1 |
| 22:02:00 | 65.5 | 65.0 |
| 22:03:00 | 65.5 | 65.0 |
| 22:04:00 | 65.6 | 65.0 |
| 22:05:00 | 65.6 | 65.0 |
| 22:06:00 | 65.6 | 65.1 |
| 22:07:00 | 65.6 | 65.0 |
| 22:08:00 | 65.5 | 65.0 |
| 22:09:00 | 65.6 | 65.0 |
| 22:10:00 | 65.6 | 65.0 |
| 22:11:00 | 65.6 | 65.0 |
| 22:12:00 | 65.6 | 65.0 |
| 22:13:00 | 65.5 | 65.0 |
| 22:14:00 | 65.6 | 65.1 |
| 22:15:00 | 65.5 | 65.0 |
| 22:16:00 | 65.5 | 65.1 |
| 22:17:00 | 65.5 | 65.1 |
| 22:18:00 | 65.5 | 65.1 |
| 22:19:00 | 65.6 | 65.0 |
| 22:20:00 | 65.6 | 65.1 |
| average | 65.6 | 65.0 |

7.1 8.4.5 Repeatability standard deviation

The performance criteria are as follows: Repeatability standard deviation at zero shall not exceed 0.3 µmol/mol. At a sample gas concentration at the reference point it shall not exceed 0.4 µmol/mol.

7.2 Test procedure

After waiting the time equivalent of one independent reading, 20 individual measurements both at zero concentration and at a test concentration (c_t), which is similar to that of the 8h limit value shall be performed.

From these measurements, the repeatability standard deviation (s_r) at zero concentration and at concentration c_t shall be calculated according to:

$$s_r = \sqrt{\frac{\sum (x_i - \bar{x})^2}{n - 1}}$$

Where:

- s_r the repeatability standard deviation;
- x_i the i th measurement;
- \bar{x} is the average of the 20 measurements;
- n is the number of measurements.

The repeatability standard deviation shall be calculated separately for both series of measurements (zero gas and concentration c_t).

s_r shall comply with the performance criterion indicated above, both at zero and at the test gas concentration c_t (8h limit value).

The detection limit, lower detection limit of the measuring system is calculated from the repeatability standard deviation and the slope of the calibration function determined in accordance with Chapter 8.4.6 according to the following equation:

$$l_{\text{det}} = 3,3 \cdot \frac{s_{r,z}}{B}$$

Where:

- l_{det} is the detection limit of the measuring system, in µmol/mol;
- $s_{r,z}$ is the repeatability standard deviation at zero, in µmol/mol;
- B is the slope of the calibration function according to Annex A based on the data from 8.4.6.

7.3 Testing

The test was performed in line with the requirements of EN 14626 mentioned before. Pursuant to EN 14626, the test shall be performed at a concentration level of 8.6 µmol/mol CO.

7.4 Evaluation

Table 9 presents the results for the repeatability standard deviation.

Table 9: Repeatability standard deviation at zero and reference point

| | requirement | device 1 | | device 2 | |
|---|-------------|----------|---|----------|---|
| repeatability standard deviation $s_{r,z}$ at zero [µmol/mol] | ≤ 0,3 | 0.02 | ✓ | 0.02 | ✓ |
| repeatability standard deviation $s_{r,ct}$ at c_t [µmol/mol] | ≤ 0,4 | 0.01 | ✓ | 0.03 | ✓ |
| detection limit [µmol/mol] | | 0.05 | | 0.07 | |

7.5 Assessment

For instrument 1 the value for the repeatability standard deviation at zero point was 0.02 µmol/mol, for instrument 2 it was 0.02 µmol/mol. Repeatability standard deviation at reference point was 0.01 µmol/mol for instrument 1 and 0.03 µmol/mol for instrument 2.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Table 10 lists the results of individual measurements.

Table 10: Individual test results obtained for the repeatability standard deviation

| zero level | | |
|------------|-------------------------|-------------------------|
| | device 1 | device 2 |
| time | [$\mu\text{mol/mol}$] | [$\mu\text{mol/mol}$] |
| 11:27:00 | 0.16 | 0.16 |
| 11:28:00 | 0.16 | 0.16 |
| 11:29:00 | 0.16 | 0.16 |
| 11:30:00 | 0.16 | 0.16 |
| 11:31:00 | 0.16 | 0.16 |
| 11:32:00 | 0.16 | 0.16 |
| 11:33:00 | 0.16 | 0.16 |
| 11:34:00 | 0.16 | 0.16 |
| 11:35:00 | 0.16 | 0.16 |
| 11:36:00 | 0.16 | 0.16 |
| 11:37:00 | 0.16 | 0.16 |
| 11:38:00 | 0.16 | 0.22 |
| 11:39:00 | 0.16 | 0.16 |
| 11:40:00 | 0.16 | 0.16 |
| 11:41:00 | 0.16 | 0.16 |
| 11:42:00 | 0.16 | 0.22 |
| 11:43:00 | 0.11 | 0.16 |
| 11:44:00 | 0.16 | 0.16 |
| 11:45:00 | 0.16 | 0.22 |
| 11:46:00 | 0.11 | 0.22 |
| average | 0.16 | 0.17 |

| c_t level | | |
|-------------|-------------------------|-------------------------|
| | device 1 | device 2 |
| time | [$\mu\text{mol/mol}$] | [$\mu\text{mol/mol}$] |
| 12:14:00 | 8.71 | 8.60 |
| 12:15:00 | 8.71 | 8.60 |
| 12:16:00 | 8.71 | 8.60 |
| 12:17:00 | 8.71 | 8.65 |
| 12:18:00 | 8.71 | 8.60 |
| 12:19:00 | 8.71 | 8.60 |
| 12:20:00 | 8.71 | 8.60 |
| 12:21:00 | 8.71 | 8.60 |
| 12:22:00 | 8.71 | 8.60 |
| 12:23:00 | 8.71 | 8.55 |
| 12:24:00 | 8.71 | 8.60 |
| 12:25:00 | 8.71 | 8.55 |
| 12:26:00 | 8.71 | 8.60 |
| 12:27:00 | 8.71 | 8.60 |
| 12:28:00 | 8.71 | 8.55 |
| 12:29:00 | 8.71 | 8.55 |
| 12:30:00 | 8.71 | 8.55 |
| 12:31:00 | 8.65 | 8.60 |
| 12:32:00 | 8.71 | 8.60 |
| 12:33:00 | 8.71 | 8.55 |
| average | 8.70 | 8.59 |

7.1 8.4.6 Lack of fit of linearity of the calibration function

The deviation from the linearity of the calibration function at zero shall not exceed 0.5 µmol/mol. At concentrations above zero, it shall not exceed 4% of the measured value.

7.2 Test procedure

The lack of fit of linearity of the calibration function of the analyser shall be tested over the range of 0% to 95% of the maximum of the certification range of NO, using at least six concentrations (including the zero point). The analyser shall be adjusted at a concentration of about 90% of the maximum of the certification range. At each concentration (including zero) at least five individual measurements shall be performed.

The concentrations shall be applied in the following sequence: 80%, 40%, 0%, 60%, 20% and 95%. After each change in concentration, at least four response times shall be taken into account before the next measurement is performed.

The regression function and the deviations are calculated in accordance with Annex A of standard EN 14626. The deviations from the linear regression function shall comply with the performance criterion specified above.

Establishment of the regression line:

A linear regression function in the form of $Y_i = A + B * X_i$ is made through calculation of the following formula:

$$Y_i = a + B(X_i - X_z)$$

For the regression calculation, all measuring points (including zero) are taken into account. The total number of measuring points is equal to the number of concentration levels (at least six including zero) times the number of repetitions (at least five) at a particular concentration level.

The coefficient a is obtained from:

$$a = \sum Y_i / n$$

Where:

- a is the average value of the Y-values;
- Y_i is the individual Y-value;
- N is the number of measuring points.

The coefficient B is obtained from:

$$B = (\sum Y_i (X_i - X_z)) / \sum (X_i - X_z)^2$$

Where:

- X_z is the average of the x-values ($= \sum (X_i / n)$)
- X_i is the individual x-value.

is the individual x-value. The function $Y_i = a + B (X_i - X_z)$ is converted to $Y_i = A + B * X_i$ through the calculation of A:

$$A = a - B * X_z$$

The residuals of the averages of each calibration point (including the zero point) are calculated as follows.

The average of each calibration point (including the zero point) at one and the same concentration c is calculated according to:

$$(Y_a)_c = \sum(Y_i)_c / m$$

Where:

$(Y_a)_c$ is the average y-value at concentration level c;

$(Y_i)_c$ is the individual y-value at concentration level c;

M is the number of repetitions at one and the same concentration level c;

The residual of each average (r_c) at each concentration level is calculated according to:

$$r_c = (Y_a)_c - (A + B \times c)$$

Each residual to a value relative to its own concentration level c is expressed in % as:

$$r_{c,rel} = \frac{r_c}{c} \times 100\%$$

7.3 Testing

The test was performed in line with the requirements of EN 14626 mentioned before.

7.4 Evaluation

The following linear regressions were established:

Figure 8 and Figure 9 provide a graphic summary of the group averages for carbon monoxide.

Table 11: Deviation from the analytical function for carbon monoxide

| | requirements | device 1 | | device 2 | |
|---|--------------|----------|---|----------|---|
| largest value of the relative residuals r_{max} [%] | $\leq 4,0$ | 1.33 | ✓ | 1.24 | ✓ |
| residual at zero r_z [$\mu\text{mol/mol}$] | $\leq 0,5$ | 0.13 | ✓ | -0.01 | ✓ |




Figure 8: Analytical function obtained from the group averages for system 1




Figure 9: Analytical function obtained from the group averages for system 2

7.5 Assessment

The deviation from the linear regression line for instrument 1 is 0.13 µmol/mol at zero point and no more than 1.33% of the target value for concentrations above zero. The deviation from the linear regression line for instrument 2 is -0.01 µmol/mol at zero point and no more than 1.24% of the target value for concentrations above zero.

The residuals from the ideal regression line do not exceed the limit values required by standard EN 14626.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Table 12 presents the individual test results.

Table 12: Individual results of the lack-of-fit test

| | | device 1 [µmol/mol] | | device 2 [µmol/mol] | |
|-------------|-----------|---------------------|-----------------|---------------------|-----------------|
| time | level [%] | actual value y_i | set value x_i | actual value y_i | set value x_i |
| 10:31:00 | 80 | 70.25 | 68.97 | 69.71 | 68.97 |
| 10:32:00 | 80 | 70.25 | 68.97 | 69.77 | 68.97 |
| 10:33:00 | 80 | 70.25 | 68.97 | 69.77 | 68.97 |
| 10:34:00 | 80 | 70.20 | 68.97 | 69.77 | 68.97 |
| 10:35:00 | 80 | 70.31 | 68.97 | 69.82 | 68.97 |
| average | | 70.25 | | 69.77 | |
| $r_{c,rel}$ | | -0.10 | | -0.12 | |
| 10:40:00 | 40 | 34.83 | 34.48 | 34.50 | 34.48 |
| 10:41:00 | 40 | 34.77 | 34.48 | 34.50 | 34.48 |
| 10:42:00 | 40 | 34.77 | 34.48 | 34.50 | 34.48 |
| 10:43:00 | 40 | 34.77 | 34.48 | 34.50 | 34.48 |
| 10:44:00 | 40 | 34.77 | 34.48 | 34.50 | 34.48 |
| average | | 34.79 | | 34.50 | |
| $r_{c,rel}$ | | -0.56 | | -0.54 | |
| 10:49:00 | 0 | 0.11 | 0.00 | -0.05 | 0.00 |
| 10:50:00 | 0 | 0.11 | 0.00 | -0.05 | 0.00 |
| 10:51:00 | 0 | 0.11 | 0.00 | 0.00 | 0.00 |
| 10:52:00 | 0 | 0.11 | 0.00 | -0.05 | 0.00 |
| 10:53:00 | 0 | 0.22 | 0.00 | 0.11 | 0.00 |
| average | | 0.13 | | -0.01 | |
| r_z | | | | | |
| 10:58:00 | 60 | 52.03 | 51.72 | 51.65 | 51.72 |
| 10:59:00 | 60 | 51.97 | 51.72 | 51.75 | 51.72 |
| 11:00:00 | 60 | 51.97 | 51.72 | 51.65 | 51.72 |
| 11:01:00 | 60 | 52.03 | 51.72 | 51.65 | 51.72 |
| 11:02:00 | 60 | 51.81 | 51.72 | 51.43 | 51.72 |
| average | | 51.96 | | 51.62 | |
| $r_{c,rel}$ | | -1.33 | | -1.24 | |
| 11:07:00 | 20 | 17.14 | 17.24 | 16.93 | 17.24 |
| 11:08:00 | 20 | 17.14 | 17.24 | 16.93 | 17.24 |
| 11:09:00 | 20 | 17.14 | 17.24 | 16.93 | 17.24 |
| 11:10:00 | 20 | 17.14 | 17.24 | 16.98 | 17.24 |
| 11:11:00 | 20 | 17.25 | 17.24 | 17.14 | 17.24 |
| average | | 17.16 | | 16.98 | |
| $r_{c,rel}$ | | -0.84 | | -0.75 | |
| 11:16:00 | 95 | 84.09 | 81.90 | 83.55 | 81.90 |
| 11:17:00 | 95 | 84.20 | 81.90 | 83.55 | 81.90 |
| 11:18:00 | 95 | 84.20 | 81.90 | 83.65 | 81.90 |
| 11:19:00 | 95 | 84.20 | 81.90 | 83.65 | 81.90 |
| 11:20:00 | 95 | 84.20 | 81.90 | 83.65 | 81.90 |
| average | | 84.17 | | 83.61 | |
| $r_{c,rel}$ | | 0.74 | | 0.71 | |

7.1 8.4.7 Sensitivity coefficient to sample gas pressure

The sensitivity coefficient to sample gas pressure shall be $\leq 0.7 \mu\text{mol/mol/kPa}$.

7.2 Test procedures

Measurements are taken at a concentration of about 70% to 80% of the maximum of the certification range of NO at an absolute pressure of about (80 ± 0.2) kPa and at an absolute pressure of about (110 ± 0.2) kPa. At each pressure after waiting the time equivalent to one independent reading, three individual measurements are recorded. From these measurements, the averages at each pressure are calculated.

Measurements at different pressures shall be separated by at least four response times.

The sensitivity coefficient to sample gas pressure is calculated as follows.

$$b_{gp} = \left| \frac{(C_{P2} - C_{P1})}{(P_2 - P_1)} \right|$$

Where:

b_{gp} is the sample gas pressure sensitivity coefficient;

C_{P1} is the average concentration of the measurements at sampling gas pressure P_1 ;

C_{P2} is the average concentration of the measurements at sampling gas pressure P_2 ;

P_1 is the minimum sampling gas pressure P_1 ;

P_2 is the maximum sampling gas pressure P_2 .

b_{gp} shall comply with the performance criterion indicated above.

7.3 Testing

The test was performed in line with the requirements of EN 14626 mentioned before.

Negative pressure was produced by reducing the test gas volume fed by means of blocking the sample gas line. For the positive pressure test, the AMS was connected to a sample gas source. The test gas volume generated was set at a higher rate than the volume sucked in by the analyser. The excess supply was diverted via a tee. The positive pressure was produced by blocking the bypass line. The test gas pressure was determined with the help of a pressure sensor located in the sample gas path.

Individual measurements were performed at concentrations around 70% to 80% of the maximum certification range and sample gas pressures of 80 kPa and 110 kPa.

7.4 Evaluation

The following sensitivity coefficients to sample gas pressure were determined:

Table 13 Sensitivity coefficient of sample gas pressure

| | requirement | device 1 | | device 2 | |
|---|-------------|----------|---|----------|---|
| sensitivity coeff. sample gas pressure b_{gp} [$\mu\text{mol/mol/kPa}$] | $\leq 0,7$ | 0.02 | ✓ | 0.02 | ✓ |

7.5 Assessment

For instrument 1, the sensitivity coefficient to sample gas pressure is 0.02 $\mu\text{mol/mol/kPa}$.

For instrument 2, the sensitivity coefficient to sample gas pressure is 0.02 $\mu\text{mol/mol/kPa}$.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Table 14: Individual results of the sensitivity to changes in sample gas pressure

| time | pressure [kPa] | concentration | device 1 | device 2 |
|------------------|----------------|---------------|-------------------------|-------------------------|
| | | | [$\mu\text{mol/mol}$] | [$\mu\text{mol/mol}$] |
| 13:04:00 | 80 | 64.66 | 64.50 | 64.72 |
| 13:05:00 | 80 | 64.66 | 64.50 | 64.82 |
| 13:06:00 | 80 | 64.66 | 64.55 | 64.88 |
| average C_{P1} | | | 64.52 | 64.80 |
| 13:17:00 | 110 | 64.66 | 65.09 | 65.36 |
| 13:18:00 | 110 | 64.66 | 65.09 | 65.36 |
| 13:19:00 | 110 | 64.66 | 65.15 | 65.47 |
| average C_{P2} | | | 65.11 | 65.40 |

7.1 8.4.8 Sensitivity coefficient to sample gas temperature

The sensitivity coefficient to sample gas temperature shall be $\leq 0.3 \mu\text{mol/mol/K}$.

7.2 Test procedures

Measurements shall be performed at sample gas temperatures of $T_{G,1} = 0 \text{ °C}$ and $T_{G,2} = 30 \text{ °C}$. The sensitivity coefficient to sample gas temperature is determined at a concentration of around 70% to 80% of the maximum certification range. Wait the time equivalent to one independent measurement and record three individual measurements at each temperature.

The sample gas temperature, measured at the inlet of the analyser, shall be held constant for at least 30 minutes.

The sensitivity coefficient to sample gas temperature is calculated as follows:

$$b_{gt} = \frac{(C_{GT,2} - C_{GT,1})}{(T_{G,2} - T_{G,1})}$$

Where:

- b_{gt} is the sample gas temperature sensitivity coefficient;
- $C_{GT,1}$ is the average concentration of the measurements at sample gas temperature $T_{G,1}$;
- $C_{GT,2}$ is the average concentration of the measurements at sample gas temperature $T_{G,2}$;
- $T_{G,1}$ is the sample gas temperature $T_{G,1}$;
- $T_{G,2}$ is the sample gas temperature $T_{G,2}$;
- b_{gt} shall comply with the performance criterion indicated above.

7.3 Testing

The test was performed in line with the requirements of EN 14626 mentioned before.

For the purpose of this test, the test gas mixture was led through a 40m tube-bundle which was situated in a climatic chamber. The measuring systems were installed directly upstream of the climatic chamber. The end of the tube-bundle was led out of the climatic chamber and connected to the measuring systems. The feed line outside of the climatic chamber was isolated; a thermometer was used to monitor the temperature of the test gas directly upstream of the measuring system. The temperature of the climatic chamber was adjusted so that the gas temperature directly upstream of the analysers was exactly 0 °C . For the purpose of testing a gas temperature of 30 °C , gas was led through a heated line instead of the tube bundle in the climatic chamber.

7.4 Evaluation

Table 15: Sensitivity coefficient to sample gas temperature

| | requirement | device 1 | device 2 | |
|---|-------------|----------|----------|---|
| sensitivity coeff. sample gas pressure b_{gt} [$\mu\text{mol/mol/K}$] | $\leq 0,3$ | 0.06 | 0.10 | ✓ |

7.5 Assessment

For instrument 1, the sensitivity coefficient to sample gas temperature is 0.06 $\mu\text{mol/mol/K}$.

For instrument 2, the sensitivity coefficient to sample gas temperature is 0.10 $\mu\text{mol/mol/K}$.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Table 16: Individual results for the determination of the sensitivity to sample gas temperature

| time | temp [$^{\circ}\text{C}$] | concentration | device 1 | device 2 |
|--------------------|-----------------------------|---------------|-------------------------|-------------------------|
| | | | [$\mu\text{mol/mol}$] | [$\mu\text{mol/mol}$] |
| 10:44:00 | 0 | 65.00 | 67.73 | 66.97 |
| 10:45:00 | 0 | 65.00 | 67.67 | 67.03 |
| 10:46:00 | 0 | 65.00 | 67.89 | 67.13 |
| average $C_{GT,1}$ | | | 67.76 | 67.04 |
| 12:53:00 | 30 | 65.00 | 65.41 | 63.69 |
| 12:54:00 | 30 | 65.00 | 66.38 | 64.12 |
| 12:55:00 | 30 | 65.00 | 65.84 | 64.18 |
| average $C_{GT,1}$ | | | 65.88 | 64.00 |

7.1 8.4.9 Sensitivity coefficient to surrounding temperature

The sensitivity coefficient to surrounding temperature shall be $\leq 0.3 \mu\text{mol/mol/K}$.

7.2 Test procedures

The sensitivity of the analyser readings to the surrounding temperature shall be determined by performing measurements at the following temperatures within the specifications of the manufacturer:

- 1) at the minimum temperature $T_{\min} = 0 \text{ }^\circ\text{C}$;
- 2) at the temperature $T_1 = 20 \text{ }^\circ\text{C}$;
- 3) at the maximum temperature $T_{\max} = 30 \text{ }^\circ\text{C}$.

For these tests, a climate chamber is necessary.

The sensitivity coefficient to surrounding temperature is determined at a concentration of around 70% to 80% of the maximum certification range. At each temperature setting after waiting the time equivalent to one independent measurement, three individual measurements at zero and at span shall be recorded.

The sequence of test temperatures is as follows:

T_1, T_{\min}, T_1 and T_1, T_{\max}, T_1

At the first temperature (T_1), the analyser shall be adjusted at zero and at span level (70% to 80% of the maximum of the certification range). Then three individual measurements are recorded after waiting the time equivalent to one independent reading at T_1 , at T_{\min} and again at T_1 . This measurement procedure shall be repeated at the temperature sequence of T_1, T_{\max} and at T_1 .

In order to exclude any possible drift due to factors other than temperature, the measurements at T_1 are averaged, which is taken into account in the following formula for calculation of the sensitivity coefficient for temperature dependence:

$$b_{st} = \left| \frac{x_T - \frac{x_1 + x_2}{2}}{T_S - T_{S,0}} \right|$$

Where:

b_{st} is the surrounding temperature sensitivity coefficient;

x_T is the average of the measurements at T_{\min} or T_{\max} ;

x_1 is the first average of the measurements at T_1 ;

x_2 is the second average of the measurements at T_1 ;

T_S is the surrounding temperature in the laboratory;

$T_{S,0}$ is the average of the surrounding temperatures at set point.

For reporting the surrounding temperature dependence the higher value is taken of the two calculations of the temperature dependence at $T_{S,1}$ and $T_{S,2}$.

b_{st} shall comply with the performance criterion indicated above.

7.3 Testing

The test was performed in line with the requirements of EN 14626 mentioned before.

7.4 Evaluation

The following sensitivity coefficients to surrounding temperature have been determined:

Table 17: Sensitivity coefficients to surrounding temperature

| | requirements | device 1 | | device 2 | |
|---|--------------|----------|---|----------|---|
| sensitivity coefficient at 0 °C for zero level [$\mu\text{mol}/\text{mol}/\text{K}$] | $\leq 0,3$ | 0.014 | ✓ | 0.029 | ✓ |
| sensitivity coefficient at 30 °C for zero level [$\mu\text{mol}/\text{mol}/\text{K}$] | $\leq 0,3$ | 0.002 | ✓ | 0.035 | ✓ |
| sensitivity coefficient at 0 °C for span level [$\mu\text{mol}/\text{mol}/\text{K}$] | $\leq 0,3$ | 0.000 | ✓ | 0.008 | ✓ |
| sensitivity coefficient at 30 °C for span level [$\mu\text{mol}/\text{mol}/\text{K}$] | $\leq 0,3$ | 0.021 | ✓ | 0.081 | ✓ |

As is evident from Table 17, the sensitivity coefficient to the surrounding temperature at zero and at reference point meets the performance criteria.

7.5 Assessment

The sensitivity coefficient to the surrounding temperature b_{st} did not exceed the performance criterion specified at $0.3 \mu\text{mol/mol/K}$. For the purpose of uncertainty calculation, the largest value b_{st} is used for both instruments. For instrument 1, this is $0.021 \mu\text{mol/mol/K}$ and for instrument 2 it is $0.081 \mu\text{mol/mol/K}$.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Table 18 presents the individual test results.

Table 18: Individual test results for the sensitivity coefficient to ambient temperature

| date | zero level | | | | span level | | | | |
|---------------------------------------|------------|-----------|-------------------------------------|-------------------------------------|------------|-----------|-------------------------------------|-------------------------------------|------|
| | time | temp [°C] | device 1 [$\mu\text{mol/mol}$] | device 2 [$\mu\text{mol/mol}$] | time | temp [°C] | device 1 [$\mu\text{mol/mol}$] | device 2 [$\mu\text{mol/mol}$] | |
| 28.05.2018 | 08:07:00 | 20 | 0.0 | 0.0 | 08:17:00 | 20 | 65.4 | 64.6 | |
| 28.05.2018 | 08:08:00 | 20 | -0.1 | -0.1 | 08:18:00 | 20 | 65.1 | 64.6 | |
| 28.05.2018 | 08:09:00 | 20 | 0.2 | -0.1 | 08:19:00 | 20 | 64.6 | 64.3 | |
| average ($X_{1(TS1)}$) | | | 0.1 | 0.0 | | | 65.0 | 64.5 | |
| 28.05.2018 | 14:39:00 | 0 | 0.5 | 0.6 | 14:49:00 | 0 | 65.1 | 65.0 | |
| 28.05.2018 | 14:40:00 | 0 | 0.3 | 0.6 | 14:50:00 | 0 | 65.1 | 64.9 | |
| 28.05.2018 | 14:41:00 | 0 | 0.4 | 0.6 | 14:51:00 | 0 | 65.0 | 64.8 | |
| average (X_{TS1}) | | | 0 | 0.4 | 0.6 | | | 65.1 | 64.9 |
| 29.05.2018 | 07:54:00 | 20 | 0.2 | 0.1 | 08:04:00 | 20 | 65.3 | 65.5 | |
| 29.05.2018 | 07:55:00 | 20 | 0.2 | 0.1 | 08:05:00 | 20 | 65.1 | 65.6 | |
| 29.05.2018 | 07:56:00 | 20 | 0.3 | 0.1 | 08:06:00 | 20 | 65.1 | 65.6 | |
| average ($X_{2(TS1)} = X_{1(TS2)}$) | | | 0.2 | 0.1 | | | 65.2 | 65.6 | |
| 29.05.2018 | 14:41:00 | 30 | 0.5 | -0.3 | 14:51:00 | 30 | 65.4 | 64.6 | |
| 29.05.2018 | 14:42:00 | 30 | 0.3 | -0.3 | 14:52:00 | 30 | 65.9 | 64.5 | |
| 29.05.2018 | 14:43:00 | 30 | 0.4 | -0.3 | 14:53:00 | 30 | 65.8 | 64.6 | |
| average (X_{TS2}) | | | 0.4 | -0.3 | | | 65.7 | 64.6 | |
| 30.05.2018 | 08:18:00 | 20 | 0.5 | 0.1 | 08:28:00 | 20 | 66.3 | 65.2 | |
| 30.05.2018 | 08:19:00 | 20 | 0.6 | 0.1 | 08:29:00 | 20 | 65.4 | 65.3 | |
| 30.05.2018 | 08:20:00 | 20 | 0.5 | 0.1 | 08:30:00 | 20 | 65.7 | 64.9 | |
| average ($X_{2(TS2)}$) | | | 0.6 | 0.1 | | | 65.8 | 65.1 | |

7.1 8.4.10 Sensitivity coefficient to electrical voltage

The sensitivity coefficient to electrical voltage shall not exceed 0.3 µmol/mol/V.

7.2 Test procedures

The sensitivity coefficient of electrical voltage shall be determined at both ends of the voltage range specified by the manufacturer, V_1 and V_2 , at zero concentration and at a concentration around 70% to 80% of the maximum of the certification range of NO. After waiting the time equivalent to one independent measurement, three individual measurements at each voltage and concentration level shall be recorded.

The sensitivity coefficient to electrical voltage in accordance with EN 14626 is calculated as follows:

$$b_v = \frac{|(C_{V_2} - C_{V_1})|}{|(V_2 - V_1)|}$$

Where:

b_v is the voltage sensitivity coefficient,

C_{V_1} is the average concentration reading of the measurements at voltage V_1

C_{V_2} is the average concentration reading of the measurements at voltage V_2

V_1 is the minimum voltage V_{\min}

V_2 is the maximum voltage V_{\max}

For reporting the dependence on voltage, the higher value of the result at zero and span level shall be taken.

b_v shall comply with the performance criterion indicated above.

7.3 Testing

For the purpose of determining the sensitivity coefficient to electrical voltage, a transformer was looped into the measuring system's voltage supply. Test gases were applied to the zero and reference point at various voltages.

7.4 Evaluation

The following sensitivity coefficients to electrical voltage have been determined:

Table 19: Sensitivity coefficient to electrical voltage

| | requirement | device 1 | | device 2 | |
|---|-------------|----------|---|----------|---|
| sensitivity coeff. of voltage b_v at zero level [$\mu\text{mol}/\text{mol}/\text{V}$] | ≤ 0.3 | 0.00 | ✓ | 0.00 | ✓ |
| sensitivity coeff. of voltage b_v at span level [$\mu\text{mol}/\text{mol}/\text{V}$] | ≤ 0.3 | 0.00 | ✓ | 0.00 | ✓ |

7.5 Assessment

At no test item did the sensitivity coefficient to electrical voltage b_v exceed the value of $0.3 \mu\text{mol}/\text{mol}/\text{V}$ specified in standard EN 14626. For the purpose of uncertainty calculation, the largest b_v is used for both instruments. For instrument 1, this is $0.00 \mu\text{mol}/\text{mol}/\text{V}$ and for instrument 2, it is $0.00 \mu\text{mol}/\text{mol}/\text{V}$.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Table 20: Individual results of the sensitivity coefficient to electrical voltage

| time | voltage [V] | concentration | device 1 | device 2 |
|--------------------------|-------------|---------------|--------------------------------|--------------------------------|
| | | | [$\mu\text{mol}/\text{mol}$] | [$\mu\text{mol}/\text{mol}$] |
| 12:19:00 | 207 | 0 | 0.05 | 0.00 |
| 12:20:00 | 207 | 0 | 0.05 | 0.00 |
| 12:21:00 | 207 | 0 | 0.05 | 0.05 |
| average C_{V1} at zero | | | 0.05 | 0.02 |
| 12:29:00 | 253 | 0 | 0.11 | 0.05 |
| 12:30:00 | 253 | 0 | 0.11 | 0.05 |
| 12:31:00 | 253 | 0 | 0.11 | 0.05 |
| average C_{V2} at zero | | | 0.11 | 0.05 |
| 13:11:00 | 207 | 65.00 | 65.20 | 65.58 |
| 13:12:00 | 207 | 65.00 | 65.31 | 65.58 |
| 13:13:00 | 207 | 65.00 | 65.20 | 65.52 |
| average C_{V1} at Span | | | 65.23 | 65.56 |
| 13:21:00 | 253 | 65.00 | 65.25 | 65.52 |
| 13:22:00 | 253 | 65.00 | 65.15 | 65.52 |
| 13:23:00 | 253 | 65.00 | 65.20 | 65.47 |
| average C_{V2} at Span | | | 65.20 | 65.50 |

7.1 8.4.11 Interferents

Interferents at zero and at concentration c_t (at the level of the 8-hour limit value = $8.6 \mu\text{mol/mol}$ for CO). Deviations for interferents shall not exceed $0.5 \mu\text{mol/mol}$ for CO_2 , NO and N_2O and $1.0 \mu\text{mol/mol}$ for H_2O .

7.2 Test procedures

The analyser response to certain interferents shall be tested. The interferents can give a positive or negative response. The test was performed at a concentration of zero and at test gas concentration (c_t), which is similar to the 8h limit value ($8.6 \mu\text{mol/mol}$ for CO).

The concentration of the mixtures of the test gases with the interferent shall have an expanded uncertainty of $\leq 5\%$ and shall be traceable to nationally accepted standards. The interferents to be tested and their respective concentrations are given in Table 21. The influence of each interferent shall be determined separately. A correction on the concentration of the measurand shall be made for the dilution effect due to addition of an interferent (e.g. water vapour).

After adjustment of the analyser at zero and span level, the analyser shall be fed with a mixture of zero gas and the interferent to be investigated with the concentration as given in Table 21. With this mixture, one independent measurement of NO followed by two individual measurements of NO shall be carried out. This procedure shall be repeated with a mixture of the measurand at concentration c_t and the interferent to be investigated. The influence quantities at zero and concentration c_t are calculated from:

$$X_{\text{int},z} = x_z$$

$$X_{\text{int},ct} = x_{ct} - c_t$$

Where:

$X_{\text{int},z}$ is the influence quantity of the interferent at zero;

x_z is the average of the measurements of NO at zero;

$X_{\text{int},ct}$ is the influence quantity of the interferent at concentration c_t ;

x_{ct} is the average of the measurements of NO at concentration c_t

c_t is the applied concentration at the eight-hour limit value.

The influence quantities of the interferents shall comply with the performance criteria indicated above, both at zero and at concentration c_t .

7.3 Testing

The test was performed in line with the requirements of EN 14626 mentioned before. Systems were set to concentrations zero and c_t ($\sim 8.6 \mu\text{mol/mol}$). Zero and test gas with the various interfering components were then applied. The interferents listed in Table 21 were applied in the concentrations indicated.

Table 21: Interferents in accordance with EN 14626

| Interferent | Value |
|------------------|--------------|
| H ₂ O | 19 mmol/mol |
| CO ₂ | 500 µmol/mol |
| NO | 1 µmol/mol |
| N ₂ O | 50 nmol/mol |

7.4 Evaluation

The following overview presents the influence quantities of each interfering substance. When determining the influence of moisture, the dilution effect which occurs inside the test gas generation system was also taken into account.

 Table 22: Influence of the tested interferents ($c_t = 8.6 \mu\text{mol/mol}$)

| | requirements | device 1 | | device 2 | |
|---|----------------|----------|---|----------|---|
| influence quantity interferent H ₂ O at zero [nmol/mol/V] | ≤ 1.0 µmol/mol | 0.05 | ✓ | 0.14 | ✓ |
| influence quantity interferent H ₂ O at c_t [nmol/mol/V] | ≤ 1.0 µmol/mol | 0.02 | ✓ | 0.00 | ✓ |
| influence quantity interferent CO ₂ at zero [nmol/mol/V] | ≤ 0.5 µmol/mol | -0.03 | ✓ | -0.22 | ✓ |
| influence quantity interferent CO ₂ at c_t [nmol/mol/V] | ≤ 0.5 µmol/mol | -0.11 | ✓ | -0.08 | ✓ |
| influence quantity interferent NO at zero [nmol/mol/V] | ≤ 0.5 µmol/mol | -0.11 | ✓ | -0.05 | ✓ |
| influence quantity interferent NO at c_t [nmol/mol/V] | ≤ 0.5 µmol/mol | -0.10 | ✓ | -0.07 | ✓ |
| influence quantity interferent N ₂ O at zero [nmol/mol/V] | ≤ 0.5 µmol/mol | -0.04 | ✓ | -0.04 | ✓ |
| influence quantity interferent N ₂ O at c_t [nmol/mol/V] | ≤ 0.5 µmol/mol | -0.07 | ✓ | 0.00 | ✓ |

7.5 Assessment

Cross-sensitivity at zero point was 0.05 µmol/mol for system 1 and 0.14 µmol/mol for system 2 for H₂O, -0.03 µmol/mol for system 1 and -0.22 µmol/mol for system 2 for CO₂, -0.11 µmol/mol for system 1 and -0.05 µmol/mol for system 2 for NO, -0.04 µmol/mol for system 1 and -0.04 µmol/mol for system 2 for N₂O.

Cross-sensitivity at the limit value c_t was 0.02 µmol/mol for system 1 and 0.00 µmol/mol for system 2 for H₂O, -0.11 µmol/mol for system 1 and -0.08 µmol/mol for system 2 for CO₂, -0.10 µmol/mol for system 1 and -0.07 µmol/mol for system 2 for NO, -0.07 µmol/mol for system 1 and 0.00 µmol/mol for system 2 for N₂O.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Table 23 presents the individual test results.

Table 23: Individual results for testing interferences

| | without interferences | | | with interferences | | |
|--|-----------------------|----------|----------|--------------------|----------|----------|
| | time | device 1 | device 2 | time | device 1 | device 2 |
| zero gas + H ₂ O (19 mmol/mol) | 09:58:00 | 0.11 | -0.05 | 0.42 | 0.16 | 0.11 |
| | 09:59:00 | 0.11 | 0.00 | 0.42 | 0.16 | 0.16 |
| | 10:00:00 | 0.11 | 0.00 | 0.42 | 0.16 | 0.11 |
| | average x_z | 0.11 | -0.02 | average x_z | 0.16 | 0.13 |
| test gas c_t + H ₂ O (19 mmol/mol) | 10:10:00 | 8.55 | 8.55 | 0.43 | 8.55 | 8.55 |
| | 10:11:00 | 8.55 | 8.60 | 0.43 | 8.55 | 8.55 |
| | 10:12:00 | 8.55 | 8.55 | 0.43 | 8.60 | 8.60 |
| | average x_{ct} | 8.55 | 8.57 | average x_{ct} | 8.57 | 8.57 |
| zero gas + CO ₂ (500 µmol/mol) | 13:00:00 | 0.05 | 0.00 | 0.55 | 0.05 | -0.22 |
| | 13:01:00 | 0.05 | 0.05 | 0.55 | 0.05 | -0.16 |
| | 13:02:00 | 0.05 | 0.00 | 0.55 | -0.05 | -0.22 |
| | average x_z | 0.05 | 0.02 | average x_z | 0.02 | -0.20 |
| test gas c_t + CO ₂ (500 µmol/mol) | 13:16:00 | 8.60 | 8.39 | 0.56 | 8.49 | 8.28 |
| | 13:17:00 | 8.60 | 8.39 | 0.56 | 8.49 | 8.33 |
| | 13:18:00 | 8.60 | 8.39 | 0.56 | 8.49 | 8.33 |
| | average x_{ct} | 8.60 | 8.39 | average x_{ct} | 8.49 | 8.31 |
| zero gas + NO (1 µmol/mol) | 13:39:00 | 0.11 | -0.11 | 0.57 | 0.00 | -0.16 |
| | 13:40:00 | 0.11 | -0.11 | 0.57 | 0.00 | -0.16 |
| | 13:41:00 | 0.11 | -0.11 | 0.57 | 0.00 | -0.16 |
| | average x_z | 0.11 | -0.11 | average x_z | 0.00 | -0.16 |
| test gas c_t + NO (1 µmol/mol) | 13:54:00 | 8.65 | 8.44 | 0.58 | 8.55 | 8.39 |
| | 13:55:00 | 8.65 | 8.44 | 0.58 | 8.55 | 8.39 |
| | 13:56:00 | 8.65 | 8.44 | 0.58 | 8.55 | 8.33 |
| | average x_{ct} | 8.65 | 8.44 | average x_{ct} | 8.55 | 8.37 |
| zero gas + N ₂ O (50 nmol/mol) | 14:08:00 | 0.11 | -0.05 | 0.59 | 0.11 | -0.05 |
| | 14:09:00 | 0.11 | -0.05 | 0.59 | 0.05 | -0.11 |
| | 14:10:00 | 0.11 | -0.05 | 0.59 | 0.05 | -0.11 |
| | average x_z | 0.11 | -0.05 | average x_z | 0.07 | -0.09 |
| test gas c_t + N ₂ O (50 nmol/mol) | 14:22:00 | 8.71 | 8.39 | 0.60 | 8.60 | 8.39 |
| | 14:23:00 | 8.71 | 8.44 | 0.60 | 8.60 | 8.44 |
| | 14:24:00 | 8.65 | 8.44 | 0.60 | 8.65 | 8.44 |
| | average x_{ct} | 8.69 | 8.42 | average x_{ct} | 8.62 | 8.42 |

7.1 8.4.12 Averaging test

The averaging effect shall not exceed 7% of the measured value.

7.2 Test conditions

The averaging test gives a measure of the uncertainty in the averaged values caused by short-term concentration variations in the sampled air shorter than the time scale of the measurement process in the analyser. In general, the output of an analyser is a result of the determination of a reference concentration (normally zero) and the actual concentration which takes a certain time.

For the determination of the uncertainty due to averaging, the following concentrations are applied to the analyser and readings are taken at each concentration: a constant carbon monoxide concentration between 0 and concentration c_t (8.6 $\mu\text{mol/mol}$)

The time period (t_c) of the constant carbon monoxide concentration shall be at least equal to a period necessary to obtain four independent readings. four independent readings (which is equal to at least sixteen response times). The time period (t_v) of the varying carbon monoxide concentration shall be at least equal to a period to obtain four independent readings. The time period (t_{CO}) for the carbon monoxide concentration shall be 45 s followed by a period (t_{zero}) of 45 s of zero concentration. Further:

c_t is the test concentration;

t_v is a time period including a whole number of t_{CO} and t_{zero} pairs, and contains a minimum of three such pairs, in s.

The change from T_{CO} to t_{zero} shall be within 0.5 s. The change from t_c to t_v shall be within one response time of the analyser under test.

The averaging effect (E_{av}) is calculated according to:


$$E_{av} = \frac{C_{const}^{av} - 2C_{var}^{av}}{C_{const}^{av}} * 100$$

Where:

E_{av} is the averaging effect (%);

C_{const}^{av} is the average of the at least four independent measurements during the variable concentration period;

C_{var}^{av} is the average of the at least four independent measurements during the variable concentration period;



Key

Y concentration (µmol/mol)
X time

Figure 10: Test of the averaging effect ($t_{so} = t_{zero} = 45$ s.)

7.3 Testing

The averaging test was performed in compliance with the requirements specified in EN 14626. The test was performed by using a step change between zero and concentration c_t (8.6 µmol/mol). First, the average was calculated at a constant test gas concentration. Then, a three-way valve served to switch between zero and test gas every 45 s. During that period of alternating test gas application the average was calculated again.

7.4 Evaluation

The following averages were determined during the test:

Table 24: Results of the averaging test

| | requirement | device 1 | | device 2 | |
|-------------------------------|-------------|----------|---|----------|---|
| averaging effect E_{av} [%] | $\leq 7\%$ | -1.2 | ✓ | 2.0 | ✓ |

This results in the following averaging effects:

System 1: -1.2%

System 2: 2.0%

7.5 Assessment

At -1.2% for system 1 and 2.0% for system 2, the performance criterion defined in EN 14626 is fully complied with.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Table 25 presents the individual results of the averaging test:

Table 25: Individual results of the averaging test

| | | device 1 | device 2 |
|---|----------|-------------------------|-------------------------|
| | time | [$\mu\text{mol/mol}$] | [$\mu\text{mol/mol}$] |
| average constant concentration $C_{\text{av,c}}$ | 15:35:00 | 8.55 | 8.48 |
| | till | | |
| | 15:54:00 | | |
| average variable concentration $C_{\text{av,c}}$ | 15:55:00 | 4.32 | 4.15 |
| | till | | |
| | 16:14:00 | | |

| | | device 1 | device 2 |
|---|----------|-------------------------|-------------------------|
| | time | [$\mu\text{mol/mol}$] | [$\mu\text{mol/mol}$] |
| average constant concentration $C_{\text{av,c}}$ | 16:25:00 | 8.58 | 8.44 |
| | till | | |
| | 16:44:00 | | |
| average variable concentration $C_{\text{av,c}}$ | 16:45:00 | 4.21 | 4.02 |
| | till | | |
| | 17:04:00 | | |

| | | device 1 | device 2 |
|---|----------|-------------------------|-------------------------|
| | time | [$\mu\text{mol/mol}$] | [$\mu\text{mol/mol}$] |
| average constant concentration $C_{\text{av,c}}$ | 17:15:00 | 8.60 | 8.43 |
| | till | | |
| | 17:33:00 | | |
| average variable concentration $C_{\text{av,c}}$ | 17:34:00 | 4.49 | 4.25 |
| | till | | |
| | 17:53:00 | | |

7.1 8.4.13 Difference sample/calibration port

The difference between sample and calibration port shall not exceed 1.0%.

7.2 Test procedures

If the analyser has different ports for feeding sample gas and calibration gas, the difference in response of the analyser to feeding through the sample or calibration port shall be tested. The test shall be carried out by feeding the analyser with a test gas with a concentration of 70% to 80% of the maximum of the certification range of NO through the sample port. The test shall consist of one independent measurement followed by two individual measurements. After a period of at least four response times, the test shall be repeated using the calibration port. The difference shall be calculated according to:

$$\Delta x_{SC} = \frac{x_{sam} - x_{cal}}{c_t} \times 100$$

Where:

- Δx_{SC} is the difference sample/calibration port;
- x_{sam} is the average of the measured concentration using the sample port;
- x_{cal} is the average of the measured concentration using the calibration port;
- c_t is the concentration of the test gas;
- Δ_{SC} shall comply with the performance criterion indicated above.

7.3 Testing

The test was performed in compliance with the requirements specified in EN 14626. During the test, the gas path was switched between sample gas and span gas inlet using a three-way valve.

7.4 Evaluation

During the test, the following differences between sample and calibration port were determined:

Table 26: Results of determining the difference between sample/calibration inlet

| | requirement | device 1 | | device 2 | |
|--|-------------|----------|---|----------|---|
| difference sample/calibration port Δx_{cs} [%] | $\leq 1\%$ | -0.06 | ✓ | -0.08 | ✓ |

7.5 Assessment

At -0.06% for system 1 and -0.08% for system 2, the performance criterion defined in EN 14626 is fully complied with.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Table 27 presents the individual results.

Table 27: Individual results for testing the difference between sample and calibration port

| | | device 1 | device 2 |
|------------------|----------|-------------------------|-------------------------|
| | time | [$\mu\text{mol/mol}$] | [$\mu\text{mol/mol}$] |
| calibration port | 13:30:00 | 65.3 | 65.4 |
| | 13:31:00 | 65.1 | 65.4 |
| | 13:32:00 | 65.3 | 65.4 |
| sample port | 13:40:00 | 65.3 | 65.4 |
| | 13:41:00 | 65.2 | 65.4 |
| | 13:42:00 | 65.3 | 65.4 |

7.1 8.5.4 Long-term drift

The long-term drift at zero point shall not exceed $\leq 0.5 \mu\text{mol/mol}$.

Long-term drift at span level shall not exceed 5% of the certification range.

7.2 Test procedures

After each bi-weekly zero and span check, the drift of the analysers under test shall be calculated at zero and at span following the procedures as given below. If the drift compared to the initial calibration exceeds one of the performance criteria for drift at zero or span level, the "period of unattended operation" equals the number of weeks until the observation of the infringement, minus two weeks. For further (uncertainty) calculations, the values for "long term drift" are the values for zero and span drift over the period of unattended operation.

At the beginning of the drift period, five individual measurements were performed at zero and span level following the calibration (after waiting the time equivalent to a single independent reading).

The long-term drift is calculated as follows:

$$D_{L,Z} = (C_{Z,1} - C_{Z,0})$$

Where:

$D_{L,Z}$ is the drift at zero;

$C_{Z,0}$ is the average concentration of the measurements at zero at the beginning of the drift period;

$C_{Z,1}$ is the average concentration of the measurements at zero at the end of the drift period;

$D_{L,Z}$ shall comply with the performance criterion indicated above.

$$D_{L,S} = \frac{(C_{S,1} - C_{S,0}) - D_{L,Z}}{C_{S,1}} \times 100$$

Where:

$D_{L,S}$ is the drift at span concentration c_i ;

$C_{S,0}$ is the average concentration of the measurements at span level at the beginning of the drift period;

$C_{S,1}$ is the average concentration of the measurements at span level at the end of the drift period;

$D_{L,S}$ shall comply with the performance criterion indicated above.

7.3 Testing

For the purpose of this test, test gas was applied every other week. Table 28 and Table 29 report the measured values for bi-weekly test gas applications.

7.4 Evaluation

Table 28: Results for the long-term drift at zero point

| | | requierment | Device 1 | | Device 2 | |
|---|------------|-------------|----------|---|----------|---|
| average start $C_{z,1}$ at zero [$\mu\text{mol/mol}$] | 23.07.2018 | ≤ 0.5 | -- | ✓ | -- | ✓ |
| long term drift $D_{L,z}$ at zero [$\mu\text{mol/mol}$] | 06.08.2018 | ≤ 0.5 | 0.21 | ✓ | 0.06 | ✓ |
| long term drift $D_{L,z}$ at zero [$\mu\text{mol/mol}$] | 20.08.2018 | ≤ 0.5 | 0.02 | ✓ | 0.04 | ✓ |
| long term drift $D_{L,z}$ at zero [$\mu\text{mol/mol}$] | 03.09.2018 | ≤ 0.5 | 0.16 | ✓ | 0.04 | ✓ |
| long term drift $D_{L,z}$ at zero [$\mu\text{mol/mol}$] | 17.09.2018 | ≤ 0.5 | 0.09 | ✓ | 0.05 | ✓ |
| long term drift $D_{L,z}$ at zero [$\mu\text{mol/mol}$] | 01.10.2018 | ≤ 0.5 | 0.10 | ✓ | -0.05 | ✓ |
| long term drift $D_{L,z}$ at zero [$\mu\text{mol/mol}$] | 15.10.2018 | ≤ 0.5 | 0.31 | ✓ | 0.21 | ✓ |
| long term drift $D_{L,z}$ at zero [$\mu\text{mol/mol}$] | 29.10.2018 | ≤ 0.5 | 0.43 | ✓ | 0.33 | ✓ |

Table 29: Results for the long-term drift at reference point

| | | requierment | Device 2 1 | | Device 2 | |
|---|------------|---------------|------------|---|----------|---|
| average start $C_{s,1}$ at span [$\mu\text{mol/mol}$] | 23.07.2018 | $\leq 5.0 \%$ | -- | ✓ | -- | ✓ |
| long term drift $D_{L,s}$ at span [$\mu\text{mol/mol}$] | 06.08.2018 | $\leq 5.0 \%$ | 0.33 | ✓ | 0.05 | ✓ |
| long term drift $D_{L,s}$ at span [$\mu\text{mol/mol}$] | 20.08.2018 | $\leq 5.0 \%$ | -0.23 | ✓ | -0.13 | ✓ |
| long term drift $D_{L,s}$ at span [$\mu\text{mol/mol}$] | 03.09.2018 | $\leq 5.0 \%$ | -0.52 | ✓ | -0.19 | ✓ |
| long term drift $D_{L,s}$ at span [$\mu\text{mol/mol}$] | 17.09.2018 | $\leq 5.0 \%$ | -0.09 | ✓ | 0.14 | ✓ |
| long term drift $D_{L,s}$ at span [$\mu\text{mol/mol}$] | 01.10.2018 | $\leq 5.0 \%$ | 1.21 | ✓ | -0.06 | ✓ |
| long term drift $D_{L,s}$ at span [$\mu\text{mol/mol}$] | 15.10.2018 | $\leq 5.0 \%$ | 1.74 | ✓ | 0.75 | ✓ |
| long term drift $D_{L,s}$ at span [$\mu\text{mol/mol}$] | 29.10.2018 | $\leq 5.0 \%$ | 2.75 | ✓ | 0.72 | ✓ |

7.5 Assessment

Maximum long-term drift at zero point $D_{L,z}$ was at $0.43 \mu\text{mol/mol}$ for instrument 1 and $0.33 \mu\text{mol/mol}$ for instrument 2. Maximum long-term drift at reference point $D_{L,s}$ was at 2.75% for instrument 1 and 0.75% for instrument 2.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Table 30 presents the individual values obtained for the determination of the long-term drift.

Report on the performance test of the 48iQ ambient air quality measuring system for carbon monoxide manufactured by Thermo Fisher Scientific,
Report No.: 936/21242986/D

Table 30: Individual results for differences

| Zero Concentration | | | |
|---------------------------------|------------|-------------|-------------|
| Date | Time | Device 1 | Device 2 |
| | | [µmol/mol] | [µmol/mol] |
| 23.07.2018 | 12:10:00 | 0.05 | 0.11 |
| | 12:11:00 | 0.05 | 0.11 |
| | 12:12:00 | 0.05 | 0.11 |
| | Mittel | 0.05 | 0.11 |
| | 12:14:00 | 0.05 | 0.11 |
| | 12:15:00 | 0.05 | 0.11 |
| | 12:16:00 | 0.05 | 0.11 |
| | Mittel | 0.05 | 0.11 |
| | 12:18:00 | 0.05 | 0.05 |
| | 12:19:00 | 0.05 | 0.11 |
| | 12:20:00 | 0.05 | 0.11 |
| | Mittel | 0.05 | 0.09 |
| | 12:22:00 | 0.05 | 0.11 |
| | 12:23:00 | 0.11 | 0.11 |
| | 12:24:00 | 0.05 | 0.11 |
| | Mittel | 0.07 | 0.11 |
| | 12:26:00 | 0.05 | 0.11 |
| 12:27:00 | 0.05 | 0.11 | |
| 12:28:00 | 0.05 | 0.11 | |
| | | 0.05 | 0.11 |
| Average field start cz,0 | | 0.06 | 0.10 |
| 06.08.2018 | 09:40:00 | 0.27 | 0.16 |
| | 09:41:00 | 0.27 | 0.16 |
| | 09:42:00 | 0.27 | 0.16 |
| | 09:43:00 | 0.27 | 0.16 |
| | 09:44:00 | 0.27 | 0.16 |
| | aver. cz,1 | 0.27 | 0.16 |
| | | | |
| 20.08.2018 | 13:35:00 | 0.05 | 0.05 |
| | 13:36:00 | 0.05 | 0.11 |
| | 13:37:00 | 0.05 | 0.11 |
| | 13:38:00 | 0.05 | 0.16 |
| | 13:39:00 | 0.16 | 0.27 |
| | aver. cz,1 | 0.08 | 0.14 |
| | | | |
| 03.09.2018 | 10:37:00 | 0.22 | 0.27 |
| | 10:38:00 | 0.22 | 0.11 |
| | 10:39:00 | 0.22 | 0.11 |
| | 10:40:00 | 0.22 | 0.11 |
| | 10:41:00 | 0.22 | 0.11 |
| | aver. cz,1 | 0.22 | 0.14 |
| | | | |
| 17.09.2018 | 09:50:00 | 0.43 | 0.16 |
| | 09:51:00 | 0.16 | 0.11 |
| | 09:52:00 | 0.05 | 0.16 |
| | 09:53:00 | 0.05 | 0.16 |
| | 09:54:00 | 0.05 | 0.16 |
| | aver. cz,1 | 0.15 | 0.15 |
| | | | |
| 01.10.2018 | 12:40:00 | 0.16 | 0.05 |
| | 12:41:00 | 0.16 | 0.05 |
| | 12:42:00 | 0.16 | 0.05 |
| | 12:43:00 | 0.16 | 0.05 |
| | 12:44:00 | 0.16 | 0.05 |
| | aver. cz,1 | 0.16 | 0.05 |
| | | | |
| 15.10.2018 | 09:58:00 | 0.38 | 0.27 |
| | 09:59:00 | 0.38 | 0.32 |
| | 10:00:00 | 0.38 | 0.32 |
| | 10:01:00 | 0.38 | 0.27 |
| | 10:02:00 | 0.32 | 0.38 |
| | aver. cz,1 | 0.37 | 0.31 |
| | | | |
| 29.10.2018 | 12:06:00 | 0.48 | 0.32 |
| | 12:07:00 | 0.48 | 0.32 |
| | 12:08:00 | 0.48 | 0.32 |
| | 12:09:00 | 0.48 | 0.59 |
| | 12:10:00 | 0.48 | 0.59 |
| | aver. cz,1 | 0.48 | 0.43 |

| C _r -Concentration | | | |
|---------------------------------|-------------|--------------|--------------|
| Date | Time | Device 1 | Device 2 |
| | | [µmol/mol] | [µmol/mol] |
| 23.07.2018 | 12:38:00 | 65.31 | 65.31 |
| | 12:39:00 | 65.31 | 65.31 |
| | 12:40:00 | 65.36 | 65.41 |
| | Mittel | 65.32 | 65.34 |
| | 12:42:00 | 65.36 | 65.36 |
| | 12:43:00 | 65.31 | 65.41 |
| | 12:44:00 | 65.31 | 65.41 |
| | Mittel | 65.32 | 65.40 |
| | 12:46:00 | 65.41 | 65.47 |
| | 12:47:00 | 65.36 | 65.47 |
| | 12:48:00 | 65.36 | 65.41 |
| | Mittel | 65.38 | 65.45 |
| | 12:50:00 | 65.41 | 65.41 |
| | 12:51:00 | 65.36 | 65.41 |
| | 12:52:00 | 65.41 | 65.41 |
| | Mittel | 65.40 | 65.41 |
| | 12:54:00 | 65.36 | 65.36 |
| 12:55:00 | 65.36 | 65.41 | |
| 12:56:00 | 65.41 | 65.36 | |
| | | 65.38 | 65.38 |
| Average field start cs,0 | | 65.36 | 65.40 |
| 06.08.2018 | 09:53:00 | 65.74 | 65.36 |
| | 09:54:00 | 65.84 | 65.47 |
| | 09:55:00 | 65.79 | 65.58 |
| | 09:56:00 | 65.79 | 65.52 |
| | 09:57:00 | 65.79 | 65.52 |
| | Mittel cs,1 | 65.79 | 65.49 |
| | | | |
| 20.08.2018 | 13:48:00 | 65.25 | 65.36 |
| | 13:49:00 | 65.25 | 65.31 |
| | 13:50:00 | 65.20 | 65.36 |
| | 13:51:00 | 65.20 | 65.36 |
| | 13:52:00 | 65.25 | 65.36 |
| | aver. cs,1 | 65.23 | 65.35 |
| | | | |
| 03.09.2018 | 10:50:00 | 65.20 | 65.31 |
| | 10:51:00 | 65.15 | 65.31 |
| | 10:52:00 | 65.20 | 65.31 |
| | 10:53:00 | 65.20 | 65.20 |
| | 10:54:00 | 65.15 | 65.41 |
| | aver. cs,1 | 65.18 | 65.31 |
| | | | |
| 17.09.2018 | 10:03:00 | 65.36 | 65.52 |
| | 10:04:00 | 65.36 | 65.58 |
| | 10:05:00 | 65.47 | 65.58 |
| | 10:06:00 | 65.36 | 65.47 |
| | 10:07:00 | 65.41 | 65.52 |
| | aver. cs,1 | 65.39 | 65.53 |
| | | | |
| 01.10.2018 | 12:53:00 | 66.27 | 65.31 |
| | 12:54:00 | 66.27 | 65.31 |
| | 12:55:00 | 66.22 | 65.25 |
| | 12:56:00 | 66.27 | 65.31 |
| | 12:57:00 | 66.27 | 65.36 |
| | aver. cs,1 | 66.26 | 65.31 |
| | | | |
| 15.10.2018 | 10:11:00 | 66.87 | 66.01 |
| | 10:12:00 | 66.76 | 66.06 |
| | 10:13:00 | 66.87 | 66.06 |
| | 10:14:00 | 66.87 | 66.38 |
| | 10:15:00 | 66.81 | 66.01 |
| | aver. cs,1 | 66.83 | 66.10 |
| | | | |
| 29.10.2018 | 12:19:00 | 67.67 | 66.33 |
| | 12:20:00 | 67.62 | 66.27 |
| | 12:21:00 | 67.67 | 65.63 |
| | 12:22:00 | 67.62 | 66.44 |
| | 12:23:00 | 67.67 | 66.33 |
| | aver. cs,1 | 67.65 | 66.20 |

7.1 8.5.5 Reproducibility standard deviation for CO under field conditions

Reproducibility standard deviation under field conditions shall not exceed 5% of the mean value over a period of three months.

7.2 Test procedures

The reproducibility standard deviation under field conditions is calculated from the measured hourly averaged data during the three-month period.

The difference $\Delta x_{f,i}$ for each (ith) parallel measurement is calculated from:

$$\Delta x_{f,i} = x_{f,1,i} - x_{f,2,i}$$

Where:

$\Delta x_{f,i}$ is the ith difference in a parallel measurement;

$x_{f,1,i}$ is the ith measurement result of analyser 1;

$x_{f,2,i}$ is the ith measurement result of analyser 2;

The reproducibility standard deviation under field conditions is calculated according to:

$$s_{r,f} = \frac{\left(\sqrt{\frac{\sum_{i=1}^n \Delta x_{f,i}^2}{2 * n}} \right)}{c_f} \times 100$$

Where:

$s_{r,f}$ is the reproducibility standard deviation for NO₂ under field conditions (%);

n is the number of parallel measurements;

c_f is the average concentration of carbon monoxide measured during the field test;

The reproducibility standard deviation under field conditions, $s_{r,f}$, shall comply with the performance criterion indicated above.

7.3 Testing

The reproducibility standard deviation under field conditions was calculated from the 8-hourly averages over the field test period according to the equation stated above.

Since carbon monoxide concentrations in central Europe are typically close to zero, sample air was enriched to various concentrations over a period of two weeks. This confirmed that the measuring systems also operate in an identical way for higher concentrations. For enrichment, a small amount of highly concentrated test gas was dosed into the sampling system of the measuring station using a needle valve. Apart from the carbon monoxide concentration, the gas matrix was hardly changed with regard to humidity, pressure, temperature and the other measurable air constituents.

7.4 Evaluation

Table 31: Determination of the reproducibility standard deviation on the basis of complete field test data

| reproducibility standard deviation in field | | |
|---|-------------------------|-------------|
| no. of measurments (1h- average) | [n] | 295 |
| average of both analyzers (3 month) | [$\mu\text{mol/mol}$] | 9.00 |
| standard deviation from paired measurements | [$\mu\text{mol/mol}$] | 0.137 |
| reproducibility standard deviation in field $S_{r,f}$ | [%] | 1.52 |
| requirement | $\leq 5.0 \%$ | ✓ |

The reproducibility standard deviation under field conditions is at 1.52% of the average.

7.5 Assessment

The reproducibility standard deviation for carbon monoxide under field conditions was 1.52% as a percentage of the mean value over the three-months field test period. Thus, the requirements of EN 14626 are satisfied.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Figure 11 provides an illustration of the reproducibility standard deviation under field conditions.




Figure 11: Diagram illustrating the reproducibility standard deviation under field conditions

7.1 8.5.6 Inspection interval

The period of unattended operation of the AMS shall be at least 2 weeks.

7.2 Equipment

Not required for this performance criterion

7.3 Testing

With regard to this minimum requirement, the maintenance tasks required in a specific period and the length of that period for the correct functioning of the measuring system were identified. Furthermore, in determining the maintenance interval, the drift determined for zero and reference point in accordance with 7.1 8.5.4 Long-term drift have been taken into consideration.

7.4 Evaluation

Over the entire period of the field test, no unacceptable drift was observed. The maintenance interval is thus determined by the necessary maintenance works.

During the three months field test period, maintenance is generally limited to contamination and plausibility checks and potential status/error messages. Naturally, the frequency of filter replacement will depend on the ambient dust concentration at the site of installation. Chapter 5 of the manual and Chapter 8 of this report provide information about tasks to be performed in the maintenance interval.

7.5 Assessment

The necessary maintenance tasks determine the period of unattended operation. In essence, these include contamination checks, plausibility checks and checks of potential status/error warnings. The external particle filter needs replacing at the measurement site after having been subjected to dust loading. EN 14626 requires checking of zero and span points at least once every two weeks.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Not applicable in this instance.

7.1 8.5.7 Period of availability of the analyser

Availability of the analyser shall be at least 90%.

7.2 Test procedures

The correct operation of the analysers shall be checked at least every fourteen days. It is recommended to perform this check every day during the first fourteen days. These checks consist of plausibility checks on the measured values, as well as, when available, on status signals and other relevant parameters. Time, duration and nature of any malfunctioning shall be logged.

The total time period with useable measuring data is the period during the field test during which valid measuring data of the ambient air concentrations are obtained. In this time period, the time needed for calibrations, conditioning of sample systems and filters and maintenance shall not be included.

The availability of the analyser is calculated as:

$$A_a = \frac{t_u}{t_t} * 100$$

Where:

A_a is the availability of the analyser (%);

t_u is the total time period with validated measuring data;

t_t is the time period of the field test minus the time for calibration, conditioning and maintenance, t_u and t_t shall be expressed in the same units.

The availability shall comply with the performance criterion indicated above.

7.3 Testing

Using the equation given above, the availability was calculated from the total period of the field test and the outage times which have occurred during this period.

Evaluation

Outage times which have occurred during the field test are listed in Table 32.

Table 32: Availability of the 48iQ measuring system

| | | System 1 | System 2 |
|--|---|----------|----------|
| Operation time | h | 2360 | 2360 |
| Outage time | h | 0 | 0 |
| Maintenance time | h | 8 | 8 |
| Actual operating time: | h | 2352 | 2352 |
| Actual operating time incl. maintenance times: | h | 2360 | 2360 |
| Availability | % | 100 | 100 |

Maintenance times were caused by daily test gas feeding for the purpose of determining the drift behaviour and the maintenance interval and by times needed for replacing the Teflon filter built into the sample gas path.

7.5 Assessment

The availability is 100%. Thus, the requirement of EN 14626 is satisfied.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Not applicable.

7.1 8.6 Calculation of the total uncertainty according to EN 14626 (2012)

The type approval of the analyser consists of the following steps:

- 1) The value of each individual performance characteristic tested in the laboratory shall fulfil the criterion stated in Table E.1 of standard EN 14626.*
- 2) The expanded uncertainty calculated from the standard uncertainties due to the values of the specific performance characteristics obtained in the laboratory tests shall fulfil the criterion as stated in Annex I of Directive 2008/50/EC (15% for fixed measurements or 25% for indicative measurements). This criterion is the maximum uncertainty of individual measurements for continuous measurements at the 8-hour limit value. The relevant specific performance characteristics and the calculation procedure are given in Annex E of standard EN 14626.*
- 3) The value of each of the individual performance characteristics tested in the field shall fulfil the criterion stated in Table E.1 of EN 14626.*
- 4) The expanded uncertainty calculated from the standard uncertainties due to the values of the specific performance characteristics obtained in the laboratory and field tests shall fulfil the criterion as stated in Annex I of Directive 2008/50/EC (15% for fixed measurements or 25% for indicative measurements). This criterion is the maximum uncertainty of individual measurements for continuous measurements at the 8-hour limit value. The relevant specific performance characteristics and the calculation procedure are given in Annex E of standard EN 14626.*

7.2 Equipment

Calculation of the total uncertainty in accordance with standard EN 14626 (2012), Annex E

7.3 Testing

At the end of the performance test, the total uncertainties were calculated from the values obtained during the test.

7.4 Evaluation

- Regarding 1) The value of each performance characteristic tested in the laboratory tests fulfils the criterion stated in Table E.1 of EN 14626.
- Regarding 2) The expanded uncertainty calculated from the standard uncertainties due to the values of the specific performance characteristics obtained in the laboratory tests fulfils the criterion as stated.
- Regarding 3) The value of each performance characteristic tested in the field tests fulfils the criterion stated in Table E.1 of EN 14626.
- Regarding 4) The expanded uncertainty calculated from the standard uncertainties due to the values of the specific performance characteristics obtained in the laboratory and field tests fulfils the criterion as stated.

7.5 Assessment

The requirement regarding the expanded uncertainty of the measuring system is complied with.

Criterion satisfied? yes

7.6 Detailed presentation of test results

Table 33 summarises the results for items 1 and 3.

Results regarding item 2 are listed in Table 36.

Table 35 and Table 37 contain the results regarding item 4.

Table 33: Relevant performance characteristics and criteria according to EN 14626

| Performance characteristic | Performance criterion | Test result | Satisfied | Page |
|--|--|---|-----------|------|
| 8.4.5 Repeatability standard deviation at zero | $\leq 0.3 \mu\text{mol/mol}$ | S _r system 1: 0.02 $\mu\text{mol/mol}$ S _r system 2: 0.02 $\mu\text{mol/mol}$ | yes | 78 |
| 8.4.5 Repeatability standard deviation at concentration level c _t | $\leq 0.4 \mu\text{mol/mol}$ | S _r system 1: 0.01 $\mu\text{mol/mol}$ S _r system 2: 0.03 $\mu\text{mol/mol}$ | yes | 78 |
| 8.4.6 "Lack of fit" (deviation from the linear regression) | Largest deviation from the linear regression function $> 0, \leq 4.0\%$ of the reading Residual at zero: $\leq 0.5 \mu\text{mol/mol}$ | X _{l,z} system 1: ZP 0.13 $\mu\text{mol/mol}$ X _l system 1: RP 1.33% X _{l,z} system 2: ZP -0.01 $\mu\text{mol/mol}$ X _l system 2: RP 1.24% | yes | 81 |
| 8.4.7 Sensitivity coefficient of sample gas pressure | $\leq 0.70 \mu\text{mol/mol/kPa}$ | b _{gp} system 1: $\leq 0.02 \mu\text{mol/mol/kPa}$ b _{gp} system 2: $\leq 0.02 \mu\text{mol/mol/kPa}$ | yes | 86 |
| 8.4.8 Sensitivity coefficient of sample gas temperature | $\leq 0.3 \mu\text{mol/mol/K}$ | b _{gt} system 1: 0.06 $\mu\text{mol/mol/K}$ b _{gt} system 2: 0.10 $\mu\text{mol/mol/K}$ | yes | 88 |
| 8.4.9 Sensitivity coefficient of surrounding temperature | $\leq 0.3 \mu\text{mol/mol/K}$ | b _{st} system 1: 0.021 $\mu\text{mol/mol/K}$ b _{st} system 2: 0.081 $\mu\text{mol/mol/K}$ | yes | 90 |
| 8.4.10 Sensitivity coefficient of electrical voltage | $\leq 0.3 \mu\text{mol/mol/V}$ | b _v system 1: 0.00 $\mu\text{mol/mol/V}$ b _v system 2: 0.00 $\mu\text{mol/mol/V}$ | yes | 93 |
| 8.4.11 Interferent at zero and at concentration level c _t | H ₂ O $\leq 1.0 \mu\text{mol/mol}$ CO ₂ $\leq 0.5 \mu\text{mol/mol}$ NO $\leq 0.5 \mu\text{mol/mol}$ NO ₂ $\leq 0.5 \mu\text{mol/mol}$ | H ₂ O system 1 ZP 0.05 $\mu\text{mol/mol}$ / RP 0.02 $\mu\text{mol/mol}$ system 2 ZP 0.14 $\mu\text{mol/mol}$ / RP 0.00 $\mu\text{mol/mol}$ CO ₂ system 1 ZP -0.03 $\mu\text{mol/mol}$ / RP -0.11 $\mu\text{mol/mol}$ system 2 ZP -0.22 $\mu\text{mol/mol}$ / RP -0.08 $\mu\text{mol/mol}$ NO system 1 ZP -0.11 $\mu\text{mol/mol}$ / RP -0.10 $\mu\text{mol/mol}$ system 2 ZP -0.05 $\mu\text{mol/mol}$ / RP -0.07 $\mu\text{mol/mol}$ NO ₂ system 1 ZP -0.04 $\mu\text{mol/mol}$ / RP -0.07 $\mu\text{mol/mol}$ system 2 ZP -0.04 $\mu\text{mol/mol}$ / RP 0.00 $\mu\text{mol/mol}$ | yes | 95 |

| Performance characteristic | Performance criterion | Test result | Satisfied | Page |
|---|---|--|-----------|------|
| 8.4.12 Averaging effect | $\leq 7.0\%$ of the measured value | E_{av} system 1: -1.2% E_{av} system 2: 2.0% | yes | 98 |
| 8.4.13 Difference sample/calibration port | $\leq 1.0\%$ | Δ_{SC} system 1: -0.06% Δ_{SC} system 2: -0.08% | yes | 101 |
| 8.4.3 Response time (rise) | ≤ 180 s | t_r system 1: 48.5 s t_r system 2: 48.5 s | yes | 70 |
| 8.4.3 Response time (fall) | ≤ 180 s | t_f system 1: 47.5 s t_f system 2: 47.5 s | yes | 70 |
| 8.4.3 Difference between the rise and fall response time | $\leq 10\%$ relative difference or 10s, whichever value is larger | t_d system 1: 1 s t_d system 2: 1 s | yes | 70 |
| 8.5.7 Availability of the analyser | $> 90\%$ | A_a system 1: 100% A_a system 2: 100% | yes | 110 |
| 8.5.5 Reproducibility standard deviation under field conditions | $\leq 5.0\%$ of the average over a period of three months | $S_{r,f}$ system 1: 1.52% $S_{r,f}$ system 2: 1.52% | yes | 106 |
| 8.5.4 Long-term drift at zero point | ≤ 0.50 $\mu\text{mol/mol}$ | $D_{l,z}$ system 1: 0.43 $\mu\text{mol/mol}$ $D_{l,z}$ system 2: 0.33 $\mu\text{mol/mol}$ | yes | 103 |
| 8.5.4 Long-term drift at span level | $\leq 5.0\%$ of the upper limit of the certification range | $D_{l,s}$ system 1: 2.75% $D_{l,s}$ system 2: 0.75% | yes | 103 |
| 8.4.4 Short-term drift at zero | ≤ 0.10 $\mu\text{mol/mol}$ over 12 h | $D_{s,z}$ system 1: 0.04 $\mu\text{mol/mol}$ $D_{s,z}$ system 2: 0.01 $\mu\text{mol/mol}$ | yes | 74 |
| 8.4.4 Short-term drift at span level | ≤ 0.60 $\mu\text{mol/mol}$ over 12 h | $D_{s,s}$ system 1: 0.20 $\mu\text{mol/mol}$ $D_{s,s}$ system 2: 0.12 $\mu\text{mol/mol}$ | yes | 74 |

Report on the performance test of the 48iQ ambient air quality measuring system for carbon monoxide manufactured by Thermo Fisher Scientific,
Report No.: 936/21242986/D

Table 34: Expanded uncertainty from the results obtained in the laboratory tests for analyser 1

| Measuring device: | | 48iQ | | Serial-No.: | | 1180540007 | |
|--------------------------------------|--|-------------------------------------|--------|---------------------|-------|-------------------------------|---------------------|
| Measured component: | | CO | | 8h-limit value: | | 8.62 $\mu\text{mol/mol}$ | |
| No. | Performance characteristic | Performance criterion | Result | Partial uncertainty | | Square of partial uncertainty | |
| 1 | Repeatability standard deviation at zero | $\leq 0.3 \mu\text{mol/mol}$ | 0.020 | $u_{r,z}$ | 0.00 | 0.0000 | |
| 2 | Repeatability standard deviation at 8h-limit value | $\leq 0.4 \mu\text{mol/mol}$ | 0.010 | u_r | 0.00 | 0.0000 | |
| 3 | "lack of fit" at 8h-limit value | $\leq 4.0\%$ of measured value | 1.330 | u_f | 0.07 | 0.0044 | |
| 4 | Sensitivity coefficient of sample gas pressure at 8h-limit value | $\leq 0.7 \mu\text{mol/mol/kPa}$ | 0.020 | u_{gp} | 0.05 | 0.0021 | |
| 5 | Sensitivity coefficient of sample gas temperature at 8h-limit value | $\leq 0.3 \mu\text{mol/mol/K}$ | 0.060 | u_{gt} | 0.13 | 0.0175 | |
| 6 | Sensitivity coefficient of surrounding temperature at 8h-limit value | $\leq 0.3 \mu\text{mol/mol/K}$ | 0.021 | u_{st} | 0.05 | 0.0023 | |
| 7 | Sensitivity coefficient of electrical voltage at 8h-limit value | $\leq 0.3 \mu\text{mol/mol/V}$ | 0.000 | u_v | 0.00 | 0.0000 | |
| 8a | Interferent H ₂ O with 19 mmol/mol | $\leq 1.0 \mu\text{mol/mol}$ (Zero) | 0.050 | u_{H_2O} | 0.01 | 0.0002 | |
| | | $\leq 1.0 \mu\text{mol/mol}$ (Span) | 0.020 | | | | |
| 8b | Interferent CO ₂ with 500 $\mu\text{mol/mol}$ | $\leq 0.5 \mu\text{mol/mol}$ (Zero) | -0.030 | $u_{int,pos}$ | 0.16 | 0.0262 | |
| | | $\leq 0.5 \mu\text{mol/mol}$ (Span) | -0.110 | | | | |
| 8c | Interferent NO with 1 $\mu\text{mol/mol}$ | $\leq 0.5 \mu\text{mol/mol}$ (Zero) | -0.110 | or | 0.16 | 0.0262 | |
| | | $\leq 0.5 \mu\text{mol/mol}$ (Span) | -0.100 | | | | |
| 8d | Interferent N ₂ O with 50 nmol/mol | $\leq 0.5 \mu\text{mol/mol}$ (Zero) | -0.040 | $u_{int,neg}$ | 0.16 | 0.0262 | |
| | | $\leq 0.5 \mu\text{mol/mol}$ (Span) | -0.070 | | | | |
| 9 | Averaging effect | $\leq 7.0\%$ of measured value | -1.200 | u_{av} | -0.06 | 0.0036 | |
| 18 | Difference sample/calibration port | $\leq 1.0\%$ | -0.060 | u_{sc} | -0.01 | 0.0000 | |
| 21 | Uncertainty of test gas | $\leq 3.0\%$ | 2.000 | u_{tg} | 0.09 | 0.0074 | |
| Combined standard uncertainty | | | | u_c | | 0.2526 | $\mu\text{mol/mol}$ |
| Expanded uncertainty | | | | U | | 0.5052 | $\mu\text{mol/mol}$ |
| Relative expanded uncertainty | | | | W | | 5.86 | % |
| Maximum allowed expanded uncertainty | | | | W_{req} | | 15 | % |

Table 35: Expanded uncertainty from the results obtained in the laboratory and field tests for analyser 1

| Measuring device: | | 48iQ | | Serial-No.: | | 1180540007 | |
|--------------------------------------|--|---|--------|---------------------|--|-------------------------------|---------------------|
| Measured component: | | CO | | 8h-limit value: | | 8.62 $\mu\text{mol/mol}$ | |
| No. | Performance characteristic | Performance criterion | Result | Partial uncertainty | | Square of partial uncertainty | |
| 1 | Repeatability standard deviation at zero | $\leq 0.3 \mu\text{mol/mol}$ | 0.020 | $u_{r,z}$ | 0.00 | 0.0000 | |
| 2 | Repeatability standard deviation at 8h-limit value | $\leq 0.4 \mu\text{mol/mol}$ | 0.010 | u_r | not considered, as $u_r = 0 < u_{r,f}$ | - | |
| 3 | "lack of fit" at 8h-limit value | $\leq 4.0\%$ of measured value | 1.330 | u_f | 0.07 | 0.0044 | |
| 4 | Sensitivity coefficient of sample gas pressure at 8h-limit value | $\leq 0.7 \mu\text{mol/mol/kPa}$ | 0.020 | u_{gp} | 0.05 | 0.0021 | |
| 5 | Sensitivity coefficient of sample gas temperature at 8h-limit value | $\leq 0.3 \mu\text{mol/mol/K}$ | 0.060 | u_{gt} | 0.13 | 0.0175 | |
| 6 | Sensitivity coefficient of surrounding temperature at 8h-limit value | $\leq 0.3 \mu\text{mol/mol/K}$ | 0.021 | u_{st} | 0.05 | 0.0023 | |
| 7 | Sensitivity coefficient of electrical voltage at 8h-limit value | $\leq 0.3 \mu\text{mol/mol/V}$ | 0.000 | u_v | 0.00 | 0.0000 | |
| 8a | Interferent H ₂ O with 19 mmol/mol | $\leq 1.0 \mu\text{mol/mol}$ (Zero) | 0.050 | u_{H_2O} | 0.01 | 0.0002 | |
| | | $\leq 1.0 \mu\text{mol/mol}$ (Span) | 0.020 | | | | |
| 8b | Interferent CO ₂ with 500 $\mu\text{mol/mol}$ | $\leq 0.5 \mu\text{mol/mol}$ (Zero) | -0.030 | $u_{int,pos}$ | 0.16 | 0.0262 | |
| | | $\leq 0.5 \mu\text{mol/mol}$ (Span) | -0.110 | | | | |
| 8c | Interferent NO with 1 $\mu\text{mol/mol}$ | $\leq 0.5 \mu\text{mol/mol}$ (Zero) | -0.110 | or | 0.16 | 0.0262 | |
| | | $\leq 0.5 \mu\text{mol/mol}$ (Span) | -0.100 | | | | |
| 8d | Interferent N ₂ O with 50 nmol/mol | $\leq 0.5 \mu\text{mol/mol}$ (Zero) | -0.040 | $u_{int,neg}$ | 0.16 | 0.0262 | |
| | | $\leq 0.5 \mu\text{mol/mol}$ (Span) | -0.070 | | | | |
| 9 | Averaging effect | $\leq 7.0\%$ of measured value | -1.200 | u_{av} | -0.06 | 0.0036 | |
| 10 | Reproducibility standard deviation under field conditions | $\leq 5.0\%$ of average over 3 months | 1.520 | $u_{r,f}$ | 0.13 | 0.0172 | |
| 11 | Long term drift at zero level | $\leq 0.5 \mu\text{mol/mol}$ | 0.430 | $u_{d,l,z}$ | 0.25 | 0.0616 | |
| 12 | Long term drift at span level | $\leq 5.0\%$ of max. of certification range | 2.750 | $u_{d,l,sp}$ | 0.14 | 0.0187 | |
| 18 | Difference sample/calibration port | $\leq 1.0\%$ | -0.060 | u_{sc} | -0.01 | 0.0000 | |
| 21 | Uncertainty of test gas | $\leq 3.0\%$ | 2.000 | u_{tg} | 0.09 | 0.0074 | |
| Combined standard uncertainty | | | | u_c | | 0.4017 | $\mu\text{mol/mol}$ |
| Expanded uncertainty | | | | U | | 0.8033 | $\mu\text{mol/mol}$ |
| Relative expanded uncertainty | | | | W | | 9.32 | % |
| Maximum allowed expanded uncertainty | | | | W_{req} | | 15 | % |

Table 36 Expanded uncertainty from the results obtained in the laboratory tests for analyser 2

| Measuring device: | | 48iQ | | Serial-No.: | | 1171780048 | |
|--------------------------------------|--|-------------------------------------|--------|---------------------|--------|-------------------------------|--|
| Measured component: | | CO | | 8h-limit value: | | 8.62 $\mu\text{mol/mol}$ | |
| No. | Performance characteristic | Performance criterion | Result | Partial uncertainty | | Square of partial uncertainty | |
| 1 | Repeatability standard deviation at zero | $\leq 0.3 \mu\text{mol/mol}$ | 0.020 | $u_{r,z}$ | 0.00 | 0.0000 | |
| 2 | Repeatability standard deviation at 8h-limit value | $\leq 0.4 \mu\text{mol/mol}$ | 0.030 | u_r | 0.01 | 0.0000 | |
| 3 | "lack of fit" at 8h-limit value | $\leq 4.0\%$ of measured value | 1.240 | u_i | 0.06 | 0.0038 | |
| 4 | Sensitivity coefficient of sample gas pressure at 8h-limit value | $\leq 0.7 \mu\text{mol/mol/kPa}$ | 0.020 | u_{sp} | 0.05 | 0.0021 | |
| 5 | Sensitivity coefficient of sample gas temperature at 8h-limit value | $\leq 0.3 \mu\text{mol/mol/K}$ | 0.100 | u_{gt} | 0.22 | 0.0495 | |
| 6 | Sensitivity coefficient of surrounding temperature at 8h-limit value | $\leq 0.3 \mu\text{mol/mol/K}$ | 0.081 | u_{st} | 0.19 | 0.0352 | |
| 7 | Sensitivity coefficient of electrical voltage at 8h-limit value | $\leq 0.3 \mu\text{mol/mol/V}$ | 0.000 | u_v | 0.00 | 0.0000 | |
| 8a | Interferent H ₂ O with 19 nmol/mol | $\leq 1.0 \mu\text{mol/mol (Zero)}$ | 0.140 | u_{H_2O} | 0.00 | 0.0000 | |
| | | $\leq 1.0 \mu\text{mol/mol (Span)}$ | 0.000 | | | | |
| 8b | Interferent CO ₂ with 500 $\mu\text{mol/mol}$ | $\leq 0.5 \mu\text{mol/mol (Zero)}$ | -0.220 | $u_{int,pos}$ | 0.09 | 0.0075 | |
| | | $\leq 0.5 \mu\text{mol/mol (Span)}$ | -0.080 | | | | |
| 8c | Interferent NO with 1 $\mu\text{mol/mol}$ | $\leq 0.5 \mu\text{mol/mol (Zero)}$ | -0.050 | or | 0.09 | 0.0075 | |
| | | $\leq 0.5 \mu\text{mol/mol (Span)}$ | -0.070 | | | | |
| 8d | Interferent N ₂ O with 50 nmol/mol | $\leq 0.5 \mu\text{mol/mol (Zero)}$ | -0.040 | $u_{int,neg}$ | 0.10 | 0.0099 | |
| | | $\leq 0.5 \mu\text{mol/mol (Span)}$ | 0.000 | | | | |
| 9 | Averaging effect | $\leq 7.0\%$ of measured value | 2.000 | u_{av} | 0.10 | 0.0099 | |
| 18 | Difference sample/calibration port | $\leq 1.0\%$ | -0.080 | u_{ssc} | -0.01 | 0.0000 | |
| 21 | Uncertainty of test gas | $\leq 3.0\%$ | 2.000 | u_{tg} | 0.09 | 0.0074 | |
| Combined standard uncertainty | | | | u_c | 0.3399 | $\mu\text{mol/mol}$ | |
| Expanded uncertainty | | | | U | 0.6798 | $\mu\text{mol/mol}$ | |
| Relative expanded uncertainty | | | | W | 7.89 | % | |
| Maximum allowed expanded uncertainty | | | | W_{req} | 15 | % | |

Table 37 Expanded uncertainty from the results obtained in the laboratory and field tests for analyser 2

| Measuring device: | | 48iQ | | Serial-No.: | | 1171780048 | |
|--------------------------------------|--|---|--------|---------------------|--|-------------------------------|--|
| Measured component: | | CO | | 8h-limit value: | | 8.62 $\mu\text{mol/mol}$ | |
| No. | Performance characteristic | Performance criterion | Result | Partial uncertainty | | Square of partial uncertainty | |
| 1 | Repeatability standard deviation at zero | $\leq 0.3 \mu\text{mol/mol}$ | 0.020 | $u_{r,z}$ | 0.00 | 0.0000 | |
| 2 | Repeatability standard deviation at 8h-limit value | $\leq 0.4 \mu\text{mol/mol}$ | 0.030 | u_r | not considered, as $u_r = 0 < u_{r,f}$ | - | |
| 3 | "lack of fit" at 8h-limit value | $\leq 4.0\%$ of measured value | 1.240 | u_i | 0.06 | 0.0038 | |
| 4 | Sensitivity coefficient of sample gas pressure at 8h-limit value | $\leq 0.7 \mu\text{mol/mol/kPa}$ | 0.020 | u_{sp} | 0.05 | 0.0021 | |
| 5 | Sensitivity coefficient of sample gas temperature at 8h-limit value | $\leq 0.3 \mu\text{mol/mol/K}$ | 0.100 | u_{gt} | 0.22 | 0.0495 | |
| 6 | Sensitivity coefficient of surrounding temperature at 8h-limit value | $\leq 0.3 \mu\text{mol/mol/K}$ | 0.081 | u_{st} | 0.19 | 0.0352 | |
| 7 | Sensitivity coefficient of electrical voltage at 8h-limit value | $\leq 0.3 \mu\text{mol/mol/V}$ | 0.000 | u_v | 0.00 | 0.0000 | |
| 8a | Interferent H ₂ O with 19 nmol/mol | $\leq 1.0 \mu\text{mol/mol (Zero)}$ | 0.140 | u_{H_2O} | 0.00 | 0.0000 | |
| | | $\leq 1.0 \mu\text{mol/mol (Span)}$ | 0.000 | | | | |
| 8b | Interferent CO ₂ with 500 $\mu\text{mol/mol}$ | $\leq 0.5 \mu\text{mol/mol (Zero)}$ | -0.220 | $u_{int,pos}$ | 0.09 | 0.0075 | |
| | | $\leq 0.5 \mu\text{mol/mol (Span)}$ | -0.080 | | | | |
| 8c | Interferent NO with 1 $\mu\text{mol/mol}$ | $\leq 0.5 \mu\text{mol/mol (Zero)}$ | -0.050 | or | 0.09 | 0.0075 | |
| | | $\leq 0.5 \mu\text{mol/mol (Span)}$ | -0.070 | | | | |
| 8d | Interferent N ₂ O with 50 nmol/mol | $\leq 0.5 \mu\text{mol/mol (Zero)}$ | -0.040 | $u_{int,neg}$ | 0.10 | 0.0099 | |
| | | $\leq 0.5 \mu\text{mol/mol (Span)}$ | 0.000 | | | | |
| 9 | Averaging effect | $\leq 7.0\%$ of measured value | 2.000 | u_{av} | 0.10 | 0.0099 | |
| 10 | Reproducibility standard deviation under field conditions | $\leq 5.0\%$ of average over 3 months | 1.520 | $u_{r,f}$ | 0.13 | 0.0172 | |
| 11 | Long term drift at zero level | $\leq 0.5 \mu\text{mol/mol}$ | 0.330 | $u_{d,LZ}$ | 0.19 | 0.0363 | |
| 12 | Long term drift at span level | $\leq 5.0\%$ of max. of certification range | 0.750 | $u_{d,LB}$ | 0.04 | 0.0014 | |
| 18 | Difference sample/calibration port | $\leq 1.0\%$ | -0.080 | u_{ssc} | -0.01 | 0.0000 | |
| 21 | Uncertainty of test gas | $\leq 3.0\%$ | 2.000 | u_{tg} | 0.09 | 0.0074 | |
| Combined standard uncertainty | | | | u_c | 0.4127 | $\mu\text{mol/mol}$ | |
| Expanded uncertainty | | | | U | 0.8254 | $\mu\text{mol/mol}$ | |
| Relative expanded uncertainty | | | | W | 9.58 | % | |
| Maximum allowed expanded uncertainty | | | | W_{req} | 15 | % | |

8. Recommendations for use in practice

Work in the maintenance interval

The tested measuring systems require regular performance of the following tasks:


- Regular visual inspections/telemetric inspections
- Instrument status ok
- No error messages
- Replace the external Teflon filter at the sample gas inlet as required by measurement site conditions;
- Perform zero and reference checks using suitable test gas every two weeks in accordance with standard EN 14626;

Other than that, follow the manufacturer's instructions indicated in the user manual.

Environmental Protection/Air Pollution Control



Dipl.-Ing. Martin Schneider



Dipl.-Ing. Guido Baum

Cologne, 4 February 2019
936/21242986/D

9. Bibliography

- [1] VDI 4202 part 1: Performance test, declaration of suitability, and certification of point-related measuring systems for gaseous air pollutants of April 2018
- [2] European standard EN 14626: Ambient air – Standard method for the measurement of the concentration of carbon monoxide by non-dispersive infrared spectroscopy of August 2012
- [3] Directive 2008/50/EG of the European Parliament and of the Council of 21 May 2008 on ambient air quality and cleaner air for Europe.

10. Appendices

Appendix 1 Certificate of Accreditation to EN ISO/IEC 17025:2005

Annex 2 Manual



Deutsche Akkreditierungsstelle GmbH

Beliehene gemäß § 8 Absatz 1 AkkStelleG i.V.m. § 1 Absatz 1 AkkStelleGBV
Unterzeichnerin der Multilateralen Abkommen
von EA, ILAC und IAF zur gegenseitigen Anerkennung

Akkreditierung



Die Deutsche Akkreditierungsstelle GmbH bestätigt hiermit, dass das Prüflaboratorium

TÜV Rheinland Energy GmbH

mit seinen in der Urkundenanlage aufgeführten Messstellen

die Kompetenz nach DIN EN ISO/IEC 17025:2005 besitzt, Prüfungen in folgenden Bereichen durchzuführen:

Bestimmung (Probenahme und Analytik) von anorganischen und organischen gas- oder partikel-förmigen Luftinhaltsstoffen im Rahmen von Emissions- und Immissionsmessungen; Probenahme von luftgetragenen polyhalogenierten Dibenz-p-Dioxinen und Dibenzofuranen bei Emissionen und Immissionen; Probenahme von faserförmigen Partikeln bei Emissionen und Immissionen; Ermittlung von gas- oder partikelförmigen Luftinhaltsstoffen mit kontinuierlich arbeitenden Messgeräten; Bestimmung von Geruchsstoffen in Luft; Kalibrierungen und Funktionsprüfungen kontinuierlich arbeitender Messgeräte für Luftinhaltsstoffe einschließlich Systemen zur Datenauswertung und Emissionsfernüberwachung; Feuerraummessungen; Eignungsprüfungen von automatisch arbeitenden Emissions- und Immissionsmesseinrichtungen einschließlich Systemen zur Datenauswertung und Emissionsfernüberwachung; Ermittlung der Emissionen und Immissionen von Geräuschen; Ermittlung von Geräuschen und Vibrationen am Arbeitsplatz; akustische und schwingungstechnische Messungen im Eisenbahnwesen; Bestimmung von Schalleistungspegeln von zur Verwendung im Freien vorgesehenen Geräten und Maschinen nach Richtlinie 2000/14/EG und Konformitätsbewertungsverfahren; Schornsteinhöhenberechnung und Immissionsprognose auf der Grundlage der Technischen Anleitung zur Reinhaltung der Luft und der Geruchsimmissions-Richtlinie und der VDI 3783 Blatt 13; Windenergieanlagen: Bestimmung von Windpotential, Energieerträgen, Standorterträgen und Standortgüte nach EEG, standortbezogenen Turbulenzcharakteristika und Extremwinde; Schallimmissionsprognosen, Schattenwurfimmissionsberechnung und Sichtbarkeitsbestimmung; Probenahme und mikrobiologische Untersuchungen von Nutzwasser gemäß §3 Absatz 8 42. BImSchV; physikalische, physikalisch-chemische und mikrobiologische Untersuchungen von Wasser (Abwasser, Wasser aus Rückkühlwerken sowie raumlufttechnischen Anlagen); Probenahme von Abwasser; mikrobiologische und ausgewählte chemische Untersuchungen gemäß Trinkwasserverordnung; Probenahme von Roh- und Trinkwasser; ausgewählte mikrobiologische Untersuchungen von Bedarfsgegenständen und kosmetischen Mitteln; Probenahme anorganischer faserförmiger Partikel sowie von partikel- und gasförmigen luftverunreinigenden Stoffen in der Innenraumluft; ausgewählte mikrobiologische Untersuchungen in Innenräumen; Ermittlung von Aerosolen und Faserstäuben, anorganischen und organischen Gasen und Dämpfen sowie ausgewählten Parametern und/oder in ausgewählten Gebieten bei Arbeitsplatzmessungen gemäß Gefahrstoffverordnung §7, Abs. 10; Modul Immissionsschutz

Die Akkreditierungsurkunde gilt nur in Verbindung mit dem Bescheid vom 02.08.2018 mit der Akkreditierungsnummer D-PL-11120-02-00 und ist gültig bis 10.12.2022. Sie besteht aus diesem Deckblatt, der Rückseite des Deckblatts und der folgenden Anlage mit insgesamt 55 Seiten.

Registrierungsnummer der Urkunde: **D-PL-11120-02-00**

Berlin, 02.08.2018


Im Auftrag Dipl.-Ing. Andrea Valbuena
Abteilungsleiterin

Siehe Hinweise auf der Rückseite

Figure 12: Certificate of accreditation according to EN ISO/IEC 17025:2005

Deutsche Akkreditierungsstelle GmbH

Standort Berlin
Spittelmarkt 10
10117 Berlin

Standort Frankfurt am Main
Europa-Allee 52
60327 Frankfurt am Main

Standort Braunschweig
Bundesallee 100
38116 Braunschweig

Die auszugsweise Veröffentlichung der Akkreditierungsurkunde bedarf der vorherigen schriftlichen Zustimmung der Deutsche Akkreditierungsstelle GmbH (DAkkS). Ausgenommen davon ist die separate Weiterverbreitung des Deckblattes durch die umseitig genannte Konformitätsbewertungsstelle in unveränderter Form.

Es darf nicht der Anschein erweckt werden, dass sich die Akkreditierung auch auf Bereiche erstreckt, die über den durch die DAkkS bestätigten Akkreditierungsbereich hinausgehen.

Die Akkreditierung erfolgte gemäß des Gesetzes über die Akkreditierungsstelle (AkkStelleG) vom 31. Juli 2009 (BGBl. I S. 2625) sowie der Verordnung (EG) Nr. 765/2008 des Europäischen Parlaments und des Rates vom 9. Juli 2008 über die Vorschriften für die Akkreditierung und Marktüberwachung im Zusammenhang mit der Vermarktung von Produkten (Abl. L 218 vom 9. Juli 2008, S. 30). Die DAkkS ist Unterzeichnerin der Multilateralen Abkommen zur gegenseitigen Anerkennung der European co-operation for Accreditation (EA), des International Accreditation Forum (IAF) und der International Laboratory Accreditation Cooperation (ILAC). Die Unterzeichner dieser Abkommen erkennen ihre Akkreditierungen gegenseitig an.

Der aktuelle Stand der Mitgliedschaft kann folgenden Webseiten entnommen werden:
EA: www.european-accrreditation.org
ILAC: www.ilac.org
IAF: www.iaf.nu

Figure 12: Certificate of accreditation according to EN ISO/IEC 17025:2005 - page 2

Annex 1:

Manual



48iQ Instruction Manual

Carbon Monoxide Analyzer

117080-00 • 15Jan2018

Contents

| | | |
|------------------|--|------------|
| Chapter 1 | Introduction..... | 1-1 |
| | iQ Series Instrument Platform..... | 1-1 |
| | 48iQ Principle of Operation | 1-3 |
| | Specifications | 1-5 |
| | Dimensions..... | 1-7 |
| | | |
| Chapter 2 | Installation and Setup..... | 2-1 |
| | Unpacking and Inspection | 2-1 |
| | Cover Removing and Replacing | 2-2 |
| | Mounting Options..... | 2-3 |
| | Bench Mount..... | 2-3 |
| | Rack Mount..... | 2-4 |
| | Setup Procedure..... | 2-6 |
| | Startup..... | 2-8 |
| | | |
| Chapter 3 | Operation..... | 3-1 |
| | Instrument Display | 3-1 |
| | Main Menus and Keypads..... | 3-5 |
| | Numeric Keypad..... | 3-6 |
| | Alphanumeric Keypad..... | 3-7 |
| | Calibration..... | 3-9 |
| | Calibrate Background..... | 3-11 |
| | Calibrate Span Coefficient | 3-12 |
| | Zero/Span Schedule | 3-14 |
| | Calibrate O ₂ Span Coefficient..... | 3-16 |
| | Advanced Calibration..... | 3-17 |
| | Manual Calibration..... | 3-19 |
| | Multipoint Calibration..... | 3-24 |
| | Manual O ₂ Calibration | 3-27 |
| | 2-Point O ₂ Calibration..... | 3-29 |
| | Calibration History..... | 3-31 |
| | Data..... | 3-32 |
| | View Data Log (Last Hour)..... | 3-33 |
| | View Data Log (Last 24 Hours) | 3-34 |
| | View Data Log (User Defined Time) | 3-35 |
| | Advanced Data Setup..... | 3-37 |
| | Data Logging Setup | 3-38 |
| | Select Data Logging Variables | 3-39 |

| | |
|---|-------|
| Streaming Data Setup | 3-41 |
| Select Streaming Variables..... | 3-42 |
| Settings | 3-44 |
| Health Check..... | 3-45 |
| Status and Alarms..... | 3-46 |
| Concentration..... | 3-47 |
| NDIR Bench..... | 3-49 |
| O ₂ Sensor | 3-52 |
| Flow and Pressure | 3-54 |
| Peripherals Support..... | 3-56 |
| Valve and Pump Resets | 3-58 |
| Serial Numbers | 3-63 |
| Predictive Diagnostics | 3-64 |
| Maintenance | 3-65 |
| Preventive Maintenance | 3-66 |
| Change Part | 3-68 |
| Maintenance History..... | 3-69 |
| File Sharing and Support..... | 3-71 |
| Measurement Settings | 3-72 |
| Averaging Time..... | 3-74 |
| Range Mode Selection..... | 3-76 |
| Range Setting..... | 3-78 |
| Gas Mode | 3-79 |
| Gas Units..... | 3-80 |
| Advanced Measurement Settings..... | 3-81 |
| Communications | 3-89 |
| Wired TCP/DHCP | 3-90 |
| Serial RS-232/485..... | 3-92 |
| Analog I/O..... | 3-93 |
| Digital I/O..... | 3-94 |
| Email Server (SMTP)..... | 3-95 |
| Instrument Settings..... | 3-96 |
| Display Setup..... | 3-97 |
| Alarm Set Points | 3-98 |
| Clock | 3-100 |
| Date / Time Parameters | 3-101 |
| Time Zone..... | 3-102 |
| Time Server..... | 3-104 |
| Date Format..... | 3-105 |
| Configuration | 3-106 |
| Security Access Levels..... | 3-107 |
| Change Security to View Only Access..... | 3-109 |
| Change Full Access Security Password..... | 3-110 |
| USB Drive | 3-112 |
| Firmware Update Via USB Drive..... | 3-113 |
| Download Data To USB Drive..... | 3-114 |

| | | |
|------------------|--|------------|
| | Change USB Password..... | 3-117 |
| | User Contact Information..... | 3-119 |
| | Update Bootloader..... | 3-120 |
| Chapter 4 | Calibration..... | 4-1 |
| | Equipment Required..... | 4-1 |
| | CO Concentration Standard..... | 4-1 |
| | Zero Air Generator..... | 4-1 |
| | External Flow Meter(s) and Controller(s)..... | 4-2 |
| | Pre-Calibration..... | 4-2 |
| | Calibration..... | 4-3 |
| | Connect the Instrument..... | 4-3 |
| | Detector Gain..... | 4-4 |
| | Initial S/R..... | 4-5 |
| | Multipoint Calibration..... | 4-6 |
| | High and Low Multipoint Calibration..... | 4-8 |
| | Calibration Frequency..... | 4-8 |
| | Calibrate Background..... | 4-9 |
| | Calibrate Span Coefficient..... | 4-10 |
| | Periodic Zero and Span Checks..... | 4-12 |
| | Manual Calibration..... | 4-13 |
| | Adjust Background..... | 4-13 |
| | Adjust Span Coefficient..... | 4-14 |
| | Reset Bkg to 0.000 and Span Coef to 1.000..... | 4-14 |
| | Zero/Span Schedule..... | 4-15 |
| | Next Time..... | 4-15 |
| | Period..... | 4-15 |
| | Zero/Span/Purge Duration Minutes..... | 4-15 |
| | Schedule Averaging Time..... | 4-16 |
| | Background Calibration and Span Calibration..... | 4-16 |
| | Zero Calibration and Span Calibration..... | 4-16 |
| | Zero/Span Ratio..... | 4-16 |
| | References..... | 4-16 |
| Chapter 5 | Maintenance..... | 5-1 |
| | Safety Precautions..... | 5-1 |
| | Fan Filter Inspection and Cleaning..... | 5-1 |
| | Pump Rebuilding..... | 5-2 |
| | Leak Test..... | 5-5 |
| | Cleaning the Optics..... | 5-6 |
| | IR Source Replacement..... | 5-8 |
| Chapter 6 | Troubleshooting..... | 6-1 |
| | Safety Precautions..... | 6-1 |
| | Troubleshooting Guide..... | 6-1 |

| | | |
|------------------|--|------------|
| Chapter 7 | Servicing | 7-1 |
| | Safety Precautions | 7-1 |
| | Firmware Updates | 7-3 |
| | Replacement Parts List | 7-3 |
| | Fuse Replacement | 7-5 |
| | Filter Replacement | 7-6 |
| | Fan Replacement..... | 7-7 |
| | Measurement Side Removal | 7-9 |
| | LCD Module Replacement | 7-12 |
| | I/O Replacement..... | 7-14 |
| | Peripherals Support Board and System Controller Board Replacement | 7-16 |
| | DMC Pressure and Flow Board | 7-17 |
| | Pump Replacement | 7-19 |
| | Capillary Cleaning and/or Replacement | 7-22 |
| | Capillary O-Ring Replacement | 7-24 |
| | Power Supply Replacement | 7-24 |
| | Step POL Board Replacement..... | 7-26 |
| | DMC Optical Bench..... | 7-29 |
| | Optical Bench Removal | 7-30 |
| | Optical Switch Replacement | 7-31 |
| | Purge Wheel Housing Removal..... | 7-34 |
| | Filter Wheel Replacement | 7-35 |
| | Motor Replacement | 7-37 |
| | Motor and Filter Wheel Alignment..... | 7-39 |
| | Optical Bench/Heater Removal..... | 7-41 |
| | Pre-Amp/Detector Assembly Removal | 7-43 |
| | IR Source Replacement | 7-45 |
| | Optional Manifold Replacement..... | 7-48 |
| | Optional Zero Air Scrubber Replacement | 7-50 |
| | Optional DMC Oxygen Sensor..... | 7-51 |
| | Oxygen Sensor Removal..... | 7-51 |
| | Oxygen Sensor Board Replacement..... | 7-54 |
| | Oxygen Sensor Capillary Replacement | 7-56 |
| | Oxygen Sensor Replacement | 7-58 |
| Chapter 8 | System Description | 8-1 |
| | Optical Bench DMC..... | 8-2 |
| | Optical Bench Hardware..... | 8-2 |
| | Filter Wheel Motor | 8-2 |
| | Filter Wheel Purge | 8-2 |
| | Detector Preamp | 8-3 |
| | Infrared Source..... | 8-3 |

| | | |
|-------------------|--|------------|
| | Optical Bench DMC Board | 8-3 |
| | Common Electronics | 8-4 |
| | Power Supply | 8-7 |
| | Front Panel | 8-7 |
| | I/O and Communication Components | 8-7 |
| | System Controller Board | 8-7 |
| | Backplane Board | 8-7 |
| | Peripherals Support System | 8-8 |
| | Fan..... | 8-8 |
| | STEP POL Board | 8-8 |
| | Sample Pump..... | 8-8 |
| | Solenoid Valve Panel (optional) | 8-8 |
| | Flow/Pressure DMC | 8-8 |
| | Firmware..... | 8-8 |
| | Oxygen Sensor (optional)..... | 8-9 |
| Chapter 9 | Optional Equipment..... | 9-1 |
| | Connecting External Devices | 9-1 |
| | Communication Board | 9-2 |
| | RS-232/RS-485 Port | 9-2 |
| | RS-485 External Accessory Port | 9-3 |
| | Analog I/O Board | 9-4 |
| | Analog Voltage Inputs..... | 9-4 |
| | Analog Voltage Outputs..... | 9-5 |
| | Analog Output Calibration | 9-6 |
| | Analog Output Zero Calibration..... | 9-7 |
| | Analog Output Full Scale Calibration | 9-9 |
| | Digital I/O Board..... | 9-11 |
| | Digital Inputs..... | 9-11 |
| | Digital Relay Switches..... | 9-13 |
| | Valve Driver Outputs..... | 9-15 |
| | Internal Zero/Span Assembly | 9-17 |
| | Internal Oxygen (O ₂) Sensor | 9-18 |
| | Internal Zero Air Scrubber | 9-18 |
| | PTFE Particulate Filter | 9-18 |
| Appendix A | Safety, Warranty, and WEEE..... | A-1 |
| | Safety | A-1 |
| | Safety and Equipment Damage Alerts | A-1 |
| | Warranty..... | A-2 |
| | WEEE Compliance..... | A-4 |
| | WEEE Symbol..... | A-4 |
| Appendix B | Quick Reference | B-1 |
| | List of Figures | B-1 |

Contents

| | | |
|-------------------|--|------------|
| | List of Tables..... | B-3 |
| Appendix C | GNU Lesser General Public License | C-1 |
| | GNU Lesser General Public License..... | C-1 |

Chapter 1

Introduction

The Thermo Scientific™ 48iQ Carbon Monoxide (CO) Analyzer utilizes gas filter correlation technology to measure the amount of carbon monoxide in the air.

The analyzer is based on the principle that carbon monoxide (CO) absorbs infrared radiation at a wavelength of 4.6 microns. Because infrared absorption is a nonlinear measurement technique, it is necessary for the instrument electronics to transform the basic analyzer signal into a linear output.

The 48iQ Gas Analyzer uses an exact calibration curve to accurately linearize the instrument output over any range up to a concentration of 10,000 ppm.

iQ Series Instrument Platform

The iQ Series Instrument Platform is a smart environmental monitoring solution for ambient and source gas analysis that affords greater control over instrument performance and data availability.

- Distributed Measurement and Control (DMC) module design simplifies serviceability. Each DMC module contains its own microprocessor control enabling functional performance validation at the module level.
- Built-in predictive diagnostics and preventive maintenance schedules identify problems before they occur. The iQ Series platform sends email notifications directly to Thermo Fisher Scientific's world class service support team or locally identified addressees in order to proactively communicate analyzer performance conditions and identify spare parts needs before an operational concern arises.
- The iQ Series platform supports Modbus, streaming and VNC protocols over serial and Ethernet as well as analog and digital I/O for easy integration into most data management systems.
- Three standard USB ports afford convenient data download capability as well as the ability to connect additional hardware, such as a computer keyboard or mouse.

Introduction

iQ Series Instrument Platform

- The iQ Series GUI runs on a 7” color touchscreen display. The GUI is highly flexible and can be customized to enable a tailored experience to simplify daily operations. Custom designed ePort software allows remote access to the analyzer with a PC. The ePort control mirrors the same GUI look and feel as the instrument touchscreen providing a speedy and familiar operational experience.




Figure 1–1. 48iQ Front

48iQ Principle of Operation

The 48iQ operates on the principle that carbon monoxide (CO) absorbs infrared radiation at a wavelength of 4.6 microns. Gas Filter Correlation (GFC) is a particular infrared technique that selectively measures light absorption uniquely due to CO by the ratio of sample-absorbed light to a filtered reference measurement. Light from a broadband infrared source passes through a gas filter wheel alternating between N₂ and CO filled cells and passes through a narrow bandpass interference filter before passing into the volume containing sample gas. Light that passes through the N₂ cell is absorbed by CO in the sample gas normally as the *sample* signal; light that passes through the CO cell is already blocked where CO absorbs, and so is unchanged by sample CO as the *reference*. The ratio of “sample” to “reference” (S/R) is acquired at high speeds and corrects for light intensity and other changes to achieve precision measurement. Because the filtering is achieved with CO gas itself, the GFC technique is specific for CO.

The so-called “spectral resolution” of the technique is such that the measured ratio is partly but not strictly linear as predicted by the well-known “Beer’s Law.” The 48iQ uses an internally stored calibration curve to accurately linearize the instrument output over any range up to a concentration of 10,000 ppm.

Gas sample is drawn into the 48iQ through the rear panel of the analyzer and through the optical detection system using an embedded intake pump, as shown in [Figure 1–2](#). Gas may be ambient, or it may be delivered from a more distant location using standard tubing connected to the rear panel. The rear panel may be a simple inlet bulkhead, or it could utilize three inlets controlled with solenoid valves: Conventionally, the three inlet configuration is used to conduct independent zero and span reference measurements.

In addition to the inlet configuration, options may be added, such as an oxygen sensor or a “zero scrubber” that catalyzes CO to CO₂ to provide a zero reference. Each of these operate within the basic gas intake pathway described above.

[Figure 1–2](#) shows the simplest case fluid schematic. Gas is introduced into the “SAMPLE” port at near ambient pressures (we describe a flow bypass later on that assures ambient pressure sampling). It is pulled by a single stage pump through the 48 DMC Bench where CO is detected and then through a constriction (a capillary in the “Flow Pressure DMC”) which regulates the flow intake to approximately 1 SLPM while monitoring and maintaining ambient pressure on the optical bench side. Note there is also a filter purge that bypasses the sampling but is also drawn by the pump downstream of the constriction. [Figure 1–3](#) shows the example of a three inlet configuration with zero span capabilities and a zero air scrubber.




Figure 1–2. 48iQ Flow Schematic




Figure 1–3. 48iQ Flow Schematic with Zero Span and Zero Air Scrubber

Specifications

Table 1–1 lists the specifications for the 48iQ.

Table 1–1. 48iQ Specifications

| | |
|------------------------------|---|
| Range | 0-10000 (ppm or mg/m ³) |
| Zero Noise | 0.02 ppm RMS (30 second averaging time) |
| Detection Limit | 0.04 ppm (30 second averaging time) |
| Zero Drift | <0.1 ppm (24 hour) |
| Span Drift | ±0.5% reading (24 hour) |
| Response Time | 60 seconds (30 second averaging time) |
| Linearity | ±1% full-scale ≤ 1000 ppm ±2.5% full-scale > 1000 ppm |
| Flow Rate | 1.0 SLPM (1 atm inlet pressure) |
| Operating Temperature Range | 5–45 °C (may be safely operated over the range of 0–45 °C) |
| Power Requirements | 100–240 VAC 50/60 Hz 275 watts |
| Physical Dimensions | 24 in (D) x 16.75 in (W) x 8.72 in (H) [609 mm (D) 425.45 mm (W) x 221.48 mm (H)] |
| Weight | 34.3 lbs |
| Analog I/O | 4 Isolated Voltage Inputs 0–10 V 6 Isolated Analog Voltages Outputs, with 4 selectable ranges 6 Isolated Analog Current Outputs, with 2 selectable ranges |
| Digital I/O | 16 Digital Inputs (TTL) 8 Solenoid Driver Outputs 10 Digital Reed Relay Contact Outputs |
| Serial Ports | 1 RS-232/485 port 1 RS-485 External Accessory port |
| Other Ports | 3 Full Speed USB ports (one in front, two in rear) 1 Gigabit Ethernet port |
| Communication Protocols | MODBUS, Streaming |
| Approvals and Certifications | CE, TUV-SUD Safety, EPA |

Table 1–2. 48iQ Optional Internal Oxygen Sensor Specifications

| | |
|---|---|
| Technology | Paramagnetic |
| Range | 0-100% O ₂ |
| Accuracy (Intrinsic error) | <±0.1% O ₂ |
| Linearity | <±0.1% O ₂ |
| Repeatability | <±0.1% O ₂ |
| Zero Drift | <±0.2% O ₂ per month (excludes up to 0.1% O ₂ in the first 24 hours of operation) |
| Response Time (T ₁₀ -T ₉₀) | <2.5 seconds |
| Weight | Approximately 2 lbs. (in addition to standard instrument) |




Figure 1-5. Rack Mount Assembly (dimensions in inches [mm])




Figure 1-6. Rack Mount Requirements




Figure 1-7. Rack Requirements Part 2

Chapter 2

Installation and Setup

Installation and Setup describes how to unpack, setup, and start-up the instrument. The installation should always be followed by instrument calibration as described in the “[Calibration](#)” chapter of this manual.



Equipment Damage Do not attempt to lift the instrument by the cover or other external fittings. ▲

Unpacking and Inspection

The 48iQ is shipped complete in one container. If there is obvious damage to the shipping container when you receive the instrument, notify the carrier immediately and hold for inspection. The carrier is responsible for any damage incurred during shipment.

Use the following procedure to unpack and inspect the instrument.

1. Remove the instrument from the shipping container and set it on a table or bench that allows easy access to both the front and rear.
2. Remove the cover to expose the internal components. (See “[Figure 2-1](#)” on page 2-2.)
3. Check for possible damage during shipment.
4. Check that all connectors and circuit boards are firmly attached.
5. Re-install the cover.
6. Remove any protective plastic material from the case exterior.

Cover Removing and Replacing

Use the following procedure to remove and replace the cover.

Equipment required:

Phillips screwdriver, #2

1. Unfasten the four 8-32 screws securing the cover (shipping screws).
2. Press in both latches located on top cover and hold while pulling up to remove. Set upright.




Figure 2-1. Removing the Cover

3. To replace, align cover and drop in. Latches will automatically snap in place.

Mounting Options

The instrument can be installed in the following configurations:

- Bench Mount
- Rack Mount

Bench Mount

Positioned on bench, includes installing feet. See [Figure 2–2](#).

Equipment required:

Slot drive, 5/16-inch

1. Fasten feet in position 1 or 2 to fit to the desired depth.




Figure 2–2. Installing Feet

Rack Mount

Mounting in a rack includes removing the front panel and installing ears and handles.

Equipment required:

Phillips drive, #2

1. Start by gripping from the top corners of the front panel and pull outwards. See [Figure 2–3](#).




Figure 2–3. Removing the Front Panel

2. Unfasten the four 8-32 pan head screws.
3. Slide ears outwards.
4. Use the same four 8-32 pan head screws to secure it.
5. Install the handles with the four 8-32 flat head screws that came with the handle kit on the backside. See [Figure 2–4](#).




Figure 2-4. Installing Ears and Handles

Setup Procedure

Use the following procedure to setup the instrument:

1. Connect the sample line to the SAMPLE bulkhead on the rear panel (Figure 2-5). Ensure that the sample line is not contaminated by dirty, wet, or incompatible materials. All tubing should be constructed of PTFE, 316 stainless steel, borosilicate glass, or similar tubing with an OD of 1/4-inch and a minimum ID of 1/8-inch. The length of the tubing should be less than 10 feet.

Note Gas must be delivered to the instrument free of particulates. It may be necessary to use the PTFE particulate filter as described in “PTFE Particulate Filter” on page 9-18. ▲

Note Gas must be delivered to the instrument at atmospheric pressure. It may be necessary to use an atmospheric bypass plumbing arrangement as shown in Figure 2-6 if gas pressure is greater than atmospheric pressure. ▲

2. Connect the EXHAUST bulkhead to a suitable vent. The exhaust line should be 1/4-inch OD with a minimum ID of 1/8-inch. The length of the exhaust line should be less than 10 feet. Verify that there is no restriction in this line.
3. If the external purge filter is installed, connect a source of pressurized clean dry zero air or a non-toxic inert gas at 10 psig to the purge fitting for use as the Filter Wheel Purge gas. A purge gas flow of 140 cc/min is recommended for optimum performance. The Filter Wheel Purge is described more fully on page 8-2.
4. If the optional zero/span solenoid valves are installed, connect a source of CO-free air to the ZERO IN bulkhead, and connect a source of CO span gas to the SPAN bulkhead.
5. Connect a suitable recording device to the rear panel connector. For detailed information about connecting to the instrument, refer to:
“Connecting External Devices” on page 9-1
Communications > “Analog I/O” on page 3-59, and “Digital I/O” on page 3-61.

6. Plug the instrument into an outlet of the appropriate voltage and frequency.



The 48iQ is supplied with a three-wire grounding cord. Under no circumstances should this grounding system be defeated. ▲




Figure 2-5. 48iQ Rear Panel




Figure 2-6. Atmospheric Dump Bypass Plumbing

Startup

Use the following procedure when starting the instrument.

1. Turn the power ON.
2. Allow 90 minutes for the instrument to stabilize.
3. Set instrument parameters such as operating ranges and averaging times to appropriate settings. For more information about instrument parameters, see the “[Operation](#)” chapter.
4. Before beginning the actual monitoring, perform a multipoint calibration as described in the “[Calibration](#)” chapter.




Figure 2–7. Front Panel and Touchscreen Display

Chapter 3


Operation

This chapter describes the functionality of the touchscreen user interface.

Instrument Display

The Instrument Display consists of a Title Bar, a User Interface, and a Status Bar. The Title Bar, located at the top, includes the Home button, instrument name, instrument gas mode, and Help button. The User Interface, located in the middle, is where the Home Screen and all other screens are accessed. The Home Screen has three Main Menu buttons, located on the left side, which include Calibration, Data, and Settings, while the user interface to the right of the buttons displays the chemical name(s), concentration value(s) and unit(s). The Status Bar, located at the bottom, includes the Back button, Access Levels, Health Check, Favorites, Date and Time, and Contact Information.

Home Screen (single range mode with O₂ option)



Home Screen (dual or auto range mode with O₂ option)



The Instrument Display contains the following information:

- Title Bar:
 - *Home button*: When pressed, it brings you to the Home Screen.
 - *Title Text*: Displays instrument name when in the Home Screen. Displays the chemical name, current concentration reading and unit when in all other screens. When unit is pressed, it brings you to the gas unit selection screen.
 - *Gas Mode button*: Displays current gas mode of the instrument. When pressed, it brings you to the Gas Mode selection screen.
 - *Help button*: When pressed, it brings you to the help screens.
- User Interface:
 - *Calibration button*: Allows the user to calibrate the instrument, setup automatic calibrations, and view calibration data.
 - *Data button*: Allows the user to view, graph, stream, and analyze data.
 - *Settings button*: Shows real-time status and alarms, also predictive diagnostics and maintenance history. Contains controls for operating the instrument, communications, and sets instrument options.
 - *Concentration*: When in single mode, displays CO concentrations in big, bold characters, depending on operating mode. When in dual or auto mode, displays either high range or low range values based on the range setting.
- Status Bar:
 - *Back button*: When pressed, it displays the previous screen.
 - *Access Levels button*: Allows the user to set security access levels, and allows/restricts access to functionality depending on the selected access level.
 - *Health Check button*: Brings the user to the Health Check screen.
 - *Favorites button*: Allows user-selectable favorite buttons. To add to the favorites screen, user presses the desired screen button for 2 seconds. The user will be directed to the favorites screen where the user chooses the button position. To remove a favorite button from the favorites screen, press and hold button for 2 seconds.
 - *Clock*: Displays current date and time.

Operation

Instrument Display

- *Thermo Scientific Information button*: Shows contact information.


Main Menus and Keypads

The Main Menu buttons, located on the Home Screen, contains three submenus. Each submenu contains related instrument settings. This chapter describes each submenu and screen in detail. Refer to the appropriate sections for more information.




Numeric Keypad

User enters a value into the box using the number keypad. When the user needs to change a value, such as for flow rates, temperatures or pressures, the keypad screen will automatically display. Initially, the box above the keypad will display the current value. Enter a new value using the keypad, and then select the **Enter** button to set the new value or press the **Cancel** button to exit the keypad screen and return to the previous screen without saving the value.




Alphanumeric Keypad

User enters a value into the box using the keypad. When the user needs to change an alphanumeric value, this keypad will automatically display. Initially, the box above the keypad will display the current value. Enter a new value using the keypad, and then select the **Enter** button to set the new value or press the **Cancel** button to exit the keypad screen and return to the previous screen without saving the value. The alphanumeric keypad is only available when the user needs to enter alphabet characters.



Operation
Instrument Display



Calibration

The Calibration screen allows the user to calibrate the system, setup automatic calibrations, and view calibration data. See Chapter 4 “Calibration” for further instructions on how to run a calibration.

The following screens show the calibration screens in single range mode and dual or auto range mode. (The only difference between the screens, are the words “High Range” and “Low Range”.) The dual and auto range modes have two CO span coefficients (high and low). This allows each range to be calibrated separately. This is necessary if the two ranges used are not close to one another. For example, a low CO range of 50 ppm and a high CO range of 1000 ppm. For more information about range modes, see “Range Mode Selection” on page 3-76.

Home Screen>Calibration (single range mode with O₂ option)



Home Screen>Calibration (dual or auto range mode with O₂ option)



The Calibration menu contains the following information:

- *Calibrate Background*: Sets the CO reading to zero.
- *Calibrate Span Coefficient*: Sets the span coefficient when in single range mode.


- *Calibrate High Range Span Coefficient:* Sets the high range span coefficient when in dual or auto range mode.
- *Calibrate Low Range Span Coefficient:* Sets the low range span coefficient when in dual or auto range mode.
- *Zero/Span Schedule:* Programs the instrument to perform fully automated zero and span checks or adjustments.
- *Calibrate O₂ Span Coefficient:* When the O₂ Sensor option is turned on (in the Settings>Configuration screen), this button will appear. It allows an O₂ calibration to be performed.
- *Advanced Calibration:* Calibrates the instrument using a manual zero/span calibration, a multipoint calibration and provides calibration history.

Calibrate Background

The Calibrate Background screen is used to calibrate the instrument zero background. Before making an adjustment, be sure the analyzer samples zero air for at least 5 minutes.

It is important to note the averaging time when calibrating. The longer the averaging time the more precise the calibration results. To achieve maximum precision, allow the instrument to stabilize each time input gas is changed and set the averaging time to 300-second averaging. The Averaging Time is located at Settings>Measurement Settings>Averaging Time.

Home Screen>Calibration>Calibrate Background



The Calibrate Background menu contains the following information:

- *Target Concentration:* Read only. Displays what the concentration value will become when the calibrate button is pressed.
- *Current Background:* Read only. Displays what the current user-set background is.
- *Calculated Background:* Read only. Displays what the current user-set background will become when the calibrate button is pressed.
- *Calibrate:* When pressed, updates the background, making the concentration go to zero.

Calibrate Span Coefficient

The Calibrate Span Coefficient screen is used to enter the span concentration and calibrate the CO span coefficient. The CO span coefficient is calculated, stored, and used to correct the current reading.

The following screens are shown in single range mode and dual or auto range mode. In dual or auto range modes, “High” or “Low” is displayed to indicate the calibration of the high or low coefficient. The Calibrate High Range Span Coefficient and Calibrate Low Range Span Coefficient screens function the same way.

It is important to note the averaging time when calibrating. The longer the averaging time the more precise the calibration results. To achieve maximum precision, allow the instrument to stabilize each time input gas is changed and set the averaging time to 300-second averaging.

Home Screen>Calibration>Calibrate Span Coefficient (single range mode)



Home Screen>Calibration>Calibrate High Range Span Coefficient (dual or auto range mode)



The Calibrate Span Coefficient menu contains the following information:

- *Edit Span Concentration*: User enters the span concentration when in single range mode.
- *Edit High Range Span Concentration*: User enters the high range span concentration when in dual or auto range mode.
- *Edit Low Range Span Concentration*: User enters the low range span concentration when in dual or auto range mode.
- *Current High Range Concentration*: Read only. Current high range concentration reading when in dual or auto range mode.
- *Current Low Range Concentration*: Read only. Current low range concentration reading when in dual or auto range mode.
- *Current Span Coefficient*: Read only. Displays what the current user-set span coefficient is when in single range mode.
- *Current High Range Span Coefficient*: Displays what the current user-set high range span coefficient is when in dual or auto range mode.
- *Current Low Range Span Coefficient*: Displays what the current user-set low range span coefficient is when in dual or auto range mode.
- *Calculated Span Coefficient*: Read only. After the “Edit Span Concentration” value is entered, the new calculated span coefficient is displayed when in single range mode.
- *Calculated High Range Span Coefficient*: Read only. After the “Edit High Range Span Concentration” value is entered, the new calculated high range span coefficient is displayed when in dual or auto range mode.
- *Calculated Low Range Span Coefficient*: Read only. After the “Edit Low Range Span Concentration” value is entered, the new calculated low range span coefficient is displayed when in dual or auto range mode.
- *Calibrate*: When pressed, updates the coefficient and the concentration should match the span concentration.


Zero/Span Schedule

The Zero/Span Schedule is used to program the instrument to perform fully automated zero and span checks or adjustments.

Home Screen>Calibration>Zero/Span Schedule



Home Screen>Calibration>Zero/Span Schedule>More



The Zero/Span Schedule contains the following information:

- *Zero/Span Schedule:* Toggles zero/span schedule Enabled or Disabled.
- *Next Time:* Allows the user to view and set the initial date and time (24-hour format) of the zero/span schedule.
- *Period:* Defines the period or interval between zero/span checks or calibrations. If period = 0, the schedule runs continuously.
- *Zero Duration:* Sets how long zero air is sampled by the instrument.
- *Span Duration:* Sets how long span gas is sampled by the instrument.
- *Purge Duration:* Sets how long the purge period will be at the end of the schedule.


- *Total Duration*: Read only. Displays the total time duration of all scheduled events.
- *Schedule Averaging Time*: Allows the user to adjust the zero/span schedule averaging time. This averaging time only affects the zero/span schedule.
- *Background Calibration*: Toggles Enabled/Disabled. If enabled, background value is calibrated. If disabled, schedule runs a background check only and background value is not updated.
- *Span Calibration*: Toggles Enabled/Disabled. If enabled, span coefficient is calibrated. If disabled, schedule runs a calibration check only and span coefficient is not updated.
- *Zero : Span Ratio*: Allows the user to perform more scheduled background calibration checks to span calibration checks. Default is 1 and therefore reads 1:1. (This means that each time the schedule is run, both the zero duration and span duration occurs.) The zero/span ratio is allowable between 1 to 99. If 99 is chosen, the schedule should only perform the Span on the 99th iteration.

Calibrate O₂ Span Coefficient

The Calibrate O₂ Span Coefficient screen is used to enter the O₂ span concentration and calibrate the O₂ span coefficient while sampling span gas of known concentration. This button appears if the O₂ Sensor option is selected in the configuration screen.

It is important to note the averaging time when calibrating. The longer the averaging time the more precise the calibration results. To achieve maximum precision, allow the instrument to stabilize each time input gas is changed and set the averaging time to 300-second averaging. The O₂ Averaging Time is located at Settings>Measurement Settings>Averaging Time.

Home Screen>Calibration>Calibrate O₂ Span Coefficient (single range mode)



The Calibrate O₂ Span Coefficients screen contains the following information:


- *Edit O₂ Span Concentration*: User enters the O₂ span concentration.
- *Current O₂ Concentration*: Read only. Current O₂ concentration reading.
- *Current O₂ Span Coefficient*: Read only. Current O₂ span coefficient value.
- *Calculated O₂ Span Coefficient*: Read only. After the “Edit O₂ Span Concentration” value is entered, the new calculated O₂ span coefficient is displayed.
- *Calibrate*: When pressed, updates the O₂ coefficient and the O₂ concentration should match the span concentration.

Advanced Calibration

The Advanced Calibration screen provides several additional ways to calibrate the instrument and view the calibration history. See Chapter 4 “Calibration” for further instructions on how to run a calibration.

The following screens show the advanced screens in single range mode and dual or auto range mode. (The only difference between the screens, are the words “High” and “Low”.) For more information about range modes, see “Range Mode Selection” on page 3-76.

Home Screen>Calibration>Advanced Calibration (single range mode with O₂ option)



Home Screen>Calibration>Advanced Calibration (dual or auto range mode with O₂ option)



The Advanced Calibration screens contain the following information:

- *Manual Calibration:* The user manually adjusts the background or span coefficient.
- *Multipoint Calibration:* Up to three gas concentrations (cal-points) may be calibrated. Three cal-points will give the most accurate readings over the entire range.


- *High Range Multipoint Calibration:* Up to three gas concentrations (cal-points) for high range may be calibrated. Three cal-points will give the most accurate readings over the entire range.
- *Low Range Multipoint Calibration:* Up to three gas concentrations (cal-points) for low range may be calibrated. Three cal-points will give the most accurate readings over the entire range.
- *Manual O₂ Calibration:* The user manually adjusts the O₂ span coefficient based on the current O₂ concentration value.
- *2-Point O₂ Calibration:* The user manually performs a 2-point calibration of the O₂ sensor.
- *Calibration History:* Lists all calibrations performed and calibration checks.

Manual Calibration

The Manual Calibration screen adjusts the zero background or span coefficient based on a user entered value. See Chapter 4, “[Calibration](#)” for instructions on how to run a Manual Calibration.

The following screens show the manual calibration screens in single range mode and dual or auto range mode. In dual or auto range modes, “High Range” or “Low Range” buttons are displayed to indicate the calibration of the high or low coefficient.

Home Screen>Calibration>Advanced Calibration>Manual Calibration (single range mode)



Home Screen>Calibration>Advanced Calibration>Manual Calibration (dual or auto range mode)



The Manual Calibration menu contains the following information:

- *Adjust Background:* Allows the user to manually adjust the zero background.
- *Adjust Span Coefficient:* Allows the user to manually adjust the span coefficient when in single range mode.


Operation
Calibration

- *Adjust High Range Span Coefficient:* Allows the user to manually adjust the high range span coefficient when in dual or auto range mode.
- *Adjust Low Range Span Coefficient:* Allows the user to manually adjust the low range span coefficient when in dual or auto range mode.
- *Reset Background to 0.000 and Span Coefficient to 1.000:* Resets all backgrounds and coefficients.

Adjust Background

The Adjust Background screen is used to manually adjust the zero background.

Home Screen>Calibration>Advanced Calibration>Manual Calibration>Adjust Background



The Adjust Background screen contains the following information:


- *Adjust Background*: User manually adjusts zero background.
- *Adjusted Concentration*: Read only. Shows adjusted concentration based on adjusted zero background.
- *Calibrate*: Calibrates zero background by saving the newly adjusted zero background value.

Adjust Span Coefficient


The Adjust Span Coefficient screen is used to manually adjust the span coefficient.

The following screen is shown in single range mode and dual or auto range mode. In dual or auto range modes, “High Range” or “Low Range” is displayed to indicate the calibration of the high or low coefficient. The Adjust High Range Span Coefficient and Adjust Low Range Span Coefficient screens function the same way.

Home Screen>Calibration>Advanced>Manual Calibration>Adjust Span Coefficient (single range mode)



Home Screen>Calibration>Advanced>Manual Calibration>Adjust High Range Span Coefficient (dual or auto range mode)



The Adjust Span Coefficient menu contains the following information:

- *Adjust Span Coefficient:* User manually adjusts span coefficient when in single range mode.
- *Adjust High Range Span Coefficient:* User manually adjusts high range span coefficient when in dual or auto range mode.

- *Adjust Low Range Span Coefficient:* User manually adjusts low range span coefficient when in dual or auto range mode.
- *Adjusted Concentration:* Read only. Shows adjusted concentration based on adjusted span coefficient when in single range mode.
- *Adjusted High Range Concentration:* Read only. Shows adjusted high range concentration based on adjusted high range span coefficient when in dual or auto range mode.
- *Adjusted Low Range Concentration:* Read only. Shows adjusted low range concentration based on adjusted low range span coefficient when in dual or auto range mode.
- *Calibrate:* Calibrates span coefficient by saving the newly adjusted span coefficient.

Multipoint Calibration

The Multipoint Calibration screen is used to calibrate the instrument using up to three gas concentrations (cal points) for each range. It is suggested to use three cal-points, as this will give the most accurate readings over the entire range.

The following screen is shown in single range mode. In dual or auto range modes, “High Range” or “Low Range” is displayed to indicate the calibration of the high or low coefficients. The High Range Multipoint Calibration and Low Range Multipoint Calibration screens function the same way.

Note Pressing the Multipoint Calibration button responds with “It is recommended to calibrate all three points” and requires an OK action. ▲

Home Screen>Calibration>Advanced Calibration>Multipoint Calibration (single range mode)



The Multipoint Calibration screen contains the following information:

- *Point 1*: First cal point used in the calibrated multipoint polynomial curve.
- *Point 2*: Second cal point used in the calibrated multipoint polynomial curve.
- *Point 3*: Third cal point used in the calibrated multipoint polynomial curve.
- *First Coefficient*: Read only. Value of the first coefficient in the polynomial curve.
- *Second Coefficient*: Read only. Value of the second coefficient in the polynomial curve.

- *Third Coefficient*: Read only. Value of the third coefficient in the polynomial curve.
- *Reset Points to Default Values*: Resets multipoint coefficients to default values.

Point 1–3 The Point 1 screen allows the user to view and set the selected calibration point. The point 2 and point 3 screens function the same way. Therefore, the following example of point 1 screen applies to point 2 and 3 as well.

The following screen is shown in single range mode. In dual or auto range modes, the High Range Multipoint Calibration and Low Range Multipoint Calibration screens function the same way.

The customer defines the ranges. It is suggested to perform the following calibration points for each range:

Cal point 1: 80% of range

Cal point 2: 50% of range

Cal point 3 20% of range

Home Screen>Calibration>Advanced Calibration>Multipoint Calibration>Point 1




The Point 1 screen contains the following information:

- *Edit Point 1 Span Concentration:* User enters span concentration.
- *Point 1 Coefficient:* Read only. After selecting the value on the Edit Point 1 Span Concentration button and after pressing the Calibrate button, the Point 1 Coefficient value is updated.
- *Calibrate:* Calibrates point 1 coefficient.

Manual O₂ Calibration

The Manual O₂ Calibration screen allows the O₂ span coefficients to be changed manually while sampling span gas of known concentration. This button appears if the O₂ Sensor option is selected in the Configuration screen.

Home Screen>Calibration>Advanced Calibration>Manual Calibration (single range mode)




The Manual O₂ Calibration screen contains the following information:

- *Adjust O₂ Span Coefficient*: Allows the user to manually adjust the O₂ span coefficient.
- *Reset O₂ Coefficient to 1.000*: Resets coefficient.

Adjust O₂ Span Coefficient

The Adjust O₂ Span Coefficient screen is used to manually adjust the O₂ span coefficient.

Home Screen>Calibration>Advanced>Manual Calibration>Adjust O₂ Span Coefficient




The Adjust O₂ Span Coefficient menu contains the following information:

- *Adjust O₂ Span Coefficient*: User manually adjusts span coefficient.
- *Adjusted Concentration*: Read only. Shows adjusted O₂ concentration based on adjusted O₂ span coefficient.
- *Calibrate*: Calibrates span coefficient by saving the newly adjusted O₂ span coefficient.


2-Point O₂ Calibration

The 2-Point O₂ Calibration screen is used to calibrate the O₂ sensor using 2 different gas concentrations. Both points need to be calibrated for a successful calibration. It is suggested that the two O₂ concentrations used for this calibration be 0% and 20.9%. This button appears if the O₂ Sensor option is selected in the Configuration screen.

Home Screen>Calibration>Advanced Calibration>2-Point O₂ Calibration>



Home Screen>Calibration>Advanced Calibration>2-Point O₂ Calibration>Continue to 2-Point O₂ Calibration




The 2-Point O₂ Calibration screen contains the following information:

- *2-Point O₂ Calibration Point 1*: First cal point used in the 2 point O₂ calibration. Defaults to 0.000%.
- *2-Point O₂ Calibration Point 2*: Second cal point used in the 2 point O₂ calibration. Defaults to 20.900%.

Point 1–2 The Point 1 screen allows the user to view and set the selected calibration point. The point 2 screen functions the same way. Therefore, the following example of point 1 screen applies to point 2 as well.

Home Screen>Calibration>Advanced Calibration>2-Point O₂ Calibration>Continue to 2-Point O₂ Calibration>2-Point O₂ Calibration Point 1



The 2-Point O₂ Calibration Point 1 screen contains the following information:

- *Edit O₂ Span Concentration:* User enters O₂ span concentration.
- *Current O₂ Concentration:* Read only. After selecting the value on the Edit O₂ Concentration button and after pressing the Calibrate O₂ button, the Point 1 Concentration value is updated.
- *Calibrate O₂ Point 1:* Calibrates point 1 coefficient.

Note Ensure that the sensor has been sampling the gas for at least 1 minute before pressing the Calibrate O₂ Point 1 button. ▲

Calibration History

The Calibration History screen shows the log of calibrations and calibration checks performed.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Calibration>Advanced Calibration>Calibration History

Note Pressing the Calibration History button responds with Retrieving calibration log data, it may take a few seconds... ▲


| Time Stamp | Event | Result | Target | Units |
|---------------------|----------------|---------|---------|-------|
| 09/07/2017 16:04:02 | Det Gain Entry | 182 | n/a | - |
| 08/16/2017 16:18:03 | Low Span Check | Fail | 21.2508 | ppm |
| 08/16/2017 16:16:03 | Bkg Cal | 9.18419 | 0 | ppm |
| 08/16/2017 15:16:03 | Bkg Cal | 9.17902 | 0 | ppm |
| 08/16/2017 14:18:04 | Low Span Check | Fail | 21.2508 | ppm |
| 08/16/2017 14:16:03 | Bkg Cal | 9.18655 | 0 | ppm |
| 08/16/2017 14:07:44 | Bkg Entry | 20 | 0 | ppm |
| 08/16/2017 13:16:03 | Bkg Cal | Fail | 0 | ppm |
| 08/16/2017 12:16:03 | Bkg Cal | 54.2743 | 0 | ppm |
| 08/16/2017 11:18:03 | Low Span Check | Fail | 127.505 | ppm |

The Calibration History screen contains the following information:

- *Time Stamp*: Time of calibration or calibration check.
- *Event*: Lists the type of calibration event.
- *Result*: Concentration result.
- *Target*: Concentration setpoint value.
- *Units*: Displays units for each item.
- *Average Time*: Averaging time used during the calibration or calibration check.

Data The Data screen is used to view and record concentrations and instrument data. Users can view both tabular data and graphed data.

Home Screen>Data



The Data screen contains the following information:

- *View Data Log (Last Hour)*: User views last hour of historical data. Table shows most recent data on top.
- *View Data Log (Last 24 Hours)*: User views last 24-hour of historical data. Table shows most recent data on top.
- *View Data Log (User Defined Time)*: User selects the start and end time for viewing the data. Table shows most recent data on top.
- *Advanced Data Setup*: Allows the user to set up the parameters of how the data is stored and streamed.

View Data Log (Last Hour)

The View Data Log (Last Hour) screen allows the user to instantly view the last hour worth of data in real time.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Data>View Data Log (Last Hour)

Note Pressing the View Data Log (Last Hour) responds with Retrieving user log data, it may take a few seconds... ▲

| Time Stamp | Concentration (ppb or ug/m3) | Bench Pressure (mmHg) | High Concentration (ppb or ug/m3) | Instrument Temperature (degC) | Sample (L/n) |
|---------------------|------------------------------|-----------------------|-----------------------------------|-------------------------------|--------------|
| | Graph | Graph | Graph | Graph | Graph |
| 09/22/2017 08:21:00 | 241.241 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:20:00 | 237.37 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:19:00 | 236.884 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:18:00 | 234.178 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:17:00 | 228.876 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:16:00 | 229.929 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:15:00 | 231.378 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:14:00 | 231.6 | 0 | 0 | 0 | 0 |

The View Data Log (Last Hour) screen contains the following options:

- *Graph*: Displays data graph for the column selected. The graph time axis is defined by the data set in the table.



View Data Log (Last 24 Hours)

The View Data Log (Last 24 Hours) screen allows the user to instantly view the last 24 hours worth of data in real time.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.


Home Screen>Data>View Data Log (Last 24 Hours)

Note Pressing the View Data Log (Last 24 Hours) responds with Retrieving user log data, it may take a few seconds... ▲

| Time Stamp | Concentration (ppb or ug/m3) | Bench Pressure (mmHg) | High Concentration (ppb or ug/m3) | Instrument Temperature (degC) | Sampl (L/m) |
|---------------------|------------------------------|-----------------------|-----------------------------------|-------------------------------|-------------|
| | Graph | Graph | Graph | Graph | Graph |
| 09/22/2017 08:21:00 | 241.241 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:20:00 | 237.37 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:19:00 | 236.884 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:18:00 | 234.178 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:17:00 | 228.876 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:16:00 | 229.929 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:15:00 | 231.378 | 0 | 0 | 0 | 0 |
| 09/22/2017 08:14:00 | 231.6 | 0 | 0 | 0 | 0 |

The View Data Log (Last 24 Hours) screen contains the following options:


- *Graph*: Displays data graph for the column selected. The graph time axis is defined by the data set in the table.




View Data Log (User Defined Time)

The View Data (User Defined Time) screen is used to specify the start and end time for viewing the data logging table.

Home Screen>Data>View Data Log (User Defined Time)



Home Screen>Data>View Data Log (User Defined Time)>Save Data Logging Start Time



The View Data Log (User Defined Time) screen contains the following information:

- *Month*: Sets month of data logging start time.
- *Day*: Sets day of data logging start time.
- *Year*: Sets year of data logging start time.
- *Hours*: Sets hours of data logging start time.
- *Minutes*: Sets minutes of data logging start time.
- *Save Data Logging Start Time*: Pressing this button saves the start time and follows directly to the end time selection for the data logging screen.

The View Data Log (User Defined Time) End Time screen contains the following information:

- *Month*: Sets month of data logging end time.
- *Day*: Sets day of data logging end time.
- *Year*: Sets year of data logging end time.
- *Hours*: Sets hour of data logging end time.
- *Minutes*: Sets minute of data logging end time.
- *Save Data Logging End Time*: Pressing the Save Data Logging End Time button saves the end time and follows directly to the data logging table.


Note End time should not be greater than 1 year from start time . ▲

Note The datalogging table is limited to 10,000 points. ▲

Advanced Data Setup

The Advanced Data Setup screen allows the user to select variables and set up parameters for data logging and streaming data.

Home Screen>Data>Advanced Data Setup



The Advanced Data Setup screen contains the following information:

- *Data Logging Setup*: User selects the parameters for collecting logged data.
- *Streaming Data Setup*: User selects the parameters for streaming data to a computer in real time.

Data Logging Setup

The Data Logging Setup screen allows the user to select data to be stored and how it is stored.

Home Screen>Data>Advanced>Data Logging Setup



The Data Logging Setup screen contains the following information:


- *Select Data Logging Variables:* User selects instrument variables to log. See “Table 3-1” for data logging variables list.
- *Period:* User selects how often data is collected by setting the duration between logged data.
- *Data Treatment:* Toggles between Average, Current, Minimum and Maximum. When set to average, the average value during the period will be recorded. When set to current, the latest data will be recorded. When set to minimum or maximum, the minimum or maximum value during the period will be recorded.
- *Erase Data Log Records:* Allows the user to erase all values in the data log and updates the data logging table.

Select Data Logging Variables

The Select Data Logging Variables screen allows the user to select which variables to store. Note: The Data logging and Streaming variable lists are **exclusive** from each other but contain the same variable selections.

Use the ▲ and ▼ buttons to scroll through the variables. Select the variables to log by pressing the corresponding cells. Next, press the **Commit Changes** button to save selections. Yellow buttons indicate that the variable is selected.

Home Screen>Data>Advanced>Data Logging Setup>Select Data Logging Variables



The following table contains the variables that can be selected for data logging:

Table 3–1. Data Logging Variables

| Description |
|---|
| Concentration (ppb or $\mu\text{g}/\text{m}^3$) |
| High Concentration (ppb or $\mu\text{g}/\text{m}^3$) |
| corrected Concentration (ppb or $\mu\text{g}/\text{m}^3$) |
| corrected High Concentration (ppb or $\mu\text{g}/\text{m}^3$) |
| Bench Pressure (mmHg) |
| Instrument Temperature (degC) |
| Sample Flow (L/min) |
| Averaging Time (sec) |
| High Averaging Time (sec) |
| Concentration Alarm |
| Pressure Alarm |
| Flow Alarm |

Operation
Data

| |
|---|
| Instrument Temperature Alarm |
| Auto Zero Alarm |
| Auto Span Alarm |
| S/R |
| High S/R |
| Concentration Background (ppb or µg/m3) |
| General Alarm |
| Alerts |
| Instrument Error |
| Low Dynamic Filter Status |
| High Dynamic Filter Status |
| Dilution Ratio |
| Bench Temperature (degC) |
| Sample Intensity |
| Reference Intensity |
| Wheel Speed (RPM) |
| External Alarm 1 |
| External Alarm 2 |
| External Alarm 3 |
| Analog Input 1 |
| Analog Input 2 |
| Analog Input 3 |
| Analog Input 4 |
| Analog Alarms |
| PSB Alarms |
| O2 Alarms |
| O2 % |
| O2 Conc Alarm |
| O2 Averaging Time (sec) |
| O2 Temperature |

Streaming Data Setup

The Streaming Data Setup menu allows the user to stream data to a computer.

Home Screen>Data>Advanced>Streaming Data Setup



The Streaming Data Setup screen contains the following information:


- *Select Streaming Variables*: User selects which variables to stream. See [Table 3–2](#) for streaming variables list.
- *Period*: Sets the time between streamed data.
- *Show Labels*: Toggles on/off. When on, shows variable labels to the left of the variable values.
- *Show Timestamp*: Toggles on/off. When on, shows timestamp at the beginning of each row of data.

Select Streaming Variables

The Select Streaming Variables screen allows the user to select which variables to track. Note: The Data logging and Streaming variable lists are **exclusive** from each other but contain the same variable selections.

Use the ▲ and ▼ buttons to scroll through the variables. Select the variables to log by pressing the corresponding cells. Next, press the **Commit Changes** button to save selections. Yellow buttons indicate that the variable is selected.

Home Screen>Data>Advanced>Streaming Data Setup>Select Streaming Variables



The following table contains the variables that can be selected for streaming data:

Table 3–2. Streaming Data Variables

| Description |
|---|
| Concentration (ppb or µg/m3) |
| High Concentration (ppb or µg/m3) |
| corrected Concentration (ppb or µg/m3) |
| corrected High Concentration (ppb or µg/m3) |
| Bench Pressure (mmHg) |
| Instrument Temperature (degC) |
| Sample Flow (L/min) |
| Averaging Time (sec) |
| High Averaging Time (sec) |
| Concentration Alarm |
| Pressure Alarm |

| |
|---|
| Flow Alarm |
| Instrument Temperature Alarm |
| Auto Zero Alarm |
| Auto Span Alarm |
| S/R |
| High S/R |
| Concentration Background (ppb or $\mu\text{g}/\text{m}^3$) |
| General Alarm |
| Alerts |
| Instrument Error |
| Low Dynamic Filter Status |
| High Dynamic Filter Status |
| Dilution Ratio |
| Bench Temperature (degC) |
| Sample Intensity |
| Reference Intensity |
| Wheel Speed (RPM) |
| External Alarm 1 |
| External Alarm 2 |
| External Alarm 3 |
| Analog Input 1 |
| Analog Input 2 |
| Analog Input 3 |
| Analog Input 4 |
| Analog Alarms |
| PSB Alarms |
| O ₂ Alarms |
| O ₂ % |
| O ₂ Conc Alarm |
| O ₂ Averaging Time (sec) |
| O ₂ Temperature |

Settings

The Settings Menu allows the user to view the instrument alarms, set up user preferences, communicate with outside devices and computers, download files to USB, and sets security protocol.

Home Screen>Settings





The Settings screen contains the following information:

- *Health Check:* View instrument status and alarms, predictive diagnostics, preventive maintenance alerts, maintenance history, email health check report files, and contact Thermo Fisher Scientific technical support.
- *Measurement Settings:* Allows the user to setup user preferences as related to the concentration readings.
- *Communications:* Allows the user to communicate with outside devices.
- *Instrument Setting:* Allows the user to setup alarm setpoints and user preferences.
- *Configuration:* User selects which options to enable.
- *Security Access Levels:* User selects security protocol. User can also change security passwords.
- *USB Drive:* User can update instrument firmware, download data, and change USB password.
- *User Contact Information:* User sets up their contact information.
- *Update Bootloader:* Used to update bootloader when an update to the bootloader is available.


Health Check

The Health Check screen is used for viewing instrument status and alarms, predictive diagnostics, preventive maintenance schedules, maintenance history, emailing files describing the health/status of the instrument, and viewing the instrument's firmware version.

Note  This symbol denotes there is an active alarm in the module. ▲

Note  This symbol denotes there is an active maintenance related warning in the module. ▲

Home Screen>Settings>Health Check




The Health Check screen contains the following information:

- *Status and Alarms:* Allows the user to view the status and alarm menus. Menus are broken down according to modules where the user can view instrument readings, setpoints and alarms.
- *Predictive Diagnostics:* Smart module diagnostics, which shows possible future issues.
- *Maintenance History:* Allows the user to set up a maintenance schedule and track maintenance history.
- *File Sharing and Support:* File sharing via email. Support through Thermo Fisher Scientific technical support.
- *Firmware Version:* Shows the instrument's firmware version.

Status and Alarms

The Status and Alarms screen provides information with respect to module alarms. In each screen, instrument readings, setpoints, and low/high alarm values are displayed. If applicable, setpoints and alarms are also settable from the Settings>Instrument Settings screen.

Note  This symbol denotes there is an active alarm in the module. ▲

Home Screen>Settings>Health Check>Status and Alarms



The Status and Alarms menu contains the following information:

- *Concentration*: Displays CO concentrations and alarms.
- *NDIR Bench*: Displays bench module alarms and faults.
- *O₂ Sensor*: Displays O₂ concentrations, sensor alarms and faults (if enabled).
- *Flow and Pressure*: Displays flow and pressure alarms and faults.
- *Peripherals Support*: Displays peripherals support alarms and faults.
- *Valve and Pump Resets*: User can reset valve and pump power.
- *Analog Input/Output*: Displays analog input/output alarms and faults.
- *Digital Input/Output*: Displays digital input/output alarms and faults.
- *Serial Numbers*: Displays all the serial numbers for the instrument.

Concentration

The Concentration screen provides status and alarms for CO concentration, background cal/checks, and span cal/checks. If an item being monitored goes outside the lower or higher alarm limit, an alarm is activated.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Settings>Health Check>Status and Alarms>Concentration

| Concentration | Value | Low Alarm | High Alarm | Span Conc | Units |
|-------------------|-------|-----------|------------|-----------|-------|
| CO | 0.498 | 0.000 | 0.000 | | ppm |
| Bkg Check Offset | 0.000 | -- | 10.000 | | ppm |
| Span Check Offset | 0.000 | -- | 10.000 | 0.000 | ppm |
| | | | | | |
| | | | | | |
| | | | | | |

The Concentration screen contains the following information:

- Across:
 - *Concentration*: This column lists items associated with the CO and concentrations.
 - *Value*: Displays the current value for each item.
 - *Low Alarm*: Displays low alarm status for each item.
 - *High Alarm*: Displays high alarm status for each item.
 - *Span Conc*: Span concentration used in the span calibration or span check.
 - *Units*: Displays units for each item.
- Down:
 - *CO*: CO concentration.
 - *Bkg Check Offset*: Displays concentration based on the last attempted background calibration. High alarm shows user defined limit for acceptable background check offset.

- *Span Check Offset*: Displays concentration based on the last attempted span calibration. High alarm shows user defined limit for acceptable span check offset (compared to the span concentration value). Span concentration shows span setpoint.

Note If both the low alarm and high alarms are set to zero, then no alarm will show. ▲

NDIR Bench The NDIR Bench screen provides status and alarms related to the bench module. If an item being monitored goes outside the lower or higher alarm limit, an alarm is activated.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Settings>Health Check>Status and Alarms>NDIR Bench

| NDIR Bench | Value | Low Alarm | High Alarm | Units |
|------------------------|---------|-----------|------------|-------|
| S/R | 1.15278 | | | |
| Sample Intensity | 217363 | | | Hz |
| Reference Intensity | 188537 | | | Hz |
| Bench Pressure | 752.559 | | | mmHg |
| Flow | 1.195 | | | L/min |
| Instrument Temperature | 36.8 | | | °C |

The NDIR Bench screen contains the following information:

- Across:
 - *NDIR Bench*: This column lists items associated with the NDIR bench module.
 - *Value*: Displays the current value for each item.
 - *Low Alarm*: Displays low alarm status for each item.
 - *High Alarm*: Displays high alarm status for each item.
 - *Units*: Displays units for each item.
- Down:
 - *S/R*: Displays the current sample/reference reading.
 - *Sample Intensity*: Displays the current sample intensity reading.
 - *Reference Intensity*: Displays the current reference intensity reading.
 - *Bench Pressure*: Displays the current bench pressure reading.
 - *Flow*: Displays the current sample flow reading.
 - *Instrument Temperature*: Displays the current instrument temperature reading.


- *Bench Temperature*: Displays the current bench temperature reading. User can adjust low and high alarm limits.
- *Bench Temperature too Low*: Displays OK/Fail for bench temperature too low.
- *Bench Temperature too High*: Displays OK/Fail for bench temperature too high.
- *Motor Speed too Low*: Displays OK/Fail for motor speed too low.
- *Motor Speed too High*: Displays OK/Fail for motor speed too high.
- *IR Source Current too Low*: Displays OK/Fail for IR source current too low.
- *IR Source Current too High*: Displays OK/Fail for IR source current too high.
- *IR Detector Bias too Low*: Displays OK/Fail for IR detector bias too low.
- *IR Detector Bias too High*: Displays OK/Fail for IR detector bias too high.
- *Bench Thermistor Open*: Displays OK/Fail for bench thermistor open.
- *Bench Thermistor Short*: Displays OK/Fail for bench thermistor short.
- *Module Thermistor Open*: Displays OK/Fail for module thermistor open.
- *Module Thermistor Short*: Displays OK/Fail for module thermistor short.
- *Board Communication*: Displays OK/Fail for board communication status.
- *Power Supply*: Displays OK/Fail of power supplies. Power supply goes red if any voltages are outside their limits. No voltage rows ever get highlighted.
 - *3.3V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.
 - *5.0V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.
 - *15V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.
 - *24V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.

- *-15V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.
- *Bias Voltage*: Displays current voltage readings. Alarm limits are not changeable.

O₂ Sensor The O₂ Sensor screen provides status and alarms related to the O₂ Sensor. If an item being monitored goes outside the lower or higher alarm limit, an alarm is activated.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Settings>Health Check>Status and Alarms>O₂ Sensor



| O ₂ Sensor | Value | Low Alarm | High Alarm | Units |
|---------------------------|-------|-----------|------------|-------|
| Concentration | 0.000 | 3.000 | 25.000 | % |
| Temperature | 0.0 | | | °C |
| Temperature Open | OK | | | |
| Temperature Short | OK | | | |
| Sensor Element Function | OK | | | |
| Outside Operational Spec. | OK | | | |

The O₂ Sensor screen contains the following information:

- Across:
 - *O₂ Sensor*: This column lists items associated with the O₂ sensor.
 - *Value*: Displays the current value for each item.
 - *Low Alarm*: Displays low alarm status for each item.
 - *High Alarm*: Displays high alarm status for each item.
 - *Units*: Displays units for each item.
- Down:
 - *Concentration*: Displays the current O₂ sensor concentration reading. User can adjust low and high alarm limits.
 - *Temperature*: Displays the current module temperature reading.
 - *Temperature Open*: Displays OK/Fail for temperature open.
 - *Temperature Short*: Displays OK/Fail for temperature short.
 - *Sensor Element Function*: Displays OK/Fail for sensor element function.
 - *Outside Operational Spec.*: Displays OK/Fail for outside operational specification.


- *Photodiode Current Too Low*: Displays OK/Fail for Photodiode Current Too Low.
- *Sensor Detected*: Displays OK/Fail for sensor detected.
- *Sensor Communication*: Displays OK/Fail for sensor communication.
- *Valid Calibration*: Displays OK/Fail for valid calibration.
- *Board Communication*: Displays OK/Fail for board communication status.
- *Power Supply*: Displays OK/Fail of power supplies. Power supply goes red if any voltages are outside their limits. No voltage rows ever get highlighted.
 - *2.5V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.
 - *3.3V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.
 - *5.0V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.
 - *24V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.

Flow and Pressure

The Flow and Pressure screen provides status and alarms related to the flow and pressure module. If an item being monitored goes outside the lower or higher alarm limit, an alarm is activated.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Settings>Health Check>Status and Alarms>Flow and Pressure



| Flow and Pressure | Value | Low Alarm | High Alarm | Units |
|------------------------|---------|-----------|------------|-------|
| Flow | 1.192 | 0.350 | 1.500 | L/min |
| Bench Pressure | 751.319 | 600.000 | 800.000 | mmHg |
| Pump Pressure | 333.37 | | | mmHg |
| Instrument Temperature | 36.5 | 8.0 | 47.0 | °C |
| Board Communication | OK | | | |
| Power Supply | OK | | | |

The Flow and Pressure screen contains the following information:

- Across:
 - *Flow and Pressure*: This column lists items associated with the flow and pressure module.
 - *Value*: Displays the current value for each item.
 - *Low Alarm*: Displays low alarm status for each item.
 - *High Alarm*: Displays high alarm status for each item.
 - *Units*: Displays units for each item.
- Down:
 - *Flow*: Displays the current sample flow reading. User can adjust low and high alarm limits.
 - *Bench Pressure*: Displays the current bench pressure reading. User can adjust low and high alarm limits.
 - *Pump Pressure*: Displays the current pump pressure reading.
 - *Instrument Temperature*: Displays the current instrument temperature reading. User can adjust low and high alarm limits.

- *Board Communication:* Displays OK/Fail for board communication status.
- *Power Supply:* Displays OK/Fail of power supplies. Power supply goes red if any voltages are outside their limits. No voltage rows ever get highlighted.
 - *2.5V Diagnostic:* Displays current voltage readings. Alarm limits are not changeable.
 - *3.3V Diagnostic:* Displays current voltage readings. Alarm limits are not changeable.
 - *5.0V Diagnostic:* Displays current voltage readings. Alarm limits are not changeable.
 - *24V Diagnostic:* Displays current voltage readings. Alarm limits are not changeable.

Peripherals Support

The Peripherals Support screen provides status and alarms related to the peripherals module. If an item being monitored goes outside the lower or higher alarm limit, an alarm is activated.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Settings>Health Check>Status and Alarms>Peripherals Support



| Peripherals Support | Value | Low Alarm | High Alarm | Units |
|---------------------|-------|-----------|------------|-------|
| Module Temperature | 36.7 | | | °C |
| Sample Valve | 0.000 | | | mA |
| Zero Valve | 1.289 | | | mA |
| Span Valve | 0.000 | | | mA |
| Instrument Error | OK | | | |
| Board Communication | OK | | | |


The Peripherals Support screen contains the following information:

- Across:
 - *Peripherals Support*: This column lists items associated with the peripherals support module.
 - *Value*: Displays the current value for each item.
 - *Low Alarm*: Displays low alarm status for each item.
 - *High Alarm*: Displays high alarm status for each item.
 - *Units*: Displays units for each item.
- Down:
 - *Module Temperature*: Displays the current module temperature of the module.
 - *Sample Valve*: Displays whether or not the sample valve is activated.
 - *Zero Valve*: Displays whether or not the zero valve is activated.
 - *Span Valve*: Displays whether or not the span valve is activated.
 - *Instrument Error*: Displays OK/Fail for PCP, datalogging, streaming, serial server, and Modbus protocols.

- *Board Communication:* Displays OK/Fail for board communication status.
- *Power Supply:* Displays OK/Fail of power supplies. Power supply goes red if any voltages are outside their limits. No voltage rows ever get highlighted.
 - *2.5V Diagnostic:* Displays current voltage readings. Alarm limits are not changeable.
 - *3.3V Diagnostic:* Displays current voltage readings. Alarm limits are not changeable.
 - *5.0V Diagnostic:* Displays current voltage readings. Alarm limits are not changeable.
 - *24V Diagnostic:* Displays current voltage readings. Alarm limits are not changeable.
 - *5.0V Step Board:* Displays OK/Fail.
 - *24V Step Board:* Displays OK/Fail.

Valve and Pump Resets

The Valve and Pump Resets screen allows the user to reset a valve or pump after a failure due to excessive amperage.

Note  This symbol denotes that the device needs to be reset. ▲

Note Resetting one valve will reset all valves. ▲

Home Screen>Settings>Health Check>Status and Alarms>Valve and Pump Resets



The Valve and Pump Resets screen contains the following information:

- *Sample Valve Reset*: Resets sample valve.
- *Zero Valve Reset*: Resets zero valve.
- *Span Valve Reset*: Resets span valve.
- *Pump Reset*: Resets pump.

Analog I/O The Analog I/O screen provides status and alarms related to the analog input/output module. If an item being monitored goes outside the lower or higher alarm limit, an alarm is activated.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Settings>Health Check>Status and Alarms>Analog I/O

| Analog IO | Value | Low Alarm | High Alarm | Units |
|--------------------------|-------|-----------|------------|-------|
| Voltage Output Channel 1 | OK | | | |
| Voltage Output Channel 2 | OK | | | |
| Voltage Output Channel 3 | OK | | | |
| Voltage Output Channel 4 | OK | | | |
| Voltage Output Channel 5 | OK | | | |
| Voltage Output Channel 6 | OK | | | |

The Analog I/O screen contains the following information:

- Across:
 - *Analog IO*: This column lists items associated with the analog I/O.
 - *Value*: Displays the current value for each item.
 - *Low Alarm*: Displays low alarm status for each item.
 - *High Alarm*: Displays high alarm status for each item.
 - *Units*: Displays units for each item.
- Down:
 - *Voltage Output Channel 1–6*: Displays real-time voltage output for each channel.
 - *Current Output Channel 1–6*: Displays real-time current output for each channel.
 - *Chip Temperatures*: Displays OK/Fail for chip temperatures.
 - *Chip 1–3 Communication*: Displays OK/Fail for each chip communication.
 - *Test Mode*: Displays test mode on or off.

- *Board Communication*: Displays OK/Fail for board communication status.
- *Power Supply*: Displays OK/Fail of power supplies. Power supply goes red if any voltages are outside their limits. No voltage rows ever get highlighted.
 - *3.3V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.
 - *5.0V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.
 - *5.0V Ref Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.
 - *15V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.
 - *-15V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.

Digital I/O The Digital I/O screen provides status and alarms related to the digital input/output module. If an item being monitored goes outside the lower or higher alarm limit, an alarm is activated.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Settings>Health Check>Status and Alarms>Digital I/O

| Digital IO | Value | Reset | Low Alarm | High Alarm | Units |
|------------|-------|-------|-----------|------------|-------|
| Solenoid 1 | 0.0 | Reset | OK | OK | mA |
| Solenoid 2 | 0.0 | Reset | OK | OK | mA |
| Solenoid 3 | 0.0 | Reset | OK | OK | mA |
| Solenoid 4 | 0.0 | Reset | OK | OK | mA |
| Solenoid 5 | 0.0 | Reset | OK | OK | mA |
| Solenoid 6 | 0.0 | Reset | OK | OK | mA |

The Digital I/O screen contains the following information:

- Across:
 - *Digital IO*: This column lists items associated with the digital I/O.
 - *Value*: Displays the current value for each item.
 - *Reset*: Resets item.
 - *Low Alarm*: Displays low alarm status for each item.
 - *High Alarm*: Displays high alarm status for each item.
 - *Units*: Displays units for each item.
- Down:
 - *Solenoid 1–8*: Displays whether or not the solenoid is activated by showing the current in mA.
 - *External Alarm 1–3*: Displays OK/Fail for external alarms.
 - *Relay Test Mode*: Displays relay test mode on or off.
 - *Solenoid Test Mode*: Displays solenoid test mode on or off.
 - *Board Communication*: Displays OK/Fail for communication status.

- *Power Supply*: Displays OK/Fail of power supplies. Power supply goes red if any voltages are outside their limits. No voltage rows ever get highlighted.
- *3.3V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.
- *5.0V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.
- *24V Diagnostic*: Displays current voltage readings. Alarm limits are not changeable.

Serial Numbers The Serial Numbers screen displays the serial number for each module.

Home Screen>Settings>Health Check>Status and Alarms>Serial Numbers




The Serial Numbers screen contains the following information:

- *Instrument*: Instrument serial number.
- *NDIR Bench*: NDIR bench serial number.
- *O₂ Sensor Board*: O₂ sensor board serial number.
- *O₂ Sensor*: O₂ sensor serial number.
- *Flow and Pressure*: Flow and pressure serial number.
- *Peripherals Support*: Peripherals support serial number.
- *Analog I/O*: Analog I/O serial number.
- *Digital I/O*: Digital I/O serial number.

Predictive Diagnostics

The Predictive Diagnostics screen is a feature for instruments to anticipate maintenance needs, reduce downtime, and reduce troubleshooting time. If button is greyed out, no maintenance is needed. If button is blue, maintenance is suggested.

Note  This symbol denotes there is an active maintenance related warning in the module. ▲


Home Screen>Settings>Health Check>Predictive Diagnostics



The Predictive Diagnostics screen contains the following information:

- Filter Wheel
- Sample Pump
- Capillary
- Flow Path
- IR Source
- Sample Valve
- Zero Valve
- Span Valve

Maintenance The Maintenance screen reminds the user when certain instrument components need to be serviced/replaced.

Note  This symbol denotes there is an active maintenance alarm in the module. ▲

Home Screen>Settings>Health Check>Maintenance



The Maintenance screen contains the following information:


- *Preventive Maintenance*: Shows suggested service interval and time left for component replacement.
- *Change Part*: User logs component fix.
- *Maintenance History*: Shows the log of all recorded component fixes.
- *Advanced Maintenance*: Resets all preventive maintenance items.

Preventive Maintenance

The Preventive Maintenance screen reminds the user when certain instrument components need to be serviced/replaced. When the “Months Left” has decreased to 1, the row is highlighted yellow. If the “Months Left” is 0 or less, the row is highlighted red and the maintenance icon (gears) will appear in the status bar located at the bottom of the screen.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Settings>Health Check>Maintenance>Preventive Maintenance



| Component | Interval in Months | Months Left | Reset | Alert |
|----------------------|--------------------|-------------|-------|---------|
| Optical Bench Module | 48 | 47 | Reset | Enabled |
| IR Source | 12 | 11 | Reset | Enabled |
| Filter Wheel | 48 | 47 | Reset | Enabled |
| Detector | 48 | 47 | Reset | Enabled |
| Chopper Motor | 48 | 47 | Reset | Enabled |
| Optical Switch | 48 | 47 | Reset | Enabled |


The Preventive Maintenance screen contains the following information:

- Across:
 - *Component*: Device to be routinely serviced or replaced.
 - *Interval in Months*: Expected period of time before a component needs to be checked and/or serviced. User settable.
 - *Months Left*: Count down timer in months. Remaining time since the beginning of the service interval. When the value is 1 or less, the row will be highlighted and it is suggested that the component should be checked and/or serviced.
 - *Reset*: Once the component is serviced/replaced, the user presses the Reset button and the “Months Left” value resets to the “Service Interval in Months” value.
 - *Alert*: Allows the user to opt out of receiving preventive maintenance alerts. Displays Enabled/Disabled for each component.

- Down:
 - *Optical Bench Module*: Service interval for optical bench module components.
 - *IR Source*: Service interval for IR source.
 - *Filter Wheel*: Service interval for filter wheel.
 - *Detector*: Service interval for detector.
 - *Chopper Motor*: Service interval for chopper motor.
 - *Optical Switch*: Service interval for optical switch.
 - *Flow System*: Service interval for the flow system components.
 - *Capillaries*: Service interval for capillaries.
 - *Pump*: Service interval for pump.
 - *DC Power Supply*: Service interval for DC power supply.
 - *Fan Filter*: Service interval for fan filter.
 - *System Components*: Service interval for system components.
 - *Purafil*: Service interval for purafil.
 - *Charcoal*: Service interval for charcoal.
 - *Dri-Rite*: Service interval for dri-rite.

Change Part The Change Part screen allows the user to enter the component being serviced and the type of fix. Pressing commit will update the preventive maintenance table and predictive diagnostics screen when applicable.

Home Screen>Settings>Health Check>Maintenance>Change Part



The Change Part screen contains the following information:

- *Select Part:* User selects part to service from the selection table.
- *Fix:* User chooses from new, rebuilt, cleaned, and unknown.
- *Comment:* User can write a brief comment, which will be saved to the preventive maintenance history table.
- *Commit:* User commits and saves the selected part fix.

Maintenance History

The Maintenance History screen allows the user to view when components were replaced, rebuilt, or cleaned. When a user changes a part in the change part screen, a new row will be automatically created at the top in the maintenance history table.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Settings>Health Check>Maintenance>Maintenance History

Note Pressing the Maintenance History button responds with Retrieving maintenance history data, it may take a few seconds... ▲

| Part | Fix | Date | Service Months | Comments |
|----------------|---------|------------|----------------|-----------|
| All | Unknown | 09/07/2017 | 0 | Reset All |
| All | Unknown | 08/05/2017 | 1 | Reset All |
| IR Source | New | 08/05/2017 | 1 | ABC |
| All | Unknown | 07/31/2017 | 0 | Reset All |
| IR Source | Rebuilt | 07/31/2017 | 0 | |
| Optical Switch | Rebuilt | 07/31/2017 | 1 | |
| Chopper Motor | Rebuilt | 07/31/2017 | 1 | |
| Detector | Rebuilt | 07/31/2017 | 1 | |
| Filter Wheel | Rebuilt | 07/31/2017 | 1 | |
| IR Source | Rebuilt | 07/31/2017 | 0 | |

The Maintenance History screen contains the following information:

- *Part*: Component that has been fixed.
- *Fix*: The type of maintenance.
- *Date*: Shows date/time when service was logged.
- *Service Months*: Amount of time in months since last service.
- *Comments*: Shows comments entered from time of change.

Advanced Maintenance

The Advanced Maintenance screen resets all preventive maintenance items.

Home Screen>Settings>Health Check>Maintenance>Advanced Maintenance




File Sharing and Support

The File Sharing and Support screen allows the user to download health check reports, email send health check report files to Thermo Fisher Scientific technical support or user emails, enable iQ360 feature, and request a field service visit. The Health Check Report file includes: Status and Alarms, PM Alerts, Activity Log, Service Database, Cal History, and Data Log (last 24 hours).

Note To create email list, go to Settings>User Contact Information. To configure email, go to Settings>Communications>Email Server (SMTP). ▲

Home Screen>Settings>Health Check>File Sharing and Support



The File Sharing and Support screen contains the following information:

- *Download Health Check Report to USB Drive:* Sends the health check report to USB drive.
- *Email Health Check Report File to Technical Support:* Sends the health check report file to technical support and the customer email addresses via email.
- *Email Health Check Report to Personal Account:* Sends the health check report file to a personal account via email.
- *iQ360:* The iQ360 feature is a paid subscription enabling or disabling the instrument to send automated emails to technical support when an alarm or alert is triggered.
- *Request a Field Service Visit:* Sends a field service visit to technical support.

Measurement Settings

The Measurement Settings menu contains a number of submenus where instrument parameters and settings can be read and modified.

The following screens show the measurement settings in single range mode and dual or auto range mode. In the dual and auto range modes, both the “High Range” or “Low Range” buttons averaging buttons will be available.

Home Screen>Settings>Measurement Settings (single range mode)



Home Screen>Settings>Measurement Settings (dual or auto range mode)



The Measurement Setting menu contains the following information:

- *Averaging Time:* Sets the averaging time for the CO sample measurement and O₂ sample measurement (if option is enabled).
- *Range Mode Selection:* User can choose between the various range modes: single, dual, or auto. For more information, see “[Range Mode Selection](#)” on page 3-76
- *Range Setting:* Sets the concentration range for the analog outputs when in single range mode.

- *High Range Setting:* Sets the high range concentration range for the analog output when in dual or auto range mode.
- *Low Range Setting:* Sets the low range concentration for the analog output when in dual or auto range mode.
- *Gas Mode:* User can manually choose sample, zero or span mode.
- *Gas Units:* Defines the units in which CO concentration reading is expressed.
- *Dilution Ratio:* Serves as a multiplier when dilution gas is utilized.
- *Advanced Measurement Settings:* Advanced settings affecting CO readings.

Averaging Time

The Averaging Time screen allows the user to choose dynamic filtering or a manually selected (static) averaging time.

Averaging Time defines the time period (1 to 300 seconds) during which CO measurements are taken. The average concentration of the readings are calculated for that time period. The front panel display and analog outputs are updated every second if averaging time is greater than 1 second. An averaging time of 10 seconds, for example, means that the average concentration of the last 10 seconds will be displayed at each update. An averaging time of 300 seconds means that the moving average concentration of the last 300 seconds will be the output at each update. Therefore, the lower the averaging time the faster the front panel display and analog outputs respond to concentration changes. Longer averaging times are typically used to smooth output data.

Dynamic Filtering allows for data smoothing without compromising response time. Automatically changes the averaging time giving the user faster response times when conditions are rapidly changing; smoother and stable readings, when conditions aren't changing as rapidly; and as an added bonus, it better processes spikes to minimize their impact on the data. At the same time it will preserve the representative nature of the filtered data to the conditions being sampled.

Note When Dynamic Filtering is selected, the user selected Averaging Time button is disabled. ▲

Home Screen>Settings>Measurement Settings>Averaging time (single range mode and O₂ option)



Home Screen>Settings>Measurement Settings>Averaging Time (dual or auto range mode and O₂ option)



The Averaging Time screen contains the following information:

- *Dynamic Filtering:* Enables/disables dynamic filtering when in single range mode.
- *High Range Dynamic Filtering:* Enables/disables high range dynamic filtering when in dual or auto range mode.
- *Low Range Dynamic Filtering:* Enables/disables low range dynamic filtering when in dual or auto range mode.
- *Averaging Time:* Sets averaging time period in single range mode and when dynamic filtering is disabled.
- *High Range Averaging Time:* Sets high averaging time when in dual or auto range mode and when dynamic filtering is disabled.
- *Low Range Averaging Time:* Sets low averaging time when in dual or auto range mode and when dynamic filtering is disabled.
- *O₂ Averaging Time:* Sets O₂ averaging time if the O₂ sensor is enabled.

Range Mode Selection

The Range Mode Selection screen is used to switch between the various range modes: Single, Dual, and Auto Range.

Home Screen>Settings>Measurement Settings>Range Mode Selection



The Range Mode Selection screen contains the following information:

- *Single*: In single range mode, there is one range, one averaging time, and one span coefficient.
- *Dual*: In the dual range mode, there are two independent analog outputs. These are labeled simply as the “High Range” and the “Low Range”. Each channel has its own analog output range setting, averaging time, and span coefficient.

This enables the sample concentration reading to be sent to the analog outputs at two different ranges. For example, the low CO analog output can be set to output concentrations from 0 to 50 ppm and the high CO analog output set to output concentrations from 0 to 100 ppm.

In addition, when in dual or auto range mode, each CO analog output has a span coefficient so that each range can be calibrated separately. This is especially necessary if the two ranges are not close to one another. For example, the low CO range is set to 0–50 ppm and the high CO range is set to 0–10,000 ppm.

- *Auto*: The auto range mode switches the CO analog outputs between high and low range settings, depending on the concentration level. The high and low ranges are defined in the Range Settings menu.

For example, suppose the low range is set to 50 ppm and the high range is set to 100 ppm. Sample concentrations below 50 ppm are output based on low range selection and sample concentrations above 50 ppm are output based on high range selection. When the low range


is active, the range mode selection status output is at 0 volts. When the high range is active, the range mode selection status output is at half of full-scale.

When the high range is active, the concentration must drop to 95% of the low CO range for the low range to become active.

In addition, each CO range and analog output has a span coefficient so that each range can be calibrated separately. This is especially necessary if the two ranges are not close to one another. For example, the low CO range is set to 0–50 ppm and the high CO range is set to 0–10000 ppm.

Note When using auto range mode, the high and low ranges should not vary by more than 1 order of magnitude. For instance, if the low range is set to 20 ppm, then the high range should be set to no more than 200 ppm. This is because the concentration response is non-linear and it is possible that the low range readings could become unpredictable above the top of the low range, resulting in a substantial jump in concentration readings when switching between ranges.

One possible fix for this would be to perform the multipoint (3-point) calibration on both ranges and make sure that the low range high point matches or is greater than the high range low point. This will ensure that the high and low range concentration curves will overlap. If both of these methods are unacceptable due to local regulations, then the dual range mode should be used so that the range selection may be evaluated by the user to meet their regulations. ▲



Range Setting

The Range Setting button defines the concentration range of the analog outputs. For example, a CO range of 0–50 ppm restricts the analog output to concentrations between 0 and 50 ppm.

The Range Setting button shows the current CO range. The range setting button is similar for the single, dual, and auto range modes. The only difference are the words “High” or “Low” displayed to indicate which range is displayed. For more information about the dual and auto range modes, see “[Range Mode Selection](#)” on page 3-76. Pressing Range Setting, High Range Setting or Low Range Setting, brings up a numeric keypad whereby the user can select a range.

Settable ranges according to unit selection include:

| | |
|--------------------------|--|
| ppb | 50–10,000,000 ppb |
| ppm | 1–10,000 ppm |
| % | 5e-6–1 % |
| $\mu\text{g}/\text{m}^3$ | 50–10,000,000 $\mu\text{g}/\text{m}^3$ |
| mg/m^3 | 1–10,000 mg/m^3 |
| g/m^3 | 0.001–10 g/m^3 |

Gas Mode The Gas Mode screen defines what gas mode the instrument is set to.

Home Screen>Settings>Measurement Settings>Gas Mode




The Gas Mode screen contains the following information:

- *Sample*: Sets the instrument to measure sample gas.
- *Zero*: Used when calibrating the background of the instrument. When pressed, sets the instrument to zero mode.
- *Span*: Used when calibrating the span coefficient. When pressed, sets the instrument to span mode.

Gas Units The Gas Units screen defines how the CO concentration reading is expressed. The $\mu\text{g}/\text{m}^3$, mg/m^3 , and g/m^3 gas concentration modes are calculated using a standard pressure of 760 mmHg and a standard temperature of 0 °C.

Home Screen>Settings>Measurement Settings>Gas Units



The Gas Units screen contains the following information:

- *ppb*: parts per billion.
- *ppm*: parts per million.
- %: percent.
- $\mu\text{g}/\text{m}^3$: micrograms per meter cubed.
- mg/m^3 : milligrams per meter cubed.
- g/m^3 : grams per meter cubed.

Advanced Measurement Settings

The Advanced Measurement Settings screen allows the user to calibrate the optical bench and set other advanced settings.

Home Screen>Settings>Measurement Settings>Advanced Measurement Settings



The Advanced Measurements Settings menu contains the following information:


- *Optical Bench Settings*: User sets the detector gain and S/R initial value. This can be done manually or automatically.
- *Compensation*: Allows the user to compensate for changes in temperature, pressure, and oxygen concentration (if enabled).
- *Pressure Calibration*: Calibrates pressure.

Optical Bench Settings

The Optical Bench Settings screen allows the user to manually or automatically set the detector gain and initial S/R (sample/reference) value. The S/R value should be calibrated prior to other instrument calibrations. For more information, see Chapter 4, “Calibration”.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Settings>Measurement Settings>Advanced Measurement Settings>Optical Bench Settings



Home Screen>Settings>Measurement Settings>Advanced Measurement Settings>Optical Bench Settings>Continue to Detector Gain Calibration

| Description | Detector Gain | Current Sample Int. (Hz) | Current Reference Int. (Hz) |
|----------------|---------------|--------------------------|-----------------------------|
| Manual Entry | 180 | 165508 | 143807 |
| Auto Cal | Start | | |
| End Cal | Stop | | |
| Default Values | Default Gain | | |
| | | | |
| | | | |

The Detector Gain Calibration screen contains the following information:

- Across:
 - *Description*: Defines the actions the user can do.
 - *Detector Gain*: User can manually set or automatically calibrate the detector gain.

- *Current Sample Int. (Hz)*: Displays the current sample intensity in Hz.
- *Current Reference Int. (Hz)*: Displays the current reference intensity in Hz.
- Down:
 - *Manual Entry*: Shows current values. If detector gain cell is pressed, user can manually set the detector gain value.
 - *Auto Cal*: When Start is pressed, the auto-calibration process is initiated. Please allow up to 5 minutes for calibration to complete. User can stop calibration by pressing the Stop button.
 - *End Cal*: When Stop is pressed, the auto calibration is interrupted and the value does not change.
 - *Default Values*: When pressed, the default gain value is saved.

Home Screen>Settings>Measurement Settings>Advanced Measurement Settings>Optical Bench Settings>Continue to Initial S/R Calibration

| Description | Initial S/R | Current S/R | | | | |
|----------------|-------------|-------------|--|--|--|--|
| Manual Entry | 1.15009 | 1.15021 | | | | |
| Auto Cal | Start | | | | | |
| End Cal | Stop | | | | | |
| Default Values | Default S/R | | | | | |
| | | | | | | |
| | | | | | | |

The Initial S/R Calibration screen contains the following information:


- Across:
 - *Description*: Defines the actions the user can do.
 - *Initial S/R.*: Displays the initial S/R value.
 - *Current S/R.*: Displays the current S/R value.
- Down:
 - *Manual Entry*: Shows current value. If the initial S/R cell is pressed, user can manually set the initial S/R value. The instrument should be sampling zero gas when changing the S/R.

Operation
Settings

- *Auto Cal:* When Start is pressed, the auto-calibration process is initiated. Please allow up to 5 minutes for calibration to complete. User can Stop calibration by pressing the Stop button.
- *End Cal:* When pressed, the auto calibration is interrupted and the value does not change.
- *Default Values:* When pressed, the default S/R value is saved.

Compensation The Compensation screen provides compensation for any changes to the instrument's output signal due to internal instrument temperature, pressure, and oxygen variations (if O₂ sensor is installed).

Home Screen>Settings>Measurement Settings>Advanced Measurement Settings>Compensation



The Compensation screen contains the following information:

- *Temp Compensation:* Toggles temperature compensation enabled or disabled and provides compensation for any changes to the instrument's output signal due to internal instrument temperature variations. The effects of internal instrument temperature changes on the analyzer's subsystems and output have been empirically determined. This empirical data is used to compensate for any changes in temperature.
- *Pressure Compensation:* Toggles pressure compensation enabled or disabled and provides compensation for any changes to the instrument's output signal due to bench pressure variations. The effects of bench pressure changes on the analyzer's subsystems and output have been empirically determined. This empirical data is used to compensate for any change in bench pressure.
- *O₂ Correction:* Allows for the correction of the CO concentration based on O₂ readings.


O₂ Correction

When O₂ correction is enabled, the following equation is applied to the concentration value to generate a corrected value. The corrected value may be output on the analog outputs, stored in logging memory, or output as streaming data. The corrected values are not displayed on the Home Screen on the front panel, only the non-corrected values.


$$C_{comp} @ O2_{corr} = C * \left(\frac{20.9 - O2_{corr}}{20.9 - O2_{meas}} \right)$$

Abbreviations: C is the measured concentration, O_{2_{corr}} is the oxygen concentration that C is corrected to (this value is set by the user in the Source O₂ Concentration Setpoint screen and defaults to 15%). O_{2_{meas}} is the measured O₂ concentration, which is clamped at 20.8% to prevent divide-by-zero errors. C_{comp} is the corrected concentration that may be used for analog outputs or datalogging.

Home Screen>Settings>Measurement Settings>Advanced Measurement Settings>Compensation>O₂ Correction (single range mode)



Home Screen>Settings>Measurement Settings>Advanced Measurement Settings>Compensation>O₂ Correction (dual or auto range mode)



The Compensation screen contains the following information:


- *Source O₂ Concentration Setpoint*: User enters expected O₂ concentration.
- *Current O₂ Concentration*: Read only. Displays current O₂ reading.
- *Corrected CO Concentration*: Read only. Displays the corrected CO concentration when in single range mode.
- *Corrected High Range CO Concentration*: Read only. Displays the corrected high range CO concentration when in dual or auto range mode.
- *Corrected Low Range CO Concentration*: Read only. Displays the corrected low range CO concentration when in dual or auto range mode.

Pressure Calibration

The Pressure Calibration screen is used to calibrate the pressure sensor to zero, span, or factory default values.

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Settings>Measurement Settings>Advanced Measurement Settings>Pressure Calibration



| Description | Reading | Calibration | | | |
|----------------------|---------|-------------|--|--|---|
| Zero Sensor 1 | 375.7 | Start | | | ▲ |
| Atmospheric Sensor 2 | 747.2 | Start | | | ▼ |
| Zero Sensor 2 | 375.7 | Start | | | ◀ |
| Atmospheric Sensor 3 | 780.0 | Start | | | ▶ |
| Zero Sensor 3 | 200.0 | Start | | | |
| Reset all values | | Reset | | | |

The Pressure Calibration screen contains the following information:

- Across:
 - *Description*: Lists items in table.
 - *Reading*: Displays reading of each pressure sensor.
 - *Calibration*: Starts calibration or resets default values.
- Down:
 - *Sensor 1–3 Reading*: Under the column labeled Reading, current reading of each pressure sensor.
 - *Atmospheric Sensor 1–3*: Under the column labeled reading, the user enters the current atmospheric pressure in mmHg units. Under the column labelled Calibration, the user presses the Start button to calibrate the high point of the sensor.
 - *Zero Sensor 1–3*: User should put the pressure sensor under a strong vacuum. Under the column labeled reading, the user enters the pressure in mmHg. Under the column labeled Calibration, the user presses the Start button to calibrate the low point of the sensor.
 - *Reset all values*: Resets values to default.

Communications

The Communications screen allows the user to set TCP/DHCP parameters, Serial settings, Analog I/O and Digital I/O, Email Server, and Instrument ID. Buttons are grayed out if not selected in Settings>Configuration.

Home Screen>Settings>Communications



The Communications screen contains the following information:

- *Wired TCP/DHCP*: Settings for communicating with the instrument through wired Ethernet.
- *Serial RS-232/485*: Settings for communicating with the instrument through RS-232/485 protocol. This is only visible if selected in Settings>Configuration>Communications Board.
- *Analog I/O*: Settings for communicating with the instrument through analog I/O settings. This is only visible if selected in Settings>Configuration>Analog I/O.
- *Digital I/O*: Settings for communicating with the instrument through digital I/O settings. This is only visible if selected in Settings>Configuration>Digital I/O.
- *Email Server (SMTP)*: Settings for communication with email.
- *Instrument ID*: Allows the user to edit the instrument identification number (ID). The ID is used to identify the instrument when using protocols to control the instrument or collect data. It may be necessary to edit the ID number if two or more of instruments of the same model are connected to one computer. Valid instrument ID numbers are from 0 to 127. The 48iQ has a default instrument ID of 1.

Wired TCP/DHCP

The Wired TCP/DHCP screen allows the user to communicate with the instrument via wired TCP/IP settings.

Note When DHCP is enabled, the dynamic IP address is used. When DHCP is disabled, the static IP address is used. ▲

Home Screen>Settings>Communications> Wired TCP/DHCP (with DHCP enabled)



Home Screen>Settings>Communications>Wired TCP/DHCP (with DHCP disabled)



The Wired TCP/DHCP screen contains the following information:

- *DHCP*: Toggles DHCP enabled/disabled.
- *Dynamic IP Address*: Dynamic IP address of the instrument.
- *Dynamic Netmask*: Dynamic Netmask of instrument.
- *Dynamic Gateway*: Dynamic Gateway of instrument.

- *Static IP Address:* Static IP address of the instrument. This is settable when DHCP is disabled.
- *Static Netmask:* Static Netmask of instrument. This is settable when DHCP is disabled.
- *Static Gateway:* Static Gateway of instrument. This is settable when DHCP is disabled.
- *DNS Server Address:* DNS IP address of instrument. This is settable when DHCP is disabled.
- *Wired MAC Address:* Instrument MAC address.
- *Host Name:* Host name of instrument.

Serial RS-232/485

The Serial RS-232/485 screen allows the user to setup serial communication. This is only visible if selected in Settings>Configuration>**Communications Board**.

Home Screen>Settings>Communications>Serial RS-232/485




The Serial RS-232/485 screen contains the following information:

- *Protocol*: User selects Modbus or Streaming.
- *Baud Rate*: User selectable baud rates from 1200 to 115200.
- *Bits*: User selectable between 7 and 8.
- *Parity*: User selectable between None, Even, and Odd.
- *Stop Bits*: User selectable between 1 and 2.
- *RS 232/485*: User selectable between RS-232 and RS-485.

Analog I/O The Analog I/O screen allows for configuring the analog inputs/outputs. This is only visible if selected in Settings>Configuration>**Analog I/O**.

Home Screen>Settings>Communications>Analog I/O



The Analog I/O screen contains the following information:

- *Analog In*: Allows the user to view and calibrate voltage inputs from external devices.
- *Analog Out (Voltage)*: Allows the user to view voltage outputs.
- *Analog Out (Current)*: Allows the user to view current (mA) outputs.
- *Analog Out Under/Over Range Enabled/Disabled*: Allows the user to select whether or not the analog outputs are allowed to exceed the selected output range.

Digital I/O The Digital I/O screen allows for configuring the digital inputs/outputs. This is only visible if selected in Settings>Configuration>**Digital I/O**.

Home Screen>Settings>Communications>Digital I/O




The Digital I/O screen contains the following information:

- *Digital In*: Allows the user to view digital inputs from external devices.
- *Digital Out (Relays)*: Allows the user to view relay outputs.
- *Digital Out (Solenoids)*: Allows the user to view solenoid outputs.
- *Advanced Digital I/O*: Allows user to test the digital out relays and solenoids.

Email Server (SMTP) The Email Server (SMTP) screen allows the user to configure their email preferences.

Home Screen>Settings>Communications>Email Server (SMTP)




The Email Server (SMTP) screen contains the following information:

- *SMTP Server Address:* Address of the user's email server.
- *From Email Address:* The email address that goes in the From field in emails.
- *SMTP Server Port:* Server port of user's email server.
- *Email Password:* Password for SMTP server.
- *Email UserName:* User name that is authorized to send email through SMTP server.

Instrument Settings

The Instrument Settings screen allows the user to configure various instrument settings.

Home Screen>Settings>Instrument Settings




The Instrument Settings screen contains the following information:

- *Display Setup*: Sets touchscreen display settings.
- *Alarm Setpoints*: View and set all available alarm setpoints.
- *Language*: Read only.
- *Clock*: Sets date and time.
- *Pump Power*: Manually enables/disables the pump.

Display Setup The Display Setup allows the user to change the brightness of the display and choose power save option.

Home Screen>Settings>Instrument Settings>Display Setup



The Display Setup screen contains the following information:

- *Power Save*: Minutes before screen times out. Toggles enable/disable.
- *Power Save Setting*: Option whereby the user can display a black screen after a set amount of inactivity.
- *Brightness*: Sets the brightness of the display.


Alarm Set Points

The Alarm Setpoints screen allows the user to view and set all settable alarm minimum and maximum values. Alarm setpoints can also be set in Settings>Health Check>Status and Alarms screens.

Note User cannot set alarm limits outside of the acceptable range. The minimum and maximum alarm limit can also be set by pressing on the corresponding buttons located in the Settings>Health Check>Status and Alarms screen. See “[Status and Alarms](#)” on page 3-46. ▲

Use the ▲ and ▼ buttons to move up and down and the ◀ and ▶ buttons to move left and right.

Home Screen>Settings>Instrument Settings>Alarm Setpoints



| Item | Value | Low Alarm | High Alarm | Units |
|------------------------|---------|-----------|------------|-------|
| CO | 0.016 | 0.0 | 0.0 | ppm |
| Bkg Check Offset | 0.000 | -- | 10.0 | ppm |
| Span Check Offset | 0.000 | -- | 10.0 | ppm |
| Instrument Temperature | 36.6 | 8.0 | 47.0 | °C |
| Bench Pressure | 754.819 | 600.000 | 800.000 | mmHg |
| Flow | 1.197 | 0.350 | 1.500 | L/min |


The Alarm Setpoints screen contains the following information:

- Across:
 - *Item*: Lists the items that have settable alarm limits.
 - *Value*: Displays the current value for each item.
 - *Low Alarm*: User sets low alarm for item.
 - *High Alarm*: User sets high alarm for item.
 - *Units*: Units for each item (not settable).
- Down:
 - *CO*: CO concentration alarm.
 - *Bkg Check Offset*: User can set the maximum allowable background reading offset for calibration and calibration checks. This is set with the high alarm only.

- *Span Check Offset:* User can set the maximum allowable span reading offset for calibration and calibration checks. This is set with the high alarm only.
- *Instrument Temperature:* Instrument temperature alarm.
- *Bench Pressure:* Bench temperature alarm.
- *Flow:* Flow pressure alarm.
- *O₂ concentration:* O₂ concentration alarm (if enabled).

Clock The Clock screen allows the user to set the instrument's date and time, choose date/time format, time zone, and time server.

Home Screen>Settings>Instrument Settings>Clock



The Clock screen contains the following information:

- Month
- Day
- Year
- Hours
- Minutes
- Seconds
- *Date / Time Parameters*: User chooses time zone, timer server, and date format.
- *Commit*: When pressed, date and time are saved.

Date / Time Parameters

The Date / Time Parameters screen allows the user to choose time zone, time server and date format.

Home Screen>Settings>Instrument Settings>Clock>Date / Time Parameters



The Date / Time Parameters screen contains the following information:

- *Time Zone:* User selects time zone from table.
- *Time Server Enabled/Disabled:* User can enabled/disable the time server to get periodic clock updates.
- *Date Format:* User selects date format.

Time Zone The Time Zone screen allows the user to set the time zone for the Network Time Protocol (NTP) server. This should be set to the time zone that the instrument is located in.

Use the ▲ and ▼ buttons to move up and down.

Home Screen>Settings>Instrument Settings>Clock>Date / Time Parameters>Time Zone



The Time Zone screen contains the following information:

- Date Line West(UTC-12)
- Samoa Time Zone(UTC-11)
- Aleutian Time Zone(UTC-10)
- Alaskan Time Zone(UTC-9)
- Pacific Time Zone(UTC-8)
- Pacific Daylight Savings(UTC-7)
- Mountain Time Zone(UTC-7)
- Mountain Daylight Savings(UTC-6)
- Central Time Zone(UTC-6)
- Central Daylight Savings((UTC-5)
- Eastern Time Zone(UTC-5)
- Eastern Daylight Savings(UTC-4)
- Atlantic Time Zone(UTC-4)
- Mid-Atlantic(UTC-3)
- South Georgia(UTC-2)

- Cape Verde Time(UTC-1)
- Coordinated Universal Time(UTC-0)
- Central European Time(UTC+1)
- Eastern European Time(UTC+2)
- Further-Eastern European Time(UTC+3)
- Gulf Standard Time(UTC+4)
- Yekaterinburg Time(UTC+5)
- Omsk Time(UTC+6)
- Indochina Time(UTC+7)
- ASEAN Common Time(UTC+8)
- Japan Standard Time(UTC+9)
- Chamorro Time Zone(UTC+10)
- Sredmnekolymsk Time(UTC+11)
- New Zealand Standard Time(UTC+12)

Time Server The Time Server screen allows the user to enable/disable the time server to get periodic clock updates.

Home Screen>Settings>Instrument Settings>Clock>Date / Time Parameters>Time Server




The Time Server screen contains the following information:

- *Time Server:* Enables/Disables periodic clock updates from an NTP (Network Time Protocol) source.
- *Set Time Server:* User can choose specific time server.
- *Set Default:* When pressed, default time server will be used.

Date Format The Date Format screen allows the user to choose from the following formats: mm/dd/yyyy or dd/mm/yyyy.

Use the ▲ and ▼ buttons to move up and down.

Home Screen>Settings>Instrument Settings>Clock>Date / Time Parameters>Date Format



The Date Format screen contains the following information:


- U.S. Format mm/dd/yyyy
- European Format dd/mm/yyyy
- ISO 8601 yyyy-mm-dd

Configuration

The Configuration screen allows the user to enable optional features. If an option is disabled, the corresponding buttons will be grayed out and the screens will not be available.

Use the ▲ and ▼ buttons to select the variables. Next, press the **Commit Changes** button to save selections. Yellow buttons indicate that the variable is selected. More than one can be chosen.

Home Screen>Settings>Configuration




The Configuration screen contains the following information:

- *Zero/Span Assembly*: Enables zero/span option.
- *Oxygen Sensor*: Enables O₂ sensor option.
- *Predictive Diagnostics*: Enables predictive diagnostics option.
- *Communications Board*: Enables RS-232 or RS-485 communication board option.
- *Analog I/O*: Enables analog I/O option.
- *Digital I/O*: Enables digital I/O option.

Security Access Levels

The Access Levels screen allows the user to set the instrument to either View Only or Full Access. When in Full Access, the user will have access to all screens. When set to View Only, user will not be able to change any values.

Home Screen>Settings>Security Access Levels (Full Access)



Home Screen>Settings>Security Access Levels (View Only Access)



The Security Access Levels screen contains the following information:

- *Current Security Access Full Access:* Read only. User will be able to change all values. Password is needed for full access.
- *Current Security Access View Only:* Read only. User won't be able to change any values. Password is not needed for view only.
- *Change Security Access to View Only:* User can switch to view only mode. Password not needed to change settings to view only access.
- *Change Security Access to Full Access:* User can switch to full access mode. Password is needed to change settings to full access.


Operation
Settings

- *Change Full Access Security Password:* Full access password can have a blank value or user selected password.

Change Security to View Only Access

The Change Security to View Only Access screen allows the user to set the instrument to view only.

Home Screen>Settings>Security Access Levels>Change Security Access to View Only Access



The Change Security to View Only Access screen contains the following information:

- *Set Access Level to View Only*: Programs the instrument to be in the view only access level, where the user won't be able to change any values.
- *Cancel*: Exit screen.

Note To change security access from view only access to full access, a keypad will be displayed where the user can enter full access password. ▲

Change Full Access Security Password

The Change Full Access Security Password screen allows the user to set a new password for allowing full access.

Home Screen>Settings>Security Access Levels>Change Full Access Security Password




To Change the Security Access Password perform the following steps using the graphical user interface only (do not use an external USB keyboard):

1. Enter the Current Security Access Password
2. Enter the New Security Access Password
3. Confirm the New Security Access Password
4. Commit the New Security Access Password Change

Note: To clear the Full Access Password, follow the steps above using blank values for the New Password.


Continue **Cancel and Return to the Home Screen**

Home Screen>Settings>Security Access Levels>Change Full Access Security Password>Continue





1. Enter the Current Security Access Password and then press Continue.
If there is no Current Full Access Password then press Continue.

Enter Current Security Password **Continue** **Cancel and Return to the Home Screen**



2. Enter the New Security Access Password and then press Continue.

Set New Security Access Password **Continue** **Cancel and Return to the Home Screen**




The Change Full Access Security Password screens contain the following information:

- *Enter Current Security Password:* User enters current security password. Default password is blank.
- *Continue:* Proceeds to next screen.
- *Enter New Security Access Password:* User enters new security password.
- *Confirm New Security Access Password:* User confirms new security password for spelling confirmation.
- *Commit New Security Access Password Change:* Commits new security password.
- *Cancel and Return to the Home Screen:* Exits screen and returns to the Home Screen without changing password.

USB Drive The USB Drive screen allows the user to update firmware, download/upload information, and change the USB password.

Note The USB drive screen only is useable when a USB drive is inserted into the USB port. When a USB drive is inserted, the user is prompted to enter the password if a password has been set. ▲

Home Screen>Settings>USB Drive




The USB Drive screen contains the following information:

- *Firmware Update Via USB Drive*: If USB is mounted, user can update instrument firmware.
- *Download Data To USB Drive*: If USB is mounted, user can download/upload information.
- *Change USB Password*: User can change the USB password.

Firmware Update Via USB Drive

The Firmware Update Via USB Drive screen allows the user to update instrument firmware from the USB drive.

Home Screen>Settings>USB Drive>Firmware Update Via USB Drive




The Firmware Update Via USB Drive screen contains the following information:

- *Update Firmware:* User chooses firmware file from USB and updates instrument firmware. Instrument reboots when update is finished.
- *Exit:* User exits without updating firmware.

Download Data To USB Drive

The Download Data To USB Drive screen allows the user to download/upload data to/from the USB drive.

Home Screen>Settings>USB Drive>Download Data To USB Drive



The Download Data to USB Drive screen contains the following information:

- *Download Health Check Report:* Includes status and alarms, preventive maintenance, and maintenance history.
- *Download Entire Data Log:* Includes the entire data log (from data logging).
- *Download Service Log:* Includes a complete listing of data for all variables. This is set at the factory.
- *Download System Log:* Consists of system log text files, which include a listing of system errors.
- *Download Calibration History:* Includes the data in the calibration history screen.
- *Download Configuration Data Backup to USB:* Allows the user to download the configuration file from the instrument to the USB.
- *Restore:* Allows the user to upload the configuration files from the USB to the instrument.
- *Download All Data:* Downloads all reports, logs, histories, and backup information.

Use the following procedure to download data using the USB connection.


1. Plug a flash drive into the USB connection on the front of the instrument. If a USB password has been previously set, you will be prompted to enter the USB password to continue. Press **Enter** to continue.



2. To continue, select the **OK** button.



3. The USB Drive will display. Select **Download Data To USB Drive**.



4. The Download Data to USB Drive screen will display. Select from various options to download.



5. The instrument will display a “downloading data” message and begin transferring data to the USB drive.

Note Do not remove the USB drive from the instrument while the data is downloading. ▲

6. When the data download is complete, the instrument will display a “Success!” message and display the file name as it is stored on the USB flash drive. (The file name format is the instrument serial number, name of download, followed by a date/time stamp.) Remove the USB flash drive and select the OK button to continue.

Change USB Password

The Change USB Password screen allows the user to set a new password for accessing USB.

Home Screen>Settings>USB Drive>Change USB Password




To Change the USB Access Password perform the following steps using the graphical user interface only (do not use an external USB keyboard):

1. Enter the Current USB Access Password
2. Enter the New USB Access Password
3. Confirm the New USB Access Password
4. Commit the USB Access Password Change

Note: To clear the USB Password, follow the steps above using blank values for the New Password.


Continue **Cancel and Return to the Home Screen**

Home Screen>Settings>Security Access Levels>Change Standard Access Password>Continue





1. Enter the Current USB Access Password and then press Continue.
If there is no Current USB Password then press Continue.

Enter Current USB Password **Continue** **Cancel and Return to the Home Screen**



2. Enter the New USB Access Password and then press Continue.

Enter New USB Password **Continue** **Cancel and Return to the Home Screen**



The Change USB Password screens contain the following information:

- *Enter Current USB Password:* User enters current USB password. Default password is blank.
- *Continue:* Proceeds to next screen.
- *Enter New USB Password:* User enters new USB password.
- *Confirm New Security Access Password:* User confirms new security password for spelling confirmation.
- *Commit New USB Password Change:* Commits new USB password.
- *Cancel and Return to the Home Screen:* Exits screen and returns to the Home Screen without changing password.

User Contact Information

The User Contact Information screen allows the user to enter their contact information. This is useful when contacting technical support through emails found at the screen Health Check>File Sharing and Support.

Home Screen>Settings>User Contact Information

| Description | User Information |
|---------------------------|------------------|
| Business Name | |
| User Name | |
| Alternate User Name | |
| User ID | |
| Business Address | |
| Business Shipping Address | |


The User Contact Information screen contains the following information:

- Business Name
- User Name
- Alternate User Name
- User ID
- Business Address
- Business Shipping Address
- To: User Email Address
- CC: User Email Address 1–10
- User Phone Number
- Alternate User Phone Number
- Shelter / Lab Phone Number

Update Bootloader

The Update Bootloader screen allows the user to update bootloader and reboot the instrument. If the button is blue, an update to the bootloader is available. If button is greyed out, no update is needed.

Home Screen>Settings>Update Bootloader



The Update Bootloader screen contains the following information:

- *Reboot and Update*: Update bootloader and reboot instrument.
- *Exit*: Exits screen.

Chapter 4

Calibration

This chapter describes the procedures for performing a standard zero/span calibration and a multipoint calibration of the 48iQ. The information described here is more than adequate to perform the calibration. However, if greater detail is needed, please refer to the *Quality Assurance Handbook for Air Pollution Measurement Systems*¹.

The following sections discuss the required apparatus and procedure for calibrating the instrument.

Equipment Required

The following equipment is required to calibrate the instrument:

CO Concentration Standard

A cylinder of CO in air containing an appropriate concentration of CO suitable for the selected operating range of the analyzer under calibration is necessary. The assay of the cylinder must be traceable either to a National Institute of Standards and Technology (NIST) CO in Air Standard Reference Material (SRM) or an NIST/EPA approved gas manufacturer's Certified Reference Material (CRM).

A recommended protocol for certifying CO gas cylinders against a CO, SRM or CRM is given in the *Quality Assurance Handbook*¹. The CO gas cylinder should be recertified on a regular basis determined by the local quality control program.

Zero Air Generator

Calibration requires zero air that is free of contaminants which will cause a detectable response on the CO analyzer. The zero air should contain <0.01 ppm CO. Since the 48iQ is virtually interference free, it is only necessary to ensure that CO has been removed.

It should be noted that zero air as supplied in cylinders from commercial suppliers typically contains CO concentrations in the 0.1-0.3 ppm range. So cylinder zero air should be scrubbed of the residual CO prior to its use in the 48iQ as a dilution gas or a zero standard. Room air which has been scrubbed of CO can also be used as the zero air source.

It is not necessary to remove SO₂, NO, NO₂, CO₂, water vapor, or hydrocarbons, since the 48iQ does not respond to these molecules. If water

vapor is not removed, it might be necessary to correct the flow measurement data when calculating the dilution ratio of the span CO reference.

A platinum on alumina catalyst, operated at 250 °C, has been found to be a convenient oxidizer to convert CO to CO₂.

External Flow Meter(s) and Controller(s)

In order to obtain an accurate dilution ratio in the dilution method used for calibration, the flow rates must be regulated to 1%, and be measured to an accuracy of at least 2%. The meter and controller can be two separate devices, or combined in one device. The user's manual for the meter should be consulted for calibration information.

Additional information on the calibration of flow devices can be found in the *Quality Assurance Handbook*¹. It should be noted that all flows should be corrected to 25 °C and 760 mmHg, and that care should be exercised in correcting for water vapor content.

Pre-Calibration

Prior to calibration, be sure the instrument is operating properly. Turn on the instrument and allow it to stabilize for one hour. Select the operating range and the averaging time of the 48iQ.

- The averaging time should be less than the zero duration and less than the span duration.
- The calibration and calibration check duration times should be long enough to account for the transition (purge) process when switching from sample to zero and from zero to span. This transition time is the time required to purge the existing air.
- Depending on the plumbing configuration and the instrument, data from approximately the first minute of a zero calibration or check should be disregarded because of residual sample air. Also, data from approximately the first minute of a span calibration or check should be disregarded because the span is mixing with the residual zero air.
- If an optional sample line filter is used, the calibration must be performed through this filter. Ensure that the flow rate into the output manifold is greater than the total flow required by the analyzer and any other flow demand connected to the manifold.

Calibration

Use the following procedure to calibrate the instrument.

Connect the Instrument

Connect the instrument and the calibration equipment as shown in [Figure 4-1](#).




Figure 4-1. Calibration Flow Schematic

Detector Gain

The Detector Gain is determined at the factory and should only be adjusted by a qualified technician. The only time the Detector Gain should be adjusted is if there were changes to the elements that affect the light path or detection. There are two ways of calibrating the Detector Gain: From the Home Screen>Settings>Advanced Measurement Settings>Optical Bench Settings>**Continue To Detector Gain Calibration**. The user can manually change the detector gain by clicking on the first cell below the Detector Gain description. The user will be brought to a keypad screen where a new value can be entered.

However, it is suggested to run an Auto Calibration for the Detector Gain. This is done by pressing on the cell labeled Start located in the Detector Gain column. Allow up to 5 minutes for the Detector Gain to be calibrated. The user can Stop the calibration at any time by pressing the Stop button located in the Detector Gain column.

The user can set the Detector Gain to factory defaults by pressing on the cell labeled Default Gain located in the Detector Gain column.

Home Screen>Measurement Settings>Advanced Measurement Settings>Optical Bench Settings>Continue To Detector Gain Calibration

| Description | Detector Gain | Current Sample Int. (Hz) | Current Reference Int. (Hz) |
|----------------|---------------|--------------------------|-----------------------------|
| Manual Entry | 180 | 165508 | 143807 |
| Auto Cal | Start | | |
| End Cal | Stop | | |
| Default Values | Default Gain | | |
| | | | |
| | | | |

Initial S/R

The Initial S/R (Sample/Reference Ratio) is determined at the factory and should only be adjusted by a qualified technician. The Initial S/R is used to correct for the slight variations found from one correlation wheel to another. The only time the Initial S/R ratio should be changed is when the correlation wheel is replaced. Zero Air should be sampled when calibrating the Initial S/R. There are two ways of calibrating the Initial S/R. The user can manually change the Initial S/R by clicking on the first cell below the Initial S/R description. The user will be brought to a keypad screen where a new value can be entered.

However, it is suggested to run an Auto Calibration for the Initial S/R. This is done by pressing on the cell labeled Start located in the Initial S/R column. Allow up to 5 minutes for the Initial S/R to be calibrated. The user can Stop the calibration at any time by pressing the Stop button located in the Initial S/R column.

The user can set the Initial S/R to factory defaults by pressing on the cell labeled Default S/R located in the Initial S/R column.

Home Screen>Settings>Measurement Settings>Advanced Measurement Settings>Optical Bench Settings>Continue To Initial S/R Calibration

| Description | Initial S/R | Current S/R | | | | |
|----------------|-------------|-------------|--|--|--|--|
| Manual Entry | 1.15009 | 1.15018 | | | | |
| Auto Cal | Start | | | | | |
| End Cal | Stop | | | | | |
| Default Values | Default S/R | | | | | |
| | | | | | | |
| | | | | | | |

Multipoint Calibration

The Multipoint Calibration should be performed initially when the instrument is received. The user can choose to calibrate with one, two, or three points. It is suggested to perform a 3-point Multipoint Calibration. The Multipoint Calibration is divided into three calibration points. The range is user definable and the following calibration points are recommended for the user selected range:

- Point 1: 80% of range
- Point 2: 50% of range
- Point 3: 20% of range

Note If performing a multipoint calibration after a “bad” calibration or changing ranges, it is recommended to start off with default values for the Cal point coefficients. ▲

To set default values, from the Home Screen select Calibration>Advanced Calibration>**Multipoint Calibration**. From Multipoint Calibration, select **Reset Points to Default Values**. The instrument will automatically reset to default values.



Use the following procedure to calibrate points 1, 2, and 3:

1. Adjust the zero air flow and the CO flow from the standard CO cylinder to provide a diluted CO concentration of approximately 80% of the upper range limit (URL) of the instrument. The total air flow must exceed the total demand of the analyzer connected to the output manifold to ensure that no ambient air is pulled into the manifold vent. The exact CO concentration is calculated from:

$$[\text{CO}]_{\text{OUT}} = \frac{([\text{CO}]_{\text{STD}} \times F_{\text{CO}})}{(F_{\text{D}} + F_{\text{CO}})}$$

Where:

$[\text{CO}]_{\text{OUT}}$ = diluted CO concentration at the output manifold, ppm

$[\text{CO}]_{\text{STD}}$ = concentration of the undiluted CO standard, ppm

F_{CO} = flow rate of CO standard corrected to 25 °C and 760 mmHg, L/min

F_{D} = flow rate of dilution air corrected to 25 °C and 760 mmHg, L/min

2. Allow the instrument to sample the CO concentration until a stable response is obtained.
3. From the Home Screen press Calibration>Advanced Calibration>Multipoint Calibration>**Point 1**.



4. Enter the span concentration being introduced to the instrument. Press **Calibrate**.

The instrument will perform a series of calculations and save the new parameters.

5. Press the back button to back up a step to the multipoint menu.
6. Introduce a CO concentration 50% of the URL.
7. Select **Point 2**.
8. Enter the span concentration being introduced to the instrument. Press **Calibrate**.

The instrument will perform a series of calculations and save the new parameters.
9. Press the back button to back up a step to the multipoint menu.
10. Introduce a CO concentration 20% of the URL.
11. Select **Point 3**.
12. Enter the span concentration being introduced to the instrument. Press **Calibrate**.

The instrument will perform a series of calculations and save the new parameters.

High and Low Multipoint Calibration

The instrument can also be calibrated using a dual three-point calibration. The calibration points are divided into a “high” range and a “low” range consisting of three points each. See “[Multipoint Calibration](#)” on page 4-6.

Calibration Frequency

In order to generate data of the highest confidence, it is recommended that a multipoint calibration be performed:

- every three months
- any time any major disassembly of components is performed


Calibrate Background

Use the following procedure to set the CO reading to zero.

1. Allow sufficient time for the instrument to warm up and stabilize.
2. Adjust the dilution system of [Figure 4–1](#) so that zero air alone is present in the manifold.

Since not all flow controllers have a positive shut off, it might be necessary to disconnect the CO input line and cap it.
3. Allow the instrument to sample zero air until a stable reading is obtained.
4. From the Home Screen, press Calibration>**Calibrate Background**.

The Target Concentration button will read 0.000. The Calculated Background button will display the background needed to make the current CO concentration go to zero.
5. Press **Calibrate** to set the CO reading to zero and to save the new background.



Calibrate Span Coefficient

Use the following procedure to adjust the span.

1. Adjust the zero air flow and the CO flow from the standard CO cylinder to provide a diluted CO concentration of approximately 80% of the upper range limit (URL) of the analyzer. The total air flow must exceed the total demand of the analyzer connected to the output manifold to ensure that no ambient air is pulled into the manifold vent. The exact CO concentration is calculated from:

$$[\text{CO}]_{\text{OUT}} = \frac{([\text{CO}]_{\text{STD}} \times F_{\text{CO}})}{(F_{\text{D}} + F_{\text{CO}})}$$

Where:

$[\text{CO}]_{\text{OUT}}$ = diluted CO concentration at the output manifold, ppm

$[\text{CO}]_{\text{STD}}$ = concentration of the undiluted CO standard, ppm

F_{CO} = flow rate of CO standard corrected to 25 °C and 760 mmHg, L/min

F_{D} = flow rate of dilution air corrected to 25 °C and 760 mmHg, L/min

2. Allow the instrument to sample this CO concentration standard until a stable response is obtained.
3. From the Home Screen, choose Calibration > **Calibrate Span Coefficient**.

The user sets the span concentration by pressing the Edit Span Concentration button. The Calculated Span Coefficient button will show what the span coefficient will be set to if the Calibrate button is pressed. Pressing the Calibrate button will save the new coefficient and calibrate the instrument.

4. Enter the CO calibration gas concentration using the pushbuttons, and then press **Calibrate** to calibrate the CO reading to the CO calibration gas.
5. Record the CO concentration and the instrument's response.



Periodic Zero and Span Checks

In order to achieve data of the highest confidence, it is suggested that periodic zero and air span checks be performed. These checks can be performed by:

1. Periodically challenging the instrument with zero air. The output of the zero air supply should be greater than the flow demand of the instrument. In addition, an atmospheric dump bypass should be utilized to ensure that the zero air gas flow is being delivered at atmospheric pressure.

Record the response in percent of scale as A_0 . Compute the zero drift from the following equation:

$$\text{Zero Drift \%} = A_0 - Z$$

Where:

Z is the response obtained at the last calibration for zero air, % scale

2. Periodically challenging the instrument with a CO level of approximately 80% of the URL. The 80% URL level may be obtained by dilution of a higher level of CO using a system similar to that of [Figure 4-1](#), or by using a low level cylinder of CO containing CO in air at a concentration of approximately 80% of the URL. In either case the cylinder of CO should be checked against an SRM or CRM. It should also be true for a cylinder of low level CO.

The *Quality Assurance Handbook*¹ should be referred to for the cylinder checking procedure.

Compute the span error from the following equation:

$$\left[\frac{\text{Reported CO Concentration} - \text{Actual CO Concentration}}{\text{Actual CO Concentration}} \right] \bullet 100$$

3. Latest copy of the *Quality Assurance Handbook for Air Pollution Measurement Systems*¹ should be consulted to determine the level of acceptance of zero and span errors.

For detailed guidance in setting up a quality assurance program, refer to the *Code of Federal Regulations and the EPA Handbook on Quality Assurance*.

Manual Calibration

The Manual Calibration menu allows the user to view and manually adjust the zero background and span coefficient. These are used to correct the CO readings that the instrument generates using its own internal calibration data.

Normally, the zero background and span coefficient are calculated automatically at the Calibrate Background and Calibrate Span Coefficient described earlier in the chapter. However, the calibration factors can also be set manually using the functions as described below.

The following screen is shown in single range mode. In dual or auto range modes, “High Range” or “Low Range” button are displayed to indicate the calibration of the high or low coefficient. The Adjust High Range Span Coefficient and Adjust Low Range Span Coefficient screens function the same way.

Home Screen>Calibration>Advanced Calibration>Manual Calibration (single range mode)




Adjust Background

The CO background is the amount of signal read by the analyzer while sampling zero air.

The Adjust Background screen is used to perform a manual zero background calibration of the instrument. As such, the instrument should sample zero air until stable readings are obtained. The button labeled Adjust Background allows the user to change zero background. The second button called Adjusted Concentration shows what the new CO concentration would be based on the changed zero background. Press the Calibrate button to save the adjusted zero background value.

Home Screen>Calibration>Advanced Calibration>Manual Calibration>Adjust Background




Adjust Span Coefficient

The span coefficients are used to correct the CO readings and normally has a value near 1.000 with minimum/maximum limits of 0.500 and 2.000 respectively.

The user can manually change the span coefficient by entering a value in the Adjust Span Coefficient button. The second button called Adjusted Concentration shows what the new CO concentration would be based on the adjusted span coefficient. Press the Calibrate button to save the adjusted span coefficient value.

Home Screen>Calibration>Advanced>Manual Calibration>Adjust Span Coefficient (single range mode)




Reset Bkg to 0.000 and Span Coef to 1.000

The Reset Bkg to 0.000 and Span Coef to 1.000 screen allows the user to reset the calibration configuration values to factory defaults.


Zero/Span Schedule

The Zero/Span Schedule screen is available only if the zero/span valve option is installed and turned on (toggles on or off) at the screen Settings>Configuration. It is used to program the instrument to perform fully automated zero and span calibration or calibration checks.

Home Screen>Calibration>Zero/Span Schedule



Home Screen>Calibration>Zero/Span Schedule>More



Next Time

The Next Time button is used to view and set the initial date and time (24-hour format) of the zero/span schedule. Once the zero/span schedule begins, the date and time of the next zero/span schedule is calculated and displayed.

Period

The Period button defines the period or interval between zero/span schedule. Periods between 0 and 999 hours are acceptable.

Zero/Span/Purge Duration Minutes

The Zero Duration button defines how long zero air is sampled by the instrument. The Span and Purge Duration buttons look and function the same way as the zero duration button. The span duration button is used to

set how long the span gas is sampled by the instrument. The purge duration button is used to set how long the purge period will be after doing a zero and/or span. This gives the instrument time to flush out the zero and span gas before any meaningful sample data is taken. Logged data is flagged as taken during a purge to show that the data is suspect. Durations between 0 and 99 minutes are acceptable. Each time a zero/span schedule occurs the zero is done first, followed by the span. To perform just a zero, set the span duration to 0 (off). The same applies to perform just a span.

Schedule Averaging Time

The Schedule Averaging Time button allows the user to adjust the schedule averaging time. The schedule averaging time is used by the analyzer only when performing a zero/span schedule. The analyzer's averaging time is used for all other functions. Range is 1–300 seconds.

Background Calibration and Span Calibration

Background Calibration and Span Calibration are toggle buttons that change between enabled or disabled.

If the background calibration is set to enabled, then a zero adjustment is made. If the span calibration is set to enabled, then a span adjustment is made. (This is how to set up a scheduled, recurring auto calibration.)

Zero Calibration and Span Calibration

Zero and Span Calibration Commit are toggle buttons that change between yes or no when selected.

If the zero calibration commit is set to yes, then a zero adjustment is made. If the span calibration commit is set to yes, then a span adjustment is made. (This is how to set up a scheduled, recurring auto calibration.)

Zero/Span Ratio

The Zero/Span Ratio button is used to set the ratio of zero checks or adjustments to span checks or adjustments. For example, if this value is set to 1, a span duration will follow every zero duration. If this value is set to 3, there will be two zero checks between each span check. This value may be set from 1 to 99, with 1 as default.

References

1. Section 12 of EPA *Quality Assurance Handbook for Air Pollution Measurement Systems*, Volume II, available at www.epa.gov.

Section 12 also provides information on “Calibration of Primary and Secondary Standards for Flow Measurements”.

Specific information on certification of concentration standards is given in EPA *Traceability Protocol for Assay and Certification of Gaseous Calibration Standards*, available at www.epa.gov.

Chapter 5

Maintenance

This chapter describes the periodic maintenance procedures that should be performed on the instrument to ensure proper operation. Since usage and environmental conditions vary greatly, you should inspect the components frequently until an appropriate maintenance schedule is determined.

Safety Precautions



Read the safety precautions before beginning any procedures in this chapter.

Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly grounded antistatic wrist strap must be worn while handling any internal component. For more information about appropriate safety precautions, see the “[Servicing](#)” chapter. ▲

Fan Filter Inspection and Cleaning

Use the following procedure to inspect and clean the fan filter.

1. Remove the fan guard from the fan and remove the filter.
2. Flush the filter with warm water and let dry (a clean, oil-free purge will help the drying process) or blow the filter clean with compressed air.
3. Re-install the filter and fan guard.

Pump Rebuilding

Use the following procedure to rebuild the pump.

Equipment required:

Pump rebuild kit (qty. 1)

Phillips drive, #1 or Torque drive, T10 (depending on pump version)

Pencil or marker



Figure 5-1. Single Stage Pump

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Mark the position of head parts relative to each other by drawing a line with a pencil. This helps avoid incorrect assembly later.
3. Undo the four screws in the head.
4. Lift the head plate and the intermediate plate off the housing.
5. Hold the pump with one hand, so that the diaphragm is pointing downwards. Lift the diaphragm by the opposing side edges, grasp it and unscrew it in the counter-clockwise direction.

6. Remove connection rod disc and diaphragm spacers from the threaded pin of the diaphragm.
7. Push the connection rod disc and the diaphragm spacers in this order onto the threaded pin of the new diaphragm.
8. Move the connecting rod to the upper point.
9. Screw the new diaphragm with connection rod disc and spacers clockwise onto the connection rod and tighten hand-tight.
10. Place the intermediate plate on housing, in the position indicated by the drawing line.
11. Place the new valve plate on the intermediate plate.
12. Place the head plate on the intermediate plate, in the position indicated by the drawing line; gently tighten the four screws, evenly and diagonally (if a torque screwdriver is available: torque about 0.30 Nm).
13. Let the pump run.




Figure 5-2. Pump Rebuilding

Leak Test

Use the following procedure to perform a leak test.

Equipment Required:

Cap

Vacuum Tester with Gauge (with a resolution of .5 in Hg or better)

1. Turn instrument OFF, unplug the power cord.
2. Block the SAMPLE bulkhead on the rear panel with a leak-tight cap.
3. Connect the vacuum tester tool to the EXHAUST bulkhead on the rear panel.
4. Squeeze trigger until gauge reads to pull in 10 in Hg.
5. Observe vacuum gauge for stable reading for 5 minutes. If reading remains at 10 in Hg, no leak is present.

Note Acceptable leak rate is .5 in Hg over 10 minutes. ▲

Cleaning the Optics

Best results are obtained when the optics are cleaned prior to calibration. The cleanliness of the mirrors should be checked any time the intensity is below 200,000 Hz, since one cause of low output is light attenuation due to dirt on the mirrors.



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly grounded antistatic wrist strap must be worn while handling any internal component. For more information about appropriate safety precautions, see the “[Servicing](#)” chapter. ▲

Use the following procedure to clean the mirrors.

Equipment Required:

Hex drive, 9/64

1. Turn off power and disconnect power line.
2. Using 9/64 hex drive, remove the field mirror by removing the four #8-32 socket cap head screws holding it to the main bench.




Figure 5–3. Removing the Field Mirror

3. Carefully clean each mirror using a cotton swab and methanol. Rinse with distilled or deionized water. Dry by blowing clean dry air over the mirror.
4. Reassemble following the above procedure in reverse. It is not necessary to realign any mirror following cleaning.
5. Calibrate the instrument. See the “[Calibration](#)” chapter in this manual.

IR Source Replacement

The IR source control system has been designed to operate the wire wound resistor IR source conservatively in order to increase its life. Nevertheless, the IR source does have a finite life. Since the IR source is relatively inexpensive and easily replaced, it is recommended that the IR source be replaced after one year of continuous use. This will prevent loss of data due to IR source failure. If an IR source is to be replaced on an as needed basis, it should be replaced when:

- There is no light output
- After cleaning the optics, the IR light intensities remain below 100,000 Hz

For more information on replacing the IR Source, see “[IR Source Replacement](#)” on page 7-45.

Note It is not necessary to recalibrate the 48iQ after replacing the IR source since it is a ratio instrument, and replacing the IR source does not affect the calibration. ▲

Chapter 6

Troubleshooting

This chapter presents guidelines for diagnosing analyzer failures, isolating faults, and includes recommended actions for restoring proper operation.

Safety Precautions

Read the safety precautions in Appendix A, “[Safety](#)” before performing any actions listed in this chapter.

Troubleshooting Guide

[Table 6–1](#) provides general troubleshooting information for the common platform and indicates the checks that you should perform if you experience an instrument problem. It also lists 48iQ specific troubleshooting information and alarm messages you may see on the graphics display and provides recommendations about how to resolve the alarm condition.

Table 6–1. 48iQ Troubleshooting Guide

| Problem | Possible Cause | Action |
|---|---|---|
| Instrument does not start (LEDs on front panel do not come on and display is blank) | No power | Verify that the power cord is plugged in, power is available and that it matches the voltage and frequency configuration of the instrument. |
| | Fuse is blown or missing | Disconnect power and check fuses with a volt meter. |
| | Bad switch or wiring connection to switch | Check for 24V @ J9 on the Backplane board (middle pins). Check all wiring connections. |
| Front panel display does not start (LEDs on front panel are off) | Disconnected ribbon cable | Power down and evaluate connections of display ribbon cable. |
| Front panel display does not start (LEDs on front panel are on) | Defective Display | Connect to the instrument using ePort. Select “Remote Interface”. If normal GUI is displayed, replace defective display. |
| Front panel display stays white after power up (LEDs on front panel are on) | Unseated or missing Micro SD card | Power off, re-seat Micro SD or install if missing. |

| Problem | Possible Cause | Action |
|--|-------------------------------------|---|
| | Micro SD Card Programming | If Micro SD card was just replaced, re-install the old one. If the problem is fixed, request a replacement Micro SD card. |
| Solenoid current out of range (option) | Sticking or damaged solenoid | Reset solenoid via Settings>Health Check>Status and Alarms>Valve and Pump Resets screen. If damaged, replace solenoid valve block. |
| Pump current out of range | Damaged or dirty pump | Reset pump via Settings>Health Check>Status and Alarms>Valve and Pump Resets. Inspect and refurbish pump. If pump motor is damaged, replace pump. |
| No output signal (or very low output) | No sample gas reaching the analyzer | Check input sample flow. |
| | Ruptured pump diaphragm | Rebuild pump head. |
| | Blocked sample capillary | Unplug power cord. Clean or replace capillary. |
| Calibration drift | Line voltage fluctuations | Check to see if line voltage is within specifications. |
| | Defective pump | Rebuild pump. |
| | Clogged capillaries | Unplug power cord. Clean or replace capillary. |
| | Clogged sample air filter | Replace filter element. |
| Non-linear response | Incorrect calibration source | Verify accuracy of multipoint calibration source gas. |
| | Leak in sample probe line | Check for variable dilution. |
| Excessive response time | Partially blocked sample capillary | Unplug power cord. Clean or replace capillary. |
| | Hang up/blockage in sample filter | Change element. |
| | Low line voltage | Check to see if line voltage is within specifications. |
| Alarm – Internal Temperature | Fan failure | Replace fan if not operating properly. |
| | Dirty fan filter | Clean or replace filter. |
| | Overheating PCB | Locate defective PCB reporting the error and replace if needed. |
| Alarm – Bench Temperature | Defective bench | Check 10K ohm thermistor and |

| Problem | Possible Cause | Action |
|-----------------------------|--------------------------------|--|
| | heater | replace heater if bad. |
| Alarm – Pressure | High bench pressure indication | <p>Check the pump for a tear in the diaphragm; replace with pump repair kit if necessary. Refer to “Maintenance” chapter in this manual.</p> <p>Check that capillaries are properly installed and o-rings are in good shape. Replace if necessary.</p> <p>Check flow system for leaks.</p> |
| Alarm – Flow | Flow low | <p>Check sample capillary for blockage. Replace as necessary.</p> <p>If using sample particulate filter, make sure it is not blocked. Disconnect sample particulate filter from the sample bulkhead. If flow increases, replace the filter.</p> <p>Perform a leak test as described on page 5-5.</p> |
| | Flow high | When delivering zero air or gas to the instrument, use an atmospheric dump. |
| | Flow = 0 LPM | Check that Step POL board #1 has both dip switch settings of SW2 off (both facing the rear of the instrument). Verify the pump is plugged into the Step POL board. |
| | Worn Diaphragm | Rebuild pump every 12 months or as needed. |
| Alarm – Board Communication | Cable connection | Check that DMC cable is connected properly. Reseat if needed. |
| | Defective DMC PCB | Replace DMC board. |
| Alarm – Power Supply | Cable connection | Check that DMC cable is connected properly. Reseat if needed. |
| | Defective component | Check for other alarms, as it is possible that another component of that DMC is drawing too much current. |
| | Defective DMC PCB | Replace DMC board. |
| Alarm – Module Temperature | Cable connection | Check that DMC cable is connected properly. Reseat if needed. |
| | Other alarm | Make sure the instrument temperature is not too high or in alarm. |

| Problem | Possible Cause | Action |
|-------------------------------------|--|--|
| | Defective DMC PCB | Replace DMC board. |
| Alarm – 5V/24V Step Board | Cable connection | Check the cable connections to that Step POL board. |
| Alarm – Conc. | Concentration has exceeded range limit | Check to ensure range corresponds with expected value. If not, select proper range. |
| | Concentration low | Check user-defined low set point. Be sure the minimum trigger is set as desired. |
| Alarm – Analog I/O | Defective PCB | Replace Analog board. |
| Alarm – Digital I/O | Defective PCB | Replace Digital board. |
| Alarm – Auto Bkg Cal/Check | Incorrect high alarm limit | Verify the high limit is correct via Settings>Status and Alarms>Concentrations screen. |
| | Instrument background calibration failed | Recalibrate the instrument. |
| Alarm – Auto Span Cal/Check | Incorrect high alarm limit | Verify the high limit is correct via Settings>Status and Alarms>Concentrations screen. |
| | Instrument span calibration failed | Recalibrate the instrument. |
| Alarm – Bench Temp Thermistor Open | Cable connection | Check connection from heater to DMC board. Reseat if needed. |
| Alarm – Bench Temp Thermistor Short | Cable connection | Check connection from heater to DMC board. Reseat if needed. |
| Alarm – Motor Speed too low | Cable connection | Check connection from motor to DMC board. Reseat if needed. |
| | Defective Heater | Replace motor as needed. |
| | Defective DMC board | Replace board as needed. |
| Alarm – Motor Speed too high | Cable connection | Check connection from motor to DMC board. Reseat if needed. |
| | Defective Heater | Replace motor as needed. |
| | Defective DMC board | Replace board as needed. |
| Alarm – Module Thermistor Open | Defective DMC board | Replace board as needed. |
| Alarm – Module Thermistor Short | Defective DMC board | Replace board as needed. |
| Alarm – Bench Temp Thermistor Open | Cable connection | Check the cable connection from the thermistor to the DMC board. |

| Problem | Possible Cause | Action |
|-------------------------------------|-----------------------|---|
| | Defective Thermistor | Replace Thermistor as needed. |
| | Defective DMC board | Replace board as needed. |
| Alarm – Bench Temp Thermistor Short | Cable connection | Check the cable connection from the IR Source to the DMC board. |
| | Defective IR Source | Replace IR Source as needed. |
| | Defective DMC board | Replace board as needed. |
| Alarm – IR Source Current Low | Cable connection | Check the cable connection from the IR Source to the DMC board. |
| | Defective IR Source | Replace IR Source as needed. |
| | Defective DMC board | Replace board as needed. |
| Alarm – IR Source Current High | Cable connection | Check the cable connection from the IR Source to the DMC board. |
| | Defective IR Source | Replace IR Source as needed. |
| | Defective DMC board | Replace board as needed. |
| Alarm – IR Detector Bias Low | Cable connection | Check the cable connection from the IR Source to the DMC board. |
| | Defective IR Source | Replace IR Source as needed. |
| | Defective DMC board | Replace board as needed. |
| Alarm – IR Detector Bias High | Cable connection | Check the cable connection from the IR Source to the DMC board. |
| | Defective IR Source | Replace IR Source as needed. |
| | Defective DMC board | Replace board as needed. |

Chapter 7

Servicing

This chapter describes the periodic servicing procedures that should be performed on the instrument to ensure proper operation and explains how to replace the 48iQ subassemblies.

Safety Precautions

Read the safety precautions before beginning any procedures in this chapter.



The service procedures in this manual are restricted to qualified service representatives. ▲



If the equipment is operated in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired. ▲



CAUTION If the LCD panel breaks, do not let the liquid crystal contact your skin or clothes. If the liquid crystal contacts your skin or clothes, wash immediately using soap and water. ▲

Do not remove the LCD panel or frame from the LCD module. ▲

The LCD polarizing plate is very fragile, handle it carefully. ▲

Do not wipe the LCD polarizing plate with a dry cloth, as it may easily scratch the plate. ▲

Do not use alcohol, acetone, MEK or other Ketone based or aromatic solvents to clean the LCD module, but rather use a soft cloth moistened with a naphtha cleaning solvent. ▲

Do not place the LCD module near organic solvents or corrosive gases. ▲

Do not shake or jolt the LCD module. ▲



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly grounded antistatic wrist strap must be worn while handling any internal component. For more information about appropriate safety precautions, see “[Safety](#)”. ▲

Note If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲




Figure 7–1. Properly Grounded Antistatic Wrist Strap

Note Ground to unpainted case or outlet as shown. ▲

Firmware Updates

New versions of the instrument software are periodically made available over Ethernet, USB flash drive, or company website at:

www.thermofisher.com

For more information on installing new firmware, see “Installing New Firmware” in the *iQ Series Communications* manual.

Replacement Parts List

For a complete list of spare parts, visit the company website at:

www.thermofisher.com/48iQ

Refer to [Figure 7–2](#) and [Figure 7–3](#) to identify the component location.




Figure 7-2. 48iQ Component Layout Top View




Figure 7-3. 48iQ Component Layout Side View

Fuse Replacement

Use the following procedure to replace the fuses.

1. Turn instrument OFF and unplug the power cord.
2. Remove fuse drawer, located on the AC power connector.
3. If either fuse is blown, replace both fuses.
4. Insert fuse drawer and reconnect power cord.




Figure 7-4. Replacing the Fuses

Filter Replacement

Use the following procedure to replace the filter.

1. Turn instrument OFF and unplug the power cord.
2. Starting with top right corner, pull out to remove fan cover.




Figure 7-5. Start with Top Right Corner of Fan Cover

3. Replace filter and snap fan cover back in place.




Figure 7-6. Removing the Fan Cover

Fan Replacement

Use the following procedure to replace the fan.

Equipment required:

Phillips drive, #2

1. Turn instrument OFF, unplug power cord, and remove the cover (Figure 2-1).
2. Unplug the fan cable J18.




Figure 7-7. Unplugging the Fan Cable

3. Starting with top right corner, pull out to remove fan cover.
4. Unhook the four latches of the fan cover.
5. Unfasten the four 6-32 screws from the fan housing.
6. Replace fan and reassemble in reverse order.

Servicing
Fan Replacement




Figure 7-8. Replacing the Fan

Measurement Side Removal

Use the following procedure to remove and replace the measurement side if necessary.

Equipment required:

Phillips drive, #2

1. Turn instrument OFF, unplug power cord, and remove the cover (Figure 2-1).
2. Unplug the fan cable J18 (Figure 7-9).




Figure 7-9. Unplugging the Fan Cable

3. Unplug DMC cable (Figure 7-10).




Figure 7-10. Unplugging the DMC Cable

4. Gripping from the top corners of the front panel and pull outwards.
5. Using #2 Phillips drive, remove three 8-32 flat head screws (Figure 7-11).




Figure 7-11. Unfasten Hardware Front for Measurement Side Removal

6. Swing arm open.
7. Unfasten captive hardware.
8. Using #2 Phillips drive, remove two 8-32 flat head screws.
9. Pull measurement side out.
10. Replace in reverse order.




Figure 7–12. Unfasten Hardware Rear for Measurement Side Removal

LCD Module Replacement

Use the following procedure to replace the LCD module.

Equipment required:

Wrench, 1/4

1. Turn instrument OFF and unplug the power cord.
2. Gripping from the top corners of the front panel and pull outwards.
3. Using 1/4 wrench, unfasten four #4-40 nuts (Figure 7-13).




Figure 7-13. Replacing the LCD Module

4. Remove cover.
5. Unplug LCD cables from backside of board.
6. Pull board off the standoffs.




Figure 7-14. Remove Electrical Cables from LCD

7. Replace LCD module and reassemble in reverse order.

I/O Replacement

Use the following procedure to replace the I/O boards.

1. Turn instrument OFF, unplug power cord, and remove the cover (Figure 2-1).
2. Swing arm open.




Figure 7-15. I/O Replacement, Arm

3. Pull board upwards.




Figure 7-16. I/O Replacement, Remove Board

4. During install, make sure to align cutout circular to keyway.
5. Insert board downwards.




Figure 7-17. I/O Replacement, Install

6. Close arm. Make sure expansion bracket aligns to the inside of the rectangular cutouts.




Figure 7-18. I/O Replacement, Close Arm Alignment

Peripherals Support Board and System Controller Board Replacement

Use the following procedure to replace the peripherals support board or system controller board.

1. Turn instrument OFF, unplug power cord, and remove the cover (Figure 2-1).
2. Pull tab out (two per board).
3. Pull board out.




Figure 7-19. Replacing the Peripherals Support Board

4. Replace board and reassemble in reverse order.

DMC Pressure and Flow Board

Use the following to replace the DMC pressure and flow board.

Equipment required:

Hex drive, 7/16

1. Turn instrument OFF, unplug power cord, and remove the cover (Figure 2–1).
2. Unplug cables from the pressure and flow board.




Figure 7–20. Flow Pressure Board, Disconnect DMC Cable

3. Disconnect plumbing.
4. Using 7/16 hex drive, unfasten four #6-32 socket cap head screws.

Servicing

DMC Pressure and Flow Board




Figure 7–21. Flow Pressure Board, Screws

5. Replace board and reassemble in reverse order.

Pump Replacement

Use the following procedure to replace the pump.

Equipment required:

Phillips drive, #1 and #2

1. Turn instrument OFF, unplug power cord, and remove the cover (Figure 2-1).
2. Unplug pump cable from step pol board J7.
3. Twist opposite direction to unlock tube clamps.

Note Push in tube clamp to lock. ▲

4. Disconnect tubing from pump.
5. Using #2 Phillips drive, unfasten two captive hardware.
6. Slide pump left until keyway meets opening.




Figure 7–22. Remove Pump, Disconnect and Unfasten

7. Pull pump outwards.

Note When installing pump, make sure the pump keyway opening goes over the keyway. ▲




Figure 7–23. Pump Removal, Keyway

8. Using #1 Phillips drive, remove two M3 screws.




Figure 7–24. Pump replacing, Unfasten Screws

9. Replace pump and reassemble in reverse order.

Capillary Cleaning and/or Replacement

Use the following procedure to clean and/or replace the capillary.

Equipment required:

Phillips drive, #2

Hex drive, 7/64

1. Turn instrument OFF, unplug power cord, and remove the cover (Figure 2–1).
2. Disconnect the plumbing.
3. Using #2 Phillips drive, unfasten captive hardware.




Figure 7–25. Remove Capillary, Disconnect and Unfasten

4. Slide capillary plate upwards clearing the partition panel keyway.




Figure 7-26. Capillary Plate, Keyway

5. Using 7/64 hex drive, remove four #6-32 socket cap head screws.
6. Pull apart the capillary blocks.




Figure 7-27. Capillary and O-Ring Replace

7. Replace capillary and reassemble in reverse order.

Note Fitting arrangements, number of capillaries and capillary sizes will vary per instrument configuration. ▲

Capillary O-Ring Replacement

Use the following procedure to replace the capillary o-rings.

Equipment required:

O-ring pick tool

1. Using a plastic o-ring pick tool, remove the o-ring.

Note Be careful in not damaging the o-ring walls during this process. Refer to [Figure 7–27](#). ▲

Power Supply Replacement

Use the following procedure to replace the power supply.

Equipment required:

Phillips drive, #2

1. Turn instrument OFF, unplug power cord, and remove the cover ([Figure 2–1](#)).
2. Unplug all electrical shown J9, J10, J24, J25, J26, and ground.
3. Unfasten captive hardware.
4. Slide power supply left, clearing three case floor plate keyways.




Figure 7–28. Removing Power Supply

5. Pull power supply up.
6. Replace power supply and reassemble in reverse order.




Figure 7–29. Replacing Power Supply

Step POL Board Replacement

Use the following procedure to replace the Step POL board.

Equipment required:

Torque screwdriver, T15 or Slot screwdriver, 3/16

1. Turn instrument OFF, unplug power cord, and remove the cover (Figure 2–1).
2. Unplug step pol power cable J4.
3. Unplug step pol signal cable J2.
4. Unplug pump cable J7.
5. Unfasten captive hardware.




Figure 7–30. Unplug and Unfasten Step POL Board




Figure 7–31. Clear Partition Keyway Step POL Board

6. Slide step board 1 upwards clearing the partition panel keyway.
7. If replacing step board 1, make sure switch 1 and 2 are pointed away from ON (Figure 7–32). If replacing optional step board 2, make sure switch 1 is pointed towards ON and switch 2 is pointed away from ON (Figure 7–33).
8. Replace step POL board and reassemble in reverse order.




Figure 7-32. Step POL Board 1 Switch Settings




Figure 7-33. Optional Step POL Board 2 Switch Settings

DMC Optical Bench

The DMC Optical Bench consists of an optical bench, a bracket, and a DMC board.




Figure 7–34. DMC Layout

Use the following procedure to remove the DMC from the instrument case. It is easier to do the following by removing the DMC first then remove and replace the following as necessary.

- Optical Bench removal
- Optical switch replacement, purge wheel housing removal, filter wheel replacement, motor replacement, filter wheel and motor alignment
- Heater Assembly removal
- Pre-Amp/Detector Assembly removal
- IR Source removal

Optical Bench Removal

Use the following procedure to remove the optical bench from the instrument case.

Equipment required:

Phillips drive, #2

1. Turn instrument OFF, unplug power cord, and remove the cover (Figure 2-1).
2. Unplug DMC cable J6 (bottom).
3. Disconnect plumbing as shown.
4. Using a #2 Phillips drive, unfasten six captive hardware.




Figure 7-35. DMC Removal from Instrument

Optical Switch Replacement

Use the following procedure to replace the optical switch.

Equipment required:

Hex drive, 5/32

Phillips drive, #1

1. Unplug J8 (motor) and J4 (opt).
2. Unhook motor and opt connections.




Figure 7–36. Motor and Filter Removal pt 1

3. Unplug electrical connections.
4. Using a 5/32 hex drive, remove three #10-32 socket cap head screws and lockwashers.




Figure 7-37. Motor and Filter Removal (pt 2)

Note Replace the optical switch if needed. You don't have to remove the optical switch to replace the motor or filter. ▲

5. Using #1 Phillips drive, unfasten two #4-40 flat head screws to remove the optical cover.
6. Using #1 Phillips drive, unfasten one #2-56 pan head screw to remove the optical switch.




Figure 7–38. Motor and Filter Optical Switch Replacement (pt 3)

Purge Wheel Housing Removal

Use the following procedure to remove the purge housing in order to get to the filter wheel and motor.

Equipment required:

Hex drive, 5/32

1. Using 5/32 hex drive, unfasten two #10-32 socket cap head screws.
2. Carefully pull wheel housing apart.




Figure 7–39. Purge Housing Removal from Motor Assembly (pt 4)

Filter Wheel Replacement

Use the following procedure to replace the filter wheel.

Equipment required:

Hex drive, 5/32 and 5/64

Phillips drive, #2

1. Remove optical bench. Refer to “[Optical Bench Removal](#)” on page 7-30.
2. Remove purge wheel housing. Refer to “[Purge Wheel Housing Removal](#)” on page 7-34.
3. Using 5/32 hex drive, unfasten two #10-32 socket cap head screws.
4. Using #2 Phillips drive, unfasten #8-32 pan head screw to gain access to #8-32 set screw.
5. Using 5/64 hex drive, loosen #8-32 set screw two or three turns only.
6. Carefully slide chopper wheel off motor shaft.
7. Replace filter wheel and align motor and filter wheel. Refer to “[Motor and Filter Wheel Alignment](#)” on page 7-39.




Figure 7–40. Filter Wheel

Motor Replacement

Use the following procedure to replace the motor.

Equipment required:

Hex drive, 5/32 and 5/64

Phillips drive, #2

1. Remove optical bench. Refer to “[Optical Bench Removal](#)” on page 7-30.
2. Remove purge wheel housing. Refer to “[Purge Wheel Housing Removal](#)” on page 7-34.
3. Remove filter wheel. Refer to “[Filter Wheel Replacement](#)” on page 7-35.
4. Using 5/64 hex drive, unfasten two #10-32 socket cap head screws.




Figure 7–41. Motor Removal from Motor Mount pt 1

5. Using #2 Phillips drive, unfasten #8-32 pan head screw to gain access to #8-32 set screw.
6. Using 5/64 hex drive, loosen #8-32 set screw two or three turns only.
7. Carefully slide motor out.
8. Replace motor and align filter wheel and motor. Refer to “[Motor and Filter Wheel Alignment](#)” on page 7-39.




Figure 7-42. Motor Removal

Motor and Filter Wheel Alignment

After installing a new motor or filter wheel, use the following procedure to align the motor and filter wheel.

Equipment required:

Hex drive, 5/32 and 5/64

Thread locker

1. With the “DIMPLE” of the shaft aligned with the access hole, carefully slide chopper wheel over motor shaft until set screw lines up with hole.
2. Apply a light amount of thread locker to #8-32 set screw.
3. Using 5/64 hex drive tighten set screw slowly while gently rotating the chopper wheel back and forth. You should feel the set screw engage with the “DIMPLE” of the shaft. (The set screw for the chopper wheel is located opposite the curved slot.)
4. Make sure 10-32 screws are fastened. If motor is replaced, refer to [Figure 7-41](#).
5. After the filter wheel is installed, spin the wheel and observe that it runs true on the motor shaft.




Figure 7–43. Motor Installation Shaft Alignment

6. Let instrument sample zero air for about 90 minutes.
7. From the Home screen, choose Settings>Measurement Settings>Advanced Measurement Settings>Optical Bench Settings>**Continue to Initial S/R Calibration**.
8. Follow steps in Chapter 4, “[Calibration](#)” for “[Initial S/R](#)”.

Optical Bench/Heater Removal

Use the following procedure to remove the optical bench or replace heater assembly.

Equipment required:

Hex drive, 5/32

Phillips drive, #1



Allow to cool before handling bottom of optical bench. ▲

1. Unplug electrical connections, J5 heater, J1 preamp, bottom connection J8 motor, and top connection J4 opt.
2. Using a 5/32 hex drive, unfasten four #10-32 socket cap head screws and lockwashers.




Figure 7-44. Bench Removal pt 1

3. Turn bench over, backside of optical bench.
4. Using #1 Phillips drive, unfasten five #4-40 pan head screws.




Figure 7-45. Heater Removal

5. When replacing with new heatsink or thermistor, heatsink compound is required. Apply a thin and even coat of heatsink compound underneath.

Pre-Amp/Detector Assembly Removal

Use the following procedure to remove the pre-amplifier/detector assembly.

Equipment required:

Phillips drive, #1

Hex drive, 7/64

1. Turn the instrument OFF, unplug the power cord, and remove the cover.
2. Unplug preamp and source IR cable assembly.




Figure 7–46. Preamp Detector Cover Removal pt 1

3. Using a #1 Phillips drive, unfasten two #4-40 pan head screws.
4. Lift preamp cover up.

- Using a 7/64 hex drive, unfasten two #6-32 socket cap head screws.
- Pull preamp board assembly outwards.




Figure 7-47. Preamp/Detector Removal

- Replace preamp/detector as needed and assemble in reverse order.

Note When reinstalling preamp board assembly, make sure the o-ring is seated properly. ▲

IR Source Replacement

The IR source control system has been designed to operate the wire wound resistor IR source conservatively in order to increase its life. Nevertheless, the IR source does have a finite life. Since the IR source is relatively inexpensive and easily replaced, it is recommended that the IR source be replaced after one year of continuous use. This will prevent loss of data due to IR source failure. If an IR source is to be replaced on an as needed basis, it should be replaced when:

- There is no light output
- After cleaning the optics, the IR light intensities remain below 100,000 Hz

It is not necessary to recalibrate the 48iQ after replacing the IR source since it is a ratio instrument, and replacing the IR source does not affect the calibration.

Use the following procedure to replace the IR source from DMC.

1. Turn the instrument OFF, unplug the power cord, and remove the cover.
2. Disconnect IR source cable as shown.




Figure 7-48. IR Source Cable Disconnect

3. Using a #1 Phillips drive, unfasten two #4-40 pan head screws.
4. Pull IR source assembly upwards.




Figure 7-49. IR Source Assembly Removal

5. Reinstall in reverse order.

Optional Manifold Replacement

Use the following procedure to replace the manifold.

Equipment required:

- Hex wrench, 9/16
- Hex drive, 9/64

1. Turn instrument OFF, unplug power cord, and remove the cover (Figure 2–1).
2. Unplug three electrical connections (J5, J6, and J8) from the step pol board 1.




Figure 7–50. Replacing the Manifold pt 1

3. Unfasten three nuts. Remove the nuts, front and back ferrules as shown from span, zero in, sample back panel (Figure 7–51).




Figure 7–51. Replacing the Manifold pt 2

4. Disconnect tubing.
5. Using a #2 Phillips drive, unfasten four #8-32 socket cap head screws.




Figure 7–52. Replacing the Manifold pt 3

6. Replace the manifold and assemble in reverse order.

Optional Zero Air Scrubber Replacement

Use the following procedure to replace the zero air scrubber.

Equipment required:

Hex drive, 9/16

1. Turn the instrument OFF, unplug the power cord, and remove the cover (Figure 2-1).
2. Disconnect plumbing.
3. Unfasten four #8-32 socket cap head screws.




Figure 7-53. Zero Air Scrubber Replacement

4. Replace zero air scrubber and reinstall in reverse order.

Optional DMC Oxygen Sensor

Use the following procedure to remove the oxygen sensor from the instrument case. It is easier to do the following by removing the oxygen sensor first then remove and replace the following as necessary:

- Oxygen Sensor removal
- Oxygen Sensor board replacement
- Oxygen Sensor capillary replacement
- Oxygen Sensor replacement

Oxygen Sensor Removal

Use the following procedure to remove and replace the oxygen sensor.

Equipment required:

Phillips drive, #2

1. Turn instrument OFF, unplug power cord, and remove the cover (Figure 2-1).
2. Unplug electrical, unplug DMC cable to oxygen sensor board DMC (J4).
3. Disconnect 2X plumbing.
4. Using a #2 Phillips drive, unfasten captive hardware.

Servicing

Optional DMC Oxygen Sensor




Figure 7–54. Oxygen Sensor Removal pt 1

5. Slide oxygen sensor assembly left.

Note Make sure oxygen sensor plate clears the edge and stud. ▲




Figure 7–55. Oxygen Sensor Removal pt 2

- Slide oxygen sensor assembly upwards.




Figure 7–56. Oxygen Sensor Removal pt 3

- Pull away from the partition panel.

Note Make sure oxygen sensor plate clears the edge. ▲




Figure 7–57. Oxygen Sensor Removal pt 4

Oxygen Sensor Board Replacement

Use the following procedure to replace the oxygen sensor board.

Equipment required:

Phillips drive, #2

1. Remove the oxygen sensor DMC from the instrument. Refer to “Oxygen Sensor Removal” on page 7-51.
2. Unplug J1.
3. Using a #2 Phillips drive, unfasten five #6-32 pan head screws.




Figure 7-58. Replacing the Oxygen Sensor DMC Board

4. Slide board upwards.

Note Clear keyway. ▲




Figure 7–59. Replacing the Oxygen Sensor DMC Board pt 2

5. Replace oxygen sensor board and reassemble in reverse order.

Oxygen Sensor Capillary Replacement

Use the following to replace the oxygen sensor capillary.

Equipment required:

Ball-end hex drive, 3/32

1. Remove the oxygen sensor DMC from the instrument. Refer to “Oxygen Sensor Removal” on page 7-51.
2. Using a 3/32 ball-end hex drive (angle alignment of screws), unfasten two #4-40 cap screws.
3. Unlock tube clamp.
4. Unplug tube after unlocking tube clamp.




Figure 7–60. Replacing the Oxygen Sensor Capillary




Figure 7–61. Replacing the Capillary pt 2

5. Replace capillary and reassemble in reverse order.

Oxygen Sensor Replacement

Use the following to replace the oxygen sensor.

Equipment required:

Phillips drive, #2

1. Remove the oxygen sensor DMC from the instrument. Refer to “Oxygen Sensor Removal” on page 7-51.
2. Unplug oxygen sensor cable.




Figure 7-62. Replacing the Oxygen Sensor

3. Using a #2 Phillips drive, unfasten three #6-32 flat head screws.
4. Disconnect tubing.
5. Pull out oxygen sensor
6. Replace oxygen sensor and reassemble in reverse order.

Chapter 8

System Description

The 48iQ deploys a set of modular subsystems that comprise the total instrument function. The core measurements for concentration are contained in Distributed Measurement and Control (DMC) modules. This chapter describes the function and location of the system components in the module framework, including firmware, electronics, and I/O function.

The 48iQ system components include:

- Optical Bench DMC
 - Optical Bench hardware with bandpass filters, mirrors, and heater cable
 - Filter Wheel and Motor sub-assembly
 - Filter Wheel Purge
 - Detector Preamp
 - Infrared source
 - Optical bench DMC board
- Common Electronics
 - Power supply
 - System Control board
 - Backplane board
 - Front panel
 - I/O (optional)
- Peripherals Support System
 - Fan (on rear panel)
 - STEP POL board
 - Sample Pump
 - Solenoid valve panel (optional)
- Flow Pressure DMC with flow restricting capillary
- Firmware

- Oxygen Sensor (optional)

Optical Bench DMC

The Optical Bench DMC contains the key components of the optical measurement that eventually results in CO concentration.

Optical Bench Hardware

The optical bench is an airtight bench that contains the sample gas. It also includes the mirrors that reflect infrared light multiple times across the sample path before detection, to maximize absorption. Heaters are used to maintain the optical bench at a constant temperature.

A bandpass filter limits the light entering the optical bench to a narrow band of the infrared within which CO absorbs.

Filter Wheel Motor

A gas filter wheel contains samples of CO and N₂ gas with a chopper disk. The wheel is rotated so that infrared light is periodically interrupted to produce a modulated signal upon detection. Differentiating the light through the CO and N₂ components of the wheel, in the presence of CO in the optical bench, allow the determination of sample CO absorption and concentration.

The chopper motor rotates the gas filter wheel and chopper disk at a uniform speed.

A separate optical switch assembly detects the position of the filter wheel for synchronizing the modulated signal and for checking the chopper motor speed.

Filter Wheel Purge

The filter wheel purge includes a housing attached between the optical bench and the motor plate. It surrounds the gas correlation wheel and allows purging the area around the gas correlation wheel with instrument air or a gas other than that present in the local atmosphere. This increases reliability in the presence of contaminants that could interfere with the analytical process. [Figure 8–1](#) shows how the filter wheel purge is configured within the instrument for an external purge gas supply. The instrument's default configuration allows for active flow of in instrument air through the filter wheel purge.




Figure 8–1. 48iQ Flow Schematic with Filter Wheel Purge

Calibration Note The stability of the purge gas is very important. Since this gas is in the same optical path as the sample, changes in the composition of the purge gas can change the calibration of the instrument. Therefore, either zero air or a non-toxic dry inert gas, such as nitrogen, is required as the purge gas.

A constant purge flow of approximately 140 cc/min is recommended for optimum performance. This is produced by feeding a purge gas to the rear panel bulkhead at a constant pressure of 10 psig. A fitting with a 0.010-inch laser drilled orifice delivers the required 140 cc/min purge flow. Flows greater than this are not recommended due to unstable cooling effects on the IR source. Lower flows are acceptable as long as the purge housing is adequately purged for the application. ▲

Detector Preamp

The detector/preamplifier assembly converts infrared light, carrying modulation and CO sample absorption, into an amplified electrical signal that undergoes processing.

Infrared Source

The infrared light source is a special wire-wound resistor operated at high temperature to generate broadband infrared radiation.

Optical Bench DMC Board

A single PCBA with microprocessor provides active controls for the above elements, performs preliminary data processing, and generates registers that interact with the higher level system controls.

Common Electronics

The common electronics contain the core computational and power routing hardware for the 48iQ, and is replicated throughout other iQ series products (Figure 8–2). It also contains front panel display, the USB ports, the Ethernet port, and the optional I/O interfaces (RS-485, analog, and digital).

Figure 8–3 shows the PCBA interconnect structure for the 48iQ, including options. The modular design of the instrument is conveyed in the architecture. Brief descriptions of the specific PCBAs follow.




Figure 8-3. 48iQ System Interconnect Diagram

Power Supply

All electronics operate from a universal VDC supply, which is capable of auto-sensing the input voltage and working over all specified operating ranges. The 48iQ contains a 24 VDC channel for most electronics operation, including the pump and fan, and a 48 VDC channel dedicated specifically for optical bench heating.

Front Panel

Front panel electronic components include the touch screen display, the on off switch, and two indicator LEDs for power and alarm status, as described in operational detail in Chapter 2, “[Installation and Setup](#)”.

I/O and Communication Components

The iQ series instruments provide a number of methods for communicating the instrument results to the operator or external equipment. Every iQ series instrument includes a front panel display, 3 USB ports, and one Ethernet data port as standard equipment.

In addition, optional RS-232/485, analog I/O, and digital I/O ports are available to provide data to external systems as described in Chapter 9, “[Connecting External Devices](#)”. The front panel GUI allows the operator to configure these output communication channels as described in Chapter 3, “[Operation](#)”.

System Controller Board

The System Controller Board (SCB) contains the main processor, power supplies, and a sub-processor, and serves as the communication hub for the instrument. The SCB receives operator inputs from the front panel GUI and/or over optional I/O connections on the rear panel. The SCB sends commands to the other boards to control the functions of the instrument and to collect measurement and diagnostic information. The SCB outputs instrument status and measurement data to the GUI, Ethernet/USB, and to the optional rear-panel I/O. The SCB plugs into the backplane via a single connector and has physical retainers to secure placement.

Backplane Board

The backplane board provides the routing and conditioning for +24 VDC (optional +48 VDC) and RS-485 communications within the instrument. It hosts the System Controller Board (SCB) and Peripherals Support Board (PSB) via direct plug ins, and similarly hosts optional I/O (communication, analog, and digital) with rear panel interfaces via direct plug in. It has connections for RS-485 communication with and powering of DMCs and the STEP POL Module. It additionally routes the front panel display and driver, external USB and Ethernet.

Peripherals Support System

The peripherals support system operates those additional devices that are needed, but do not require special feedback control or processing. These components are connected to a Peripherals Support Board (PSB).

The PSB microprocessor regulates the timing and health of such devices, and generates registers that interact with the higher level system controls.

Fan

The chassis fan provides air cooling of the active electronic components.

STEP POL Board

The STEP POL board provides high/low outputs for continuous operation or on/off states. The STEP POL board contains the basic circuitry to provide a programmable load to passive devices, either continuously, or on user or automated command. In the iQ Series instruments, the pump, solenoids, etc., are controlled off of the STEP POL board from commands generated via the PSB.

Sample Pump

Internal vacuum pump for generating air/sample through the instrument.

Solenoid Valve Panel (optional)

Optional solenoid valves for switching between sample, zero, and span gases, and other optional components.

Flow/Pressure DMC

The Flow/Pressure DMC is used measure instrument pressures that assure proper flow regulation and for sample pressure within the measurement bench for pressure corrections and compensation.

The DMC includes two pressure sensors that read 0–860 mmHg. These sensors are used with the coupled restricting capillary for flow control along with the downstream sample pump. The pressure differential determines the flow through the capillary. The upstream pressure is the measurement bench pressure, while the downstream pressure is at the pump inlet pressure.

Firmware

Like the hardware, the firmware is modular and located within microprocessors distributed throughout the instrument. In the 48iQ, microprocessors containing firmware are located as follows:

- Optical Bench DMC
- Flow/Pressure DMC

- Peripherals Support Board
- Optional I/O (Communications, Analog, and Digital)
- Optional Oxygen Sensor

The firmware contains the active controls for their application, as well as self-identification and configuration for “plug and play” style operation. Each are associated with specific registers of two types:

- Modbus registers that are communicated from each microprocessor to the System Controller Board (SCB) via internal RS-485
- SNMP registers that are maintained in the software and SCB for health and data processing computation

The Modbus communication system operates on 1 second intervals. Within those intervals, data treatment like integration (whether analog or digital) and servo control, are embedded in the module firmware. The SCB receives the 1 second updates for higher level “software” processing and control via SNMP registers, some of which is interfaced with the front panel Graphical User Interface (GUI).

In addition to the operating registers, the 48iQ stores a historical data log in a MySQL database. The memory is provided on the same μ SD card where the operating software resides, for which there is capability to store up to a year of data at 1 minute intervals. Chapter 3, “[Operation](#)” describes how this database is accessed and used including external memory downloads.

Oxygen Sensor (optional)

The 48iQ can be configured with an optional DMC based Oxygen (O_2) Sensor. This sensor is a paramagnetic sensor for O_2 concentration measurement and CO correction. This option allows the user to correct the CO readings for the amount of oxygen in the sample. Selectable O_2 concentrations can be used as the correction factor.

Chapter 9

Optional Equipment

The 48iQ is available with the following options:

Connecting External Devices

Several components are available for connecting external devices.

These connection options consist of three plug-in boards:

- Communication Board
- Analog I/O Board
- Digital I/O Board




Figure 9-1. I/O Expansion Replacement Boards

Communication Board

The communication board consists of:

- RS-232/485 Port
- RS-485 External Accessory Port

RS-232/RS-485 Port

The RS-232/RS-485 port uses a 9-pin serial connector with a bi-directional serial interface that can be configured for either RS-232 or RS-485 communication.




Figure 9–2. RS-232/RS-485 Port

Table 9–1. RS-232/RS-485 Port Terminal Assignment

| Terminal Number | Signal Name |
|-----------------|----------------|
| 1 | No Connect |
| 2 | RX/RS485_RX_P |
| 3 | TX/RS485_TX_N |
| 4 | No Connect |
| 5 | GND |
| 6 | No Connect |
| 7 | RTS/RS485_TX_P |
| 8 | CTS/RS485_RX_N |
| 9 | No Connect |

RS-485 External Accessory Port

The RS-485 external accessory port uses a 15-pin serial connector for communication with external smart devices.




Figure 9–3. RS-485 External Accessory Port

Table 9–2. RS-485 External Accessory Port Terminal Assignment

| Terminal Number | Signal Name |
|-----------------|--------------------|
| 1 | EXT_RS485_RX_N |
| 2 | EXT_RS485_RX_P |
| 3 | +5V (Fused @0.4A) |
| 4 | +5V (Fused @0.4A) |
| 5 | +5V (Fused @0.4A) |
| 6 | GND |
| 7 | GND |
| 8 | GND |
| 9 | EXT_RS485_TX_N |
| 10 | EXT_RS485_TX_P |
| 11 | +24V (Fused @0.4A) |
| 12 | +24V (Fused @0.4A) |
| 13 | +24V (Fused @0.4A) |
| 14 | +24V (Fused @0.4A) |
| 15 | +24V (Fused @0.4A) |

Analog I/O Board

The Analog I/O Board consists of:

- 4 Isolated Analog Voltage Inputs, Input Voltage Range: 0–10 V
- 6 Isolated Analog Voltage Outputs, Three Ranges: 0–1.0 V, 0–5.0 V, 0–10 V
- 6 Isolated Analog Current Outputs, Two Ranges: 0mA–20mA, 4mA–20mA

Analog Voltage Inputs

Table 9–3 lists the analog voltage inputs are used to monitor four external 0–10V signals.




Figure 9–4. Analog Voltage Inputs

Table 9–3. Analog Voltage Inputs Assignment

| Terminal Number | Signal Name |
|-----------------|-------------|
| 1 | Analog In 1 |
| 2 | Analog GND |
| 3 | Analog In 2 |
| 4 | Analog GND |
| 5 | Analog In 3 |
| 6 | Analog GND |
| 7 | Analog In 4 |
| 8 | Analog GND |

Analog Voltage Outputs

There are six globally isolated, 16-bit, Analog Output channels, each with a Voltage Output, a Current Output and a common Return (isolated ground). The Analog Outputs are configured through the software control registers to select Voltage Output ranges 0–1 V, 0–5 V or 0–10 V, as well as Current Output ranges 0–20 mA or 4–20 mA. The maximum allowable load for each Current Output is 1000 Ω . All Voltage Outputs and Current Outputs are continuously monitored separately for accuracy.

The Analog Outputs may be used to control and report parameters pertinent to the analyzers' measured functions.




Figure 9–5. Analog Voltage and Current

Table 9-4. Analog Voltage and Current Assignment

| Terminal Number | Signal Name |
|-----------------|---------------|
| 1 | Current Out 1 |
| 2 | Voltage Out 1 |
| 3 | C/V Return 1 |
| 4 | Current Out 2 |
| 5 | Voltage Out 2 |
| 6 | C/V Return 2 |
| 7 | Current Out 3 |
| 8 | Voltage Out 3 |
| 9 | C/V Return 3 |
| 10 | Current Out 4 |
| 11 | Voltage Out 4 |
| 12 | C/V Return 4 |
| 13 | Current Out 5 |
| 14 | Voltage Out 5 |
| 15 | C/V Return 5 |
| 16 | Current Out 6 |
| 17 | Voltage Out 6 |
| 18 | C/V Return 6 |

Analog Output Calibration

The iQ series instruments provide for the ability to calibrate the analog outputs (both voltage and current) of the instruments. The basic procedure for both voltage and current are the same using the following procedure:

- Complete the connections of the recording device to the desired analog output channel. (See page 9-5 for the channel information).
- Calibrate the output channel low level.

Note When calibrating the current output when using the 0-20 mA scale, the low level will be set to 4 mA due to the inability to adjust the actual current output to below zero. ▲


- Calibrate the output channel full scale.

Analog Output Zero Calibration


Use the following procedure to calibrate the output channel to low level. This analog output calibration procedure reflects the zero calibration for analog output voltage for demonstration purposes. To calibrate the 4 mA current calibration, follow the same procedure, by selecting the 4 mA current calibration option.

Note This adjustment should only be performed by an instrument service technician. ▲


1. From the Home screen, choose **Settings>Communications>Analog I/O>Analog Out Calibration.**



2. Depending on the output type being used, select either Analog Out Zero Calibration (Voltage) or Analog Out 4.000 mA Calibration (Current).



3. A confirmation screen is presented. Select Continue to proceed with the calibration or Return to Previous Screen.



4. There are six columns for each of the six available output channels:

| Channel | Output (V) | Decrease ↓↓ | Decrease ↓ | Increase ↑ | Increase ↑↑ | Commit |
|---------|------------|-------------|------------|------------|-------------|--------|
| 1 | 0.000 | ↓↓ | ↓ | ↑ | ↑↑ | Commit |
| 2 | 0.000 | ↓↓ | ↓ | ↑ | ↑↑ | Commit |
| 3 | 0.000 | ↓↓ | ↓ | ↑ | ↑↑ | Commit |
| 4 | 0.000 | ↓↓ | ↓ | ↑ | ↑↑ | Commit |
| 5 | 0.000 | ↓↓ | ↓ | ↑ | ↑↑ | Commit |
| 6 | 0.000 | ↓↓ | ↓ | ↑ | ↑↑ | Commit |

- *Output (V)*: Displays the actual output level at the terminal of the analog output board. For analog voltage, this value will default at zero. For analog current, this value will default at 4 mA.
- *Decrease ↓↓ and Decrease ↓*: Decreases the output by coarse or fine amounts
- *Increase ↑ and Increase ↑↑*: Increases the output by coarse and fine amounts.
- *Commit*: Accepts the changes to the analog output levels.

5. For the desired analog output channel, increase or decrease the output until the reading on the recording device indicates the proper value.

6. After making changes to the output levels, the commit button will turn green. To accept the changes, press the Commit button. To revert to the previous values, press the back button to return to the previous analog output calibration screen.

Analog Output Full Scale Calibration

Use the following procedure to calibrate the output channel to full scale. This analog output calibration procedure reflects the full scale calibration for analog output voltage for demonstration purposes. To calibrate the 20 mA current calibration, follow the same procedure, by selecting the 20 mA current calibration option.

Note This adjustment should only be performed by an instrument service technician. ▲


1. From the Home screen, choose **Settings>Communications>Analog I/O>Analog Output Calibration**.



2. Depending on the output type being used, select either Analog Out Full Scale Calibration (Voltage) or Analog Out 20.000 mA Calibration (Current).



3. A confirmation screen is presented. Select Continue to proceed with the calibration or Return to Previous Screen.



4. There are six columns for each of the six available output channels:

| Channel | Output (V) | Decrease | Decrease | Increase | Increase | Commit |
|---------|------------|----------|----------|----------|----------|--------|
| 1 | 5.000 | ↓↓ | ↓ | ↑ | ↑↑ | Commit |
| 2 | 1.000 | ↓↓ | ↓ | ↑ | ↑↑ | Commit |
| 3 | 10.000 | ↓↓ | ↓ | ↑ | ↑↑ | Commit |
| 4 | 1.000 | ↓↓ | ↓ | ↑ | ↑↑ | Commit |
| 5 | 1.000 | ↓↓ | ↓ | ↑ | ↑↑ | Commit |
| 6 | 1.000 | ↓↓ | ↓ | ↑ | ↑↑ | Commit |

- *Output (V)*: Displays the actual output level at the terminal of the analog output board. For analog voltage, this value will default at the setting of the output channel, 1, 5, or 10 V. For analog current, this value will default at 20 mA.
 - *Decrease ↓↓ and Decrease ↓*: Decreases the output by coarse or fine amounts
 - *Increase ↑ and Increase ↑↑*: Increases the output by coarse and fine amounts.
 - *Commit*: Accepts the changes to the analog output levels.
5. For the desired analog output channel, increase or decrease the output until the reading on the recording device indicates the proper value.
 6. After making changes to the output levels, the commit button will turn green. To accept the changes, press the Commit button. To revert to the previous values, press the back button to return to the previous analog output calibration screen.

Digital I/O Board

The digital I/O board consists of:

- 16 Digital Inputs (18 pin connector)
- 10 Digital Relay Switches (20 pin connector)
- 8 Valve Driver Outputs (16 pin connector)

Digital Inputs

The digital inputs are TTL (3 V or 5 V) compatible and are pulled high within the instrument. The active state can be user defined in firmware.

- Logic Low Threshold: 0.8 V
- Logic High Threshold: 2.0 V
- Absolute allowable input voltages: -0.5 to 5.5 V




Figure 9-6. Digital Inputs

Table 9–5. Digital Inputs Terminal Assignment

| Terminal Number | Signal Name |
|------------------------|--------------------|
| COMMON | |
| 1 | Digital In 1 |
| 2 | Digital In 2 |
| 3 | Digital In 3 |
| 4 | Digital In 4 |
| 5 | Digital In 5 |
| 6 | Digital In 6 |
| 7 | Digital In 7 |
| 8 | Digital In 8 |
| 9 | Digital In 9 |
| 10 | Digital In 10 |
| 11 | Digital In 11 |
| 12 | Digital In 12 |
| 13 | Digital In 13 |
| 14 | Digital In 14 |
| 15 | Digital In 15 |
| 16 | Digital In 16 |
| COMMON | |

Digital Relay Switches Table 9–6 lists the digital relay switches.

- Maximum Voltage: 300 VDC
- Maximum Current: 500 mA
- Fuse: 800 mA




Figure 9–7. Digital Relay Switches

Table 9-6. Digital Relay Switch Assignment

| Terminal Number | Signal Name |
|------------------------|--------------------|
| 1A | Relay 1A |
| 1B | Relay 1B |
| 2A | Relay 2A |
| 2B | Relay 2B |
| 3A | Relay 3A |
| 3B | Relay 3B |
| 4A | Relay 4A |
| 4B | Relay 4B |
| 5A | Relay 5A |
| 5B | Relay 5B |
| 6A | Relay 6A |
| 6B | Relay 6B |
| 7A | Relay 7A |
| 7B | Relay 7B |
| 8A | Relay 8A |
| 8B | Relay 8B |
| 9A | Relay 9A |
| 9B | Relay 9B |
| 10A | Relay 10A |
| 10B | Relay 10B |

Valve Driver Outputs

Table 9–7 lists the valve driver outputs.

- Actual Output Voltage: 22–24 VDC
- Maximum Current: 300 mA
- Both positive and negative outputs are protected from over voltage and over current by 500 mA fuses.




Figure 9–8. Valve Driver Outputs

Table 9–7. Valve Driver Outputs Assignment

| Terminal Number | Signal Name |
|------------------------|--------------------|
| 1+ | Valve Drive 1+ |
| 1- | Valve Drive 1- |
| 2+ | Valve Drive 2+ |
| 2- | Valve Drive 2- |
| 3+ | Valve Drive 3+ |
| 3- | Valve Drive 3- |
| 4+ | Valve Drive 4+ |
| 4- | Valve Drive 4- |
| 5+ | Valve Drive 5+ |
| 5- | Valve Drive 5- |
| 6+ | Valve Drive 6+ |
| 6- | Valve Drive 6- |
| 7+ | Valve Drive 7+ |
| 7- | Valve Drive 7- |
| 8+ | Valve Drive 8+ |
| 8- | Valve Drive 8- |

Note Intended for 24 V valves. These outputs will also drive any DC load of 22–24 VDC, up to 300 mA. ▲

Internal Zero/Span Assembly

With the internal zero/span assembly option, a source of span gas is connected to the SPAN port and a source of zero air is connected to the ZERO port. Zero and span gas should be supplied at atmospheric pressure. It may be necessary to use an atmospheric dump bypass plumbing arrangement to accomplish this. Figure 9–9 shows how this option is integrated with the instrument.




Figure 9–9. 48iQ Flow Schematic with Zero Span and Zero Air Scrubber

Internal Oxygen (O₂) Sensor

The Internal Oxygen (O₂) Sensor option provides a paramagnetic sensor for O₂ concentration measurement and CO correction. This option allows the user to correct the CO readings for the amount of oxygen in the sample. Selectable O₂ concentrations can be used as the correction factor.

Figure 9–10 shows how this option is integrated with the 48iQ.




Figure 9–10. 48iQ Flow Schematic with Internal O₂ Sensor

Internal Zero Air Scrubber

The internal air scrubber is mounted inside the instrument and provides a source of zero air. Figure 9–9 shows how this option is integrated with the instrument.

PTFE Particulate Filter

A 5–10 micron pore size, two-inch diameter PTFE element is available for the 48iQ. This filter should be installed just prior to the SAMPLE bulkhead. When using a filter, all calibrations and span checks must be performed through the filter.

Appendix A

Safety, Warranty, and WEEE





Safety

Review the following information carefully before using the instrument. This manual provides specific information on how to operate the instrument, however if the instrument is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.



Safety and Equipment Damage Alerts

This manual contains important information to alert you to potential safety hazards and risks of equipment damage. Refer to the following types of alerts you may see in this manual.

Safety and Equipment Damage Alert Descriptions

| Alert | Description |
|---|--|
|  | <ul style="list-style-type: none"> A hazard is present that will result in death or serious personal injury if the warning is ignored. ▲ |
|  | <ul style="list-style-type: none"> A hazard is present or an unsafe practice can result in serious personal injury if the warning is ignored. ▲ |
|  | <ul style="list-style-type: none"> The hazard or unsafe practice could result in minor to moderate personal injury if the warning is ignored. ▲ |
|  Equipment Damage | <ul style="list-style-type: none"> The hazard or unsafe practice could result in property damage if the warning is ignored. ▲ |

Safety and Equipment Damage Alerts in this Manual

| Alert | Description |
|---|--|
|  | <ul style="list-style-type: none"> If the equipment is operated in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired. ▲ The service procedures in this manual are restricted to qualified service personnel only. ▲ |
|  Equipment Damage | <ul style="list-style-type: none"> Do not attempt to lift the analyzer by the cover or other external fittings. ▲ This adjustment should only be performed by an instrument service technician. ▲ |

Warranty

Seller warrants that the Products will operate or perform substantially in conformance with Seller's published specifications and be free from defects in material and workmanship, when subjected to normal, proper and intended usage by properly trained personnel, for the period of time set forth in the product documentation, published specifications or package inserts. If a period of time is not specified in Seller's product documentation, published specifications or package inserts, the warranty period shall be one (1) year from the date of shipment to Buyer for equipment and ninety (90) days for all other products (the "Warranty Period"). Seller agrees during the Warranty Period, to repair or replace, at Seller's option, defective Products so as to cause the same to operate in substantial conformance with said published specifications; provided that (a) Buyer shall promptly notify Seller in writing upon the discovery of any defect, which notice shall include the product model and serial number (if applicable) and details of the warranty claim; (b) after Seller's review, Seller will provide Buyer with service data and/or a Return Material Authorization ("RMA"), which may include biohazard decontamination procedures and other product-specific handling instructions; and (c) then, if applicable, Buyer may return the defective Products to Seller with all costs prepaid by Buyer. Replacement parts may be new or refurbished, at the election of Seller. All replaced parts shall become the property of Seller. Shipment to Buyer of repaired or replacement Products shall be made in accordance with the Delivery provisions of the Seller's Terms and Conditions of Sale. Consumables, including but not limited to lamps, fuses, batteries, bulbs and other such expendable items, are expressly excluded from the warranty under this warranty.

Notwithstanding the foregoing, Products supplied by Seller that are obtained by Seller from an original manufacturer or third party supplier are not warranted by Seller, but Seller agrees to assign to Buyer any warranty rights in such Product that Seller may have from the original manufacturer or third party supplier, to the extent such assignment is allowed by such original manufacturer or third party supplier.

In no event shall Seller have any obligation to make repairs, replacements or corrections required, in whole or in part, as the result of (i) normal wear and tear, (ii) accident, disaster or event of force majeure, (iii) misuse, fault or negligence of or by Buyer, (iv) use of the Products in a manner for which they were not designed, (v) causes external to the Products such as, but not limited to, power failure or electrical power surges, (vi) improper storage and handling of the Products or (vii) use of the Products in combination with equipment or software not supplied by Seller. If Seller determines that Products for which Buyer has requested warranty services are not covered by the warranty hereunder, Buyer shall pay or reimburse Seller for all costs of investigating and responding to such request at Seller's then

prevailing time and materials rates. If Seller provides repair services or replacement parts that are not covered by the warranty provided in this warranty, Buyer shall pay Seller therefor at Seller's then prevailing time and materials rates. ANY INSTALLATION, MAINTENANCE, REPAIR, SERVICE, RELOCATION OR ALTERATION TO OR OF, OR OTHER TAMPERING WITH, THE PRODUCTS PERFORMED BY ANY PERSON OR ENTITY OTHER THAN SELLER WITHOUT SELLER'S PRIOR WRITTEN APPROVAL, OR ANY USE OF REPLACEMENT PARTS NOT SUPPLIED BY SELLER, SHALL IMMEDIATELY VOID AND CANCEL ALL WARRANTIES WITH RESPECT TO THE AFFECTED PRODUCTS.

THE OBLIGATIONS CREATED BY THIS WARRANTY STATEMENT TO REPAIR OR REPLACE A DEFECTIVE PRODUCT SHALL BE THE SOLE REMEDY OF BUYER IN THE EVENT OF A DEFECTIVE PRODUCT. EXCEPT AS EXPRESSLY PROVIDED IN THIS WARRANTY STATEMENT, SELLER DISCLAIMS ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, ORAL OR WRITTEN, WITH RESPECT TO THE PRODUCTS, INCLUDING WITHOUT LIMITATION ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. SELLER DOES NOT WARRANT THAT THE PRODUCTS ARE ERROR-FREE OR WILL ACCOMPLISH ANY PARTICULAR RESULT.

WEEE Compliance


This product is required to comply with the European Union's Waste Electrical & Electronic Equipment (WEEE) Directive 2002/96/EC. It is marked with the following symbol:



Thermo Fisher Scientific has contracted with one or more recycling/disposal companies in each EU Member State, and this product should be disposed of or recycled through them. Further information on Thermo Fisher Scientific's compliance with these Directives, the recyclers in your country, and information on Thermo Fisher Scientific products which may assist the detection of substances subject to the RoHS Directive are available at: www.thermoscientific.com/WEEERoHS.

WEEE Symbol

The following symbol and description identify the WEEE marking used on the instrument and in the associated documentation.

| Symbol | Description |
|---|---|
|  | Marking of electrical and electronic equipment which applies to electrical and electronic equipment falling under the Directive 2002/96/EC (WEEE) and the equipment that has been put on the market after 13 August 2005. ▲ |

Appendix B

Quick Reference

List of Figures

| | |
|--|------|
| Figure 1–1. 48iQ Front | 1-2 |
| Figure 1–2. 48iQ Flow Schematic..... | 1-4 |
| Figure 1–3. 48iQ Flow Schematic with Zero Span and Zero Air Scrubber..... | 1-4 |
| Figure 1–4. Bench Mount Assembly (dimensions in inches [mm]) | 1-7 |
| Figure 1–5. Rack Mount Assembly (dimensions in inches [mm]) | 1-8 |
| Figure 1–6. Rack Mount Requirements..... | 1-9 |
| Figure 1–7. Rack Requirements Part 2 | 1-9 |
| Figure 2–1. Removing the Cover..... | 2-2 |
| Figure 2–2. Installing Feet | 2-3 |
| Figure 2–3. Removing the Front Panel | 2-4 |
| Figure 2–4. Installing Ears and Handles..... | 2-5 |
| Figure 2–5. 48iQ Rear Panel | 2-7 |
| Figure 2–6. Atmospheric Dump Bypass Plumbing | 2-7 |
| Figure 2–7. Front Panel and Touchscreen Display | 2-8 |
| Figure 4–1. Calibration Flow Schematic | 4-3 |
| Figure 5–1. Single Stage Pump | 5-2 |
| Figure 5–2. Pump Rebuilding..... | 5-4 |
| Figure 5–3. Removing the Field Mirror..... | 5-6 |
| Figure 7–1. Properly Grounded Antistatic Wrist Strap | 7-2 |
| Figure 7–2. 48iQ Component Layout Top View | 7-4 |
| Figure 7–3. 48iQ Component Layout Side View..... | 7-4 |
| Figure 7–4. Replacing the Fuses..... | 7-5 |
| Figure 7–5. Start with Top Right Corner of Fan Cover | 7-6 |
| Figure 7–6. Removing the Fan Cover..... | 7-6 |
| Figure 7–7. Unplugging the Fan Cable | 7-7 |
| Figure 7–8. Replacing the Fan | 7-8 |
| Figure 7–9. Unplugging the Fan Cable | 7-9 |
| Figure 7–10. Unplugging the DMC Cable..... | 7-10 |
| Figure 7–11. Unfasten Hardware Front for Measurement Side Removal | 7-10 |
| Figure 7–12. Unfasten Hardware Rear for Measurement Side Removal..... | 7-11 |
| Figure 7–13. Replacing the LCD Module..... | 7-12 |
| Figure 7–14. Remove Electrical Cables from LCD..... | 7-13 |

Quick Reference

List of Figures

| | |
|--|------|
| Figure 7–15. I/O Replacement, Arm | 7-14 |
| Figure 7–16. I/O Replacement, Remove Board | 7-14 |
| Figure 7–17. I/O Replacement, Install | 7-15 |
| Figure 7–18. I/O Replacement, Close Arm Alignment | 7-15 |
| Figure 7–19. Replacing the Peripherals Support Board | 7-16 |
| Figure 7–20. Flow Pressure Board, Disconnect DMC Cable | 7-17 |
| Figure 7–21. Flow Pressure Board, Screws | 7-18 |
| Figure 7–22. Remove Pump, Disconnect and Unfasten | 7-20 |
| Figure 7–23. Pump Removal, Keyway..... | 7-21 |
| Figure 7–24. Pump replacing, Unfasten Screws | 7-21 |
| Figure 7–25. Remove Capillary, Disconnect and Unfasten | 7-22 |
| Figure 7–26. Capillary Plate, Keyway | 7-23 |
| Figure 7–27. Capillary and O-Ring Replace | 7-23 |
| Figure 7–28. Removing Power Supply | 7-25 |
| Figure 7–29. Replacing Power Supply | 7-25 |
| Figure 7–30. Unplug and Unfasten Step POL Board..... | 7-26 |
| Figure 7–31. Clear Partition Keyway Step POL Board..... | 7-27 |
| Figure 7–32. Step POL Board 1 Switch Settings | 7-28 |
| Figure 7–33. Optional Step POL Board 2 Switch Settings | 7-28 |
| Figure 7–34. DMC Layout..... | 7-29 |
| Figure 7–35. DMC Removal from Instrument..... | 7-30 |
| Figure 7–36. Motor and Filter Removal pt 1 | 7-31 |
| Figure 7–37. Motor and Filter Removal (pt 2)..... | 7-32 |
| Figure 7–38. Motor and Filter Optical Switch Replacement (pt 3) | 7-33 |
| Figure 7–39. Purge Housing Removal from Motor Assembly (pt 4)..... | 7-34 |
| Figure 7–40. Filter Wheel..... | 7-36 |
| Figure 7–41. Motor Removal from Motor Mount pt 1 | 7-37 |
| Figure 7–42. Motor Removal | 7-38 |
| Figure 7–43. Motor Installation Shaft Alignment | 7-40 |
| Figure 7–44. Bench Removal pt 1 | 7-41 |
| Figure 7–45. Heater Removal | 7-42 |
| Figure 7–46. Preamp Detector Cover Removal pt 1 | 7-43 |
| Figure 7–47. Preamp/Detector Removal..... | 7-44 |
| Figure 7–48. IR Source Cable Disconnect..... | 7-46 |
| Figure 7–49. IR Source Assembly Removal | 7-47 |
| Figure 7–50. Replacing the Manifold pt 1 | 7-48 |
| Figure 7–51. Replacing the Manifold pt 2 | 7-49 |
| Figure 7–52. Replacing the Manifold pt 3 | 7-49 |
| Figure 7–53. Zero Air Scrubber Replacement | 7-50 |
| Figure 7–54. Oxygen Sensor Removal pt 1 | 7-52 |

Figure 7–55. Oxygen Sensor Removal pt 2 7-52
Figure 7–56. Oxygen Sensor Removal pt 3 7-53
Figure 7–57. Oxygen Sensor Removal pt 4 7-53
Figure 7–58. Replacing the Oxygen Sensor DMC Board 7-54
Figure 7–59. Replacing the Oxygen Sensor DMC Board pt 2 7-55
Figure 7–60. Replacing the Oxygen Sensor Capillary 7-56
Figure 7–61. Replacing the Capillary pt 2 7-57
Figure 7–62. Replacing the Oxygen Sensor 7-58
Figure 8–1. 48iQ Flow Schematic with Filter Wheel Purge 8-3
Figure 8–2. Common System Interconnect Diagram 8-5
Figure 8–3. 48iQ System Interconnect Diagram 8-6
Figure 9–1. I/O Expansion Replacement Boards 9-1
Figure 9–2. RS-232/RS-485 Port 9-2
Figure 9–3. RS-485 External Accessory Port 9-3
Figure 9–4. Analog Voltage Inputs 9-4
Figure 9–5. Analog Voltage and Current 9-5
Figure 9–6. Digital Inputs 9-11
Figure 9–7. Digital Relay Switches 9-13
Figure 9–8. Valve Driver Outputs 9-15
Figure 9–9. 48iQ Flow Schematic with Zero Span and Zero Air Scrubber 9-17
Figure 9–10. 48iQ Flow Schematic with Internal O₂ Sensor 9-18

List of Tables

Table 1–1. 48iQ Specifications 1-5
Table 1–2. 48iQ Optional Internal Oxygen Sensor Specifications 1-6
Table 3–1. Data Logging Variables 3-39
Table 3–2. Streaming Data Variables 3-42
Table 6–1. 48iQ Troubleshooting Guide 6-1
Table 9–1. RS-232/RS-485 Port Terminal Assignment 9-2
Table 9–2. RS-485 External Accessory Port Terminal Assignment 9-3
Table 9–3. Analog Voltage Inputs Assignment 9-4
Table 9–4. Analog Voltage and Current Assignment 9-6
Table 9–5. Digital Inputs Terminal Assignment 9-12
Table 9–6. Digital Relay Switch Assignment 9-14
Table 9–7. Valve Driver Outputs Assignment 9-16

Appendix C

GNU Lesser General Public License

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc.

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE,
THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT
PERMITTED BY APPLICABLE LAW.

The Open Source code used in the development of this product will be provided for a period of 3-years from date of purchase to the original purchaser provided they supply Thermo Fisher Scientific with the applicable serial number for the product the Open Source code is being requested for.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages--typically libraries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it;

that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use

the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) The modified work must itself be a software library.
- b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
- c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.
- d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.

(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy. This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is

called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is

understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

- b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.
- c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.
- d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.
- e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

- a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.
- b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR

ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the library's name and a brief idea of what it does.>

Copyright (C) <year> <name of author>

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Also add information on how to contact you by electronic and paper mail.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the library `Frob' (a library for tweaking knobs) written by James Random Hacker.

<signature of Ty Coon>, 1 April 1990

Ty Coon, President of Vice

That's all there is to it!

Nokia Qt LGPL Exception version 1.1

As an additional permission to the GNU Lesser General Public License version 2.1, the object code form of a "work that uses the Library" may incorporate material from a header file that is part of the Library. You may distribute such object code under terms of your choice, provided that:

- (i) the header files of the Library have not been modified; and
- (ii) the incorporated material is limited to numerical parameters, data structure layouts, accessors, macros, inline functions and templates; and
- (iii) you comply with the terms of Section 6 of the GNU Lesser General Public License version 2.1.

Moreover, you may apply this exception to a modified version of the Library, provided that such modification does not involve copying material from the Library into the modified Library's header files unless such material is limited to (i) numerical parameters; (ii) data structure layouts; (iii) accessors; and (iv) small macros, templates and inline functions of five lines or less in length.

Furthermore, you are not required to apply this additional permission to a modified version of the Library.

thermoscientific



USA

27 Forge Parkway
Franklin, MA 02038
Ph: (508) 520-0430
Fax: (508) 520-2800
orders.aqi@thermofisher.com

India

C/327, TTC Industrial Area
MIDC Pawane
New Mumbai 400 705, India
Ph: +91 22 4157 8800
india@thermofisher.com

China

+Units 702-715, 7th Floor
Tower West, Yonghe
Beijing, China 100007
Ph: +86 10 84193588
info.eid.china@thermofisher.com

Europe

Ion Path, Road Three,
Winsford, Cheshire CW73GA UK
Ph: +44 1606 548700
Fax: +44 1606 548711
sales.epm.uk@thermofisher.com

Find out more at thermofisher.com/48iQ

ThermoFisher
SCIENTIFIC