

# CERTIFICATE

## of Product Conformity (QAL1)

Certificate No.: 0000040212\_04

**AMS designation:** Fidas® 200 S, Fidas® 200 and Fidas® 200 E  
for suspended particulate matter PM<sub>10</sub> and PM<sub>2.5</sub>

**Manufacturer:** PALAS GmbH  
Greschbachstraße 3b  
76229 Karlsruhe  
Germany

**Test Laboratory:** TÜV Rheinland Energy GmbH

**This is to certify that the AMS has been tested and certified according to the standards VDI 4202-1 (2010), VDI 4203-3 (2010), EN 12341 (1998), EN 14907 (2005), EN 16450 (2017), Guide to the demonstration of equivalence of ambient air monitoring methods (2010), EN 15267-1 (2009) and EN 15267-2 (2009).**

Certification is awarded in respect of the conditions stated in this certificate (this certificate contains 13 pages).

The present certificate replaces certificate 0000040212\_03 of 28 February 2017.



Suitability Tested  
Complying with  
2008/50/EC  
EN 15267  
Regular  
Surveillance

www.tuv.com  
ID 0000040212

Publication in the German Federal Gazette  
(BAnz) of 26 August 2015

This certificate will expire on:  
31 March 2019

German Federal Environment Agency  
Dessau, 13 April 2018

TÜV Rheinland Energy GmbH  
Cologne, 12 April 2018

  
Dr. Marcel Langner  
Head of Section II 4.1

  
ppa. Dr. Peter Wilbring

[www.umwelt-tuv.eu](http://www.umwelt-tuv.eu)  
[tre@umwelt-tuv.eu](mailto:tre@umwelt-tuv.eu)  
Phone: + 49 221 806-5200

TÜV Rheinland Energy GmbH  
Am Grauen Stein  
51105 Köln

Test institute accredited to EN ISO/IEC 17025:2005 by DAkkS (German Accreditation Body).  
This accreditation is limited to the accreditation scope defined in the enclosure to the certificate D-PL-11120-02-00.

<b>Test Report:</b>	936/21227195/C dated 12 October 2016
<b>Initial certification:</b>	01 April 2014
<b>Expiry date:</b>	31 March 2019
<b>Publication:</b>	BAnz AT 26.08.2015 B4, chapter III number 2.1

### Approved application

The certified AMS is suitable for continuous and simultaneous ambient air monitoring of suspended particulate matter, PM<sub>10</sub> and PM<sub>2.5</sub> (stationary operation).

The suitability of the AMS for this application was assessed on the basis of a laboratory test and a sixteen-months field test.

The Fidas® 200 S version of the instrument is approved for an ambient temperature range of -20 °C to +50 °C. The Fidas® 200 and Fidas® 200 E versions of the instrument are approved for an ambient temperature range of +5 °C to +40 °C.

The notification of suitability of the AMS, performance testing and the uncertainty calculation have been effected on the basis of the regulations applicable at the time of testing. As changes in legal provisions are possible, any potential user should ensure, in consultation with the manufacturer, that this AMS is suitable for monitoring the limit values relevant to the application.

Any potential user should ensure, in consultation with the manufacturer, that this AMS is suitable for the planned operation purpose.

### Basis of the certification

This certification is based on:

- Test report 936/21227195/C dated 12 October 2016 and addendum 936/21239834/A dated 1 September 2017 issued by TÜV Rheinland Energy GmbH
- Suitability announced by the German Federal Environment Agency (UBA) as the relevant body
- The ongoing surveillance of the product and the manufacturing process

Publication in the German Federal Gazette: BAnz AT 26.08.2015 B4, chapter III number 2.1, UBA announcement dated 22 July 2015:

**AMS designation:**

Fidas<sup>®</sup> 200 S respectively Fidas<sup>®</sup> 200 for suspended particulate matter PM<sub>10</sub> and PM<sub>2.5</sub>

**Manufacturer:**

PALAS GmbH, Karlsruhe

**Field of application:**

For continuous and simultaneous ambient air monitoring suspended particulate matter, PM<sub>10</sub> and PM<sub>2.5</sub> fractions (stationary sources)

**Measuring ranges during performance testing:**

Component	Certification range	Unit
PM <sub>10</sub>	0–10 000	µg/m <sup>3</sup>
PM <sub>2.5</sub>	0–10 000	µg/m <sup>3</sup>

**Software version:**

100380.0014.0001.0001.0011

**Restrictions:**

None

**Notes:**

1. The Fidas<sup>®</sup> 200 S measuring system is also available as an indoor-version for installation at temperature-controlled locations. It is then called Fidas<sup>®</sup> 200.
2. Both, the four comparison campaigns (initial testing) and the six comparison campaigns (supplementary testing) meet the requirements for PM<sub>10</sub> and PM<sub>2.5</sub> stipulated by the Guide to "Demonstration of Equivalence of Ambient Air Monitoring Methods".
3. One of the tested instrument tested at the site in Cologne in the summer failed to meet the requirements for the variation coefficient R<sup>2</sup> in accordance with standard EN 12341 (1998 version).
4. The particle sensor's sensitivity has to be checked on a monthly basis using CalDust 1100 or MonoDust 1500.
5. The measuring system must be calibrated on site at regular intervals by using the gravimetric PM<sub>2.5</sub> and PM<sub>10</sub> reference method according to EN 12341 (2014 version).
6. The test report on performance testing is available on the internet at [www.qal1.de](http://www.qal1.de).
7. Supplementary testing (extended equivalence testing, presentation of design changes, inclusion of the MonoDust1500 test standard) as regards Federal Environment Agency notices of 27 February 2014 (BAnz AT 01.04.2014 B12, chapter IV number 5.1) and of 25 February 2015 (BAnz AT 02.04.2015 B5 chapter IV 14<sup>th</sup> notification).

**Test Report:**

TÜV Rheinland Energie und Umwelt GmbH, Cologne  
Report no.: 936/21227195/A dated 9 March 2015

Publication in the German Federal Gazette: BAnz AT 14.03.2016 B7, chapter V  
notification 6, UBA announcement dated 18 February 2016:

**6 Notification as regards Federal Environment Agency (UBA) notice  
of 22 July 2015 (BAnz AT 26.08.2015 B4, chapter III number 2.1)**

A mistake regarding the description of the IADS-control functions was detected in the manual for the Fidas® 200 S respectively the Fidas® 200 measuring system for PM<sub>10</sub> and PM<sub>2.5</sub> manufactured by PALAS GmbH. The description should correctly read as follows:

*“The temperature of the IADS is controlled as a function of the ambient temperature and humidity (as measured by the weather station). The minimum temperature is 23°C. Moisture compensation is ensured via a dynamic adjustment of the IADS temperature up to a maximum heat capacity of 90 Watt.”*

The manufacturer corrected this mistake as of manual version V0140815. Test report 936/21227195/A dated 9 March 2015 issued by TÜV Rheinland Energie und Umwelt GmbH was corrected accordingly and replaced by test report 936/21227195/B dated 5 October 2015.

The measuring system can alternatively be operated with a WS300-UMB weather station. An extended IADS adaptable for lengths between 1.20m and 2.10m is available for the measuring system.

Furthermore, the Fidas® 200 E version of the measuring system may be used with an external sensor.

The current software version is: 100396.0014.0001.0001.0011

Statement issued by TÜV Rheinland Energie und Umwelt GmbH  
dated 6 November 2015

Publication in the German Federal Gazette: BAnz AT 01.08.2016 B11, chapter V notification 35, UBA announcement dated 14 July 2016:

**35 Notification as regards Federal Environment Agency (UBA) notices of 27 February 2014 (BAnz AT 01.04.2014 B12, chapter IV number 5.1) and of 18 February 2016 (BAnz AT 14.03.2016 B7, chapter V 6<sup>th</sup> notification)**

The sensitivity test of the particle sensor for the Fidas® 200, Fidas® 200 S or Fidas® 200 E for PM<sub>10</sub> and PM<sub>2.5</sub> particle monitor with MonoDust 1500 manufactured by PALAS GmbH can be performed at an IADS temperature 35 °C or 50 °C.

The measuring system may provide two additional contacts for the control of an external pump/flow regulator (not relevant for the performance-tested instrument version).

The current software version of the measuring system is:  
100408.0014.0001.0001.0011

Statement issued by TÜV Rheinland Energie und Umwelt GmbH  
dated 24 February 2016

Publication in the German Federal Gazette: BAnz AT 15.03.2017 B6, chapter V notification 10, UBA announcement dated 22 February 2017:

**10 Notification as regards Federal Environment Agency (UBA) notices of 27 February 2014 (BAnz AT 01.04.2014 B12, chapter IV number 5.1) and of 14 July 2016 (BAnz AT 01.08.2016 B11, chapter V 35<sup>th</sup> notification)**

The particle sensor's sensitivity of the Fidas® 200, Fidas® 200 S and Fidas® 200 E for PM<sub>10</sub> and PM<sub>2.5</sub> manufactured by PALAS GmbH has to be checked every three month using CalDust 1100 or MonoDust 1500.

These measuring systems may alternatively be used with the Siargo FS4008-10-O6-CV-A flow sensor instead of the Honeywell AWM5102VN model used so far.

The new temperature compensation factors for each instrument are as follows: 0.15 (Fidas® 200 S), 0.19 (Fidas® 200 E) and 0.17 (Fidas® 200).

To ensure effective heating for the outdoor enclosure of the Fidas® 200 S AMS variant the fan heater has been repositioned. The air flow produced by the fan heater now flows from the bottom to the top of the enclosure.

A mistake in the test report no. 936/21227195/B dated 5 October 2015 prepared by TÜV Rheinland Energie und Umwelt GmbH has been corrected. Instead of a 30-minute moving average as stated in two instances in the report, the Fidas® 200 S, Fidas® 200 E and Fidas® 200 ambient air quality monitors operate with a moving average over 900s (15 minutes). Report no. 936/21227195/C dated 12 October 2016 prepared by TÜV Rheinland Energy GmbH replaces the report referred to above.

The current software version of the measuring system is:  
100417.0014.0001.0001.0011.

Statement issued by TÜV Rheinland Energy GmbH dated 12 October 2016

Publication in the German Federal Gazette: BAnz AT 31.07.2017 B12, chapter II notification 30, UBA announcement dated 13 July 2017:

**30 Notification as regards Federal Environment Agency (UBA) notices of 27 February 2014 (BAnz AT 01.04.2014 B12, chapter IV number 5.1) and of 22 February 2017 (BAnz AT 15.03.2017 B6, chapter V 10<sup>th</sup> notification)**

The current software version for the Fidas® 200, Fidas® 200 S and Fidas® 200 E monitoring PM<sub>10</sub> and PM<sub>2,5</sub> manufactured by PALAS GmbH is:  
100427.0014.0001.0001.0011

Statement issued by TÜV Rheinland Energy GmbH dated 7 March 2017

Publication in the German Federal Gazette: BAnz AT 26.03.2018 B8, chapter V notification 10, UBA announcement dated 21 February 2018:

**10 Notification as regards Federal Environment Agency (UBA) notices 27 February 2014 (BAnz AT 01.04.2014 B12, chapter IV number 5.1) and of 13 July 2017 (BAnz AT 31.07.2017 B12, chapter II 30<sup>th</sup> notification)**

The Fidas® 200, Fidas® 200 S and Fidas® 200 E measuring systems for PM<sub>10</sub> and PM<sub>2,5</sub> manufactured by PALAS GmbH meet the requirements of standard EN 16450 (July 2017 version). An addendum no. 936/21239834/A as integral part of test report is available online at [www.qal1.de](http://www.qal1.de).

The current software versions are:

100430.0014.0001.0001.0011  
100431.0014.0001.0001.0011  
100434.0014.0001.0001.0011

Statement issued by TÜV Rheinland Energy GmbH dated 8 September 2017

### Certified product

This certification applies to automated measurement systems conforming to the following description:

The Fidas® 200 S, Fidas® 200 and Fidas® 200 E are optical aerosol sensors which determine the particle size and number using scattered light on single particles in accordance with Lorenz-Mie. For the determination of mass concentrations, particle size and count distributions are converted using a size-dependent and weighted evaluation algorithm.

The measuring system is available as instrument versions Fidas® 200 S (for use outdoors, incl. protective enclosure), Fidas® 200 (for installation at temperature controlled sites such as air-conditioned measurement stations) and as Fidas® 200 E (as Fidas® 200, but with external sensor unit).

The tested measuring system consists of a Sigma-2 sampling head, the sampling tube with IADS humidity compensation module (standard or long version), the Fidas® control unit with integrated aerosol sensor (Fidas® 200 S or Fidas® 200) or with external sensor unit

(Fidas® 200 E), the compact WS600-UMB or WS300-UMB weather station, the optional UMTS receiver, a weather-proof housing (IP 65, Fidas® 200 S only), the required connecting lines and cables, a CalDust 1100 or MonoDust 1500 bottle and the relevant manuals in German.

At a flow rate of 4.8 l/min (at 25 °C and 1013 hPa), the particle sample passes through the Sigma-2 sampling head and reaches the sampling tube which connects the sampling head to the Fidas control unit. In order to avoid water condensation effects especially at high ambient humidity, the IADS humidity compensation module is used. The IADS was controlled in relation to ambient temperature and moisture (as measured using a compact weather station). The minimum temperature is 23 °C. Moisture compensation is ensured via a dynamic adjustment of the IADS temperature up to a maximum heat capacity of 90 Watt. The IADS module is controlled via the Fidas firmware. After passing through the IADS module, the particle sample finally reaches the aerosol sensor which is where the actual measurement takes place. Downstream of the aerosol sensor, the sample passes through an absolute filter which may be used for further analyses of the collected aerosol. The Fidas® 200 S, Fidas® 200 and Fidas® 200 E measuring systems also come with an integrated weather station (type Lufft WS300-UMB for recording parameters such as wind speed, wind direction, precipitation rates, type of precipitation, temperature, humidity and pressure; the alternative is the Lufft WS600-UMB for recording temperature, humidity and pressure). The measuring system's control unit does not only provide the necessary electronics for operating the system, but also 2 sampling pumps, which are connected in parallel. If one pump fails, the other one takes over to ensure smooth operation.

The Fidas® 200 S, Fidas® 200 and Fidas® 200 E measuring systems store data in the raw-format. To determine mass concentration values, the stored raw data will have to be converted with the help of evaluation algorithm. To this effect, a size-dependent and weighted algorithm converts particle size and counts into mass concentrations. Algorithm PM\_ENVIRO\_0011 was used for conversion in the context of performance testing.

The measuring system may be operated either directly via the touch screen at the front of the instrument or remotely via an internet connection using a wireless modem using appropriate software (e.g. Teamviewer). The user is able to check measurement data and instrument information, change parameters and check correct functionality of the AMS.

The current software versions are:

100430.0014.0001.0001.0011  
100431.0014.0001.0001.0011  
100434.0014.0001.0001.0011

The current manual versions are:

- Fidas fine dust monitoring system V0221116
- Fidas Firmware V0230816
- PDAnalyze-Fidas Software V0010713.

### General remarks

This certificate is based upon the equipment tested. The manufacturer is responsible for ensuring that on-going production complies with the requirements of the EN 15267. The manufacturer is required to maintain an approved quality management system controlling the manufacturing process for the certified product. Both the product and the quality management systems shall be subject to regular surveillance.

If a product of the current production does not conform to the certified product, TÜV Rheinland Energy GmbH must be notified at the address given on page 1.

A certification mark with an ID-Number that is specific to the certified product is presented on page 1 of this certificate.

This document as well as the certification mark remains property of TÜV Rheinland Energy GmbH. Upon revocation of the publication the certificate loses its validity. After the expiration of the certificate and on request of TÜV Rheinland Energy GmbH this document shall be returned and the certificate mark must no longer be used.

The relevant version of this certificate and its expiration date are also accessible on the internet at [qal1.de](http://qal1.de).

Certification of the Fidas® 200 S, Fidas® 200 and Fidas® 200 E measuring system is based on the documents listed below and the regular, continuous surveillance of the manufacturer's quality management system:

### Initial certification according to EN 15267

Certificate no. 0000040212: 29 April 2014  
Expiry date of the certificate: 31 March 2019

Test report: 936/21218896/A dated 20 September 2013  
TÜV Rheinland Energie und Umwelt GmbH, Cologne  
Publication: BANz AT 01.04.2014 B12, chapter IV no. 5.1  
UBA announcement dated 27 February 2014

### Notification in accordance with EN 15267

Statement issued by TÜV Rheinland Energie und Umwelt GmbH dated 27 September 2014  
Publication: BANz AT 02.04.2015 B5, chapter IV notification 14  
UBA announcement dated 25 February 2015  
(new LED, indoor version, new format for software versions)

### Supplementary testing according to EN 15267

Certificate no. 0000040212\_01: 30 September 2015  
Expiry date of the certificate: 31 March 2019

Test report: 936/21227195/A dated 9 March 2015  
TÜV Rheinland Energie und Umwelt GmbH, Cologne  
Publication: BANz AT 26.08.2015 B4, chapter III number 2.1  
UBA announcement dated 22 July 2015



### **Notifications in accordance with EN 15267**

Certificate no. 0000040212\_02: 25 April 2016  
Expiry date of the certificate: 31 March 2019

Statement issued by TÜV Rheinland Energie und Umwelt GmbH dated 6 November 2015  
and test report 936/21227195/B dated 5 October 2015  
Publication: BAnz AT 14.03.2016 B7, chapter V notification 6  
UBA announcement dated 18 February 2016  
(correction of the manual, alternative weather station and new software version)

Statement issued by TÜV Rheinland Energie und Umwelt GmbH dated 24 February 2016  
Publication: BAnz AT 01.08.2016 B11, chapter V notification 35  
UBA announcement dated 14 July 2016  
(change in the test procedure, hardware amendment, new software version)

### **Correction**

Certificate no. 0000040212\_03: 09 November 2016  
Expiry date of the certificate: 31 March 2019  
(Correction of the quote taken from the standard referred to)

### **Notifications in accordance with EN 15267**

Statement issued by TÜV Rheinland Energy GmbH dated 12 October 2016  
Publication: BAnz AT 15.03.2017 B6, chapter V notification 10  
UBA announcement dated 22 February 2017  
(temperature compensation factors, flow sensor, mistake in the test report)

Statement issued by TÜV Rheinland Energy GmbH dated 7 March 2017  
Publication: BAnz AT 31.07.2017 B12, chapter II notification 30  
UBA announcement dated 13 July 2017  
(New software version)

Certificate no. 0000040212\_04: 13 April 2018  
Expiry date of the certificate: 31 March 2019

Statement issued by TÜV Rheinland Energy GmbH dated 8 September 2017  
Publication: BAnz AT 26.03.2018 B8, chapter V notification 10  
UBA announcement dated 21 February 2018  
(compliance with standard EN 16450 (2017), new software version)

Summary of the results for equivalence testing, SN 0111 & SN 0112

Measured component PM<sub>2.5</sub> after correction of the slope, evaluation algorithm PM\_ENVIRO\_0011

Comparison candidate with reference according to Guide "Demonstration of Equivalence Of Ambient Air Monitoring Methods", January 2010				
Candidate	FIDAS 200 S	SN	SN 0111 & SN 0112	
Status of measured values	Slope corrected	Limit value	30	µg/m <sup>3</sup>
		Allowed uncertainty	25	%
<b>All comparisons</b>				
Uncertainty between Reference	0.53			µg/m <sup>3</sup>
Uncertainty between Candidates	0.45			µg/m <sup>3</sup>
<b>SN 0111 &amp; SN 0112</b>				
Number of data pairs	313			
Slope b	0.999			not significant
Uncertainty of b	0.008			
Ordinate intercept a	-0.190			not significant
Uncertainty of a	0.136			
Expanded meas. uncertainty W <sub>CM</sub>	9.35			%
<b>All comparisons, ≥18 µg/m<sup>3</sup></b>				
Uncertainty between Reference	0.60			µg/m <sup>3</sup>
Uncertainty between Candidates	0.80			µg/m <sup>3</sup>
<b>SN 0111 &amp; SN 0112</b>				
Number of data pairs	67			
Slope b	0.981			
Uncertainty of b	0.020			
Ordinate intercept a	0.306			
Uncertainty of a	0.630			
Expanded meas. uncertainty W <sub>CM</sub>	12.51			%
<b>All comparisons, &lt;18 µg/m<sup>3</sup></b>				
Uncertainty between Reference	0.51			µg/m <sup>3</sup>
Uncertainty between Candidates	0.31			µg/m <sup>3</sup>
<b>SN 0111 &amp; SN 0112</b>				
Number of data pairs	246			
Slope b	1.065			
Uncertainty of b	0.023			
Ordinate intercept a	-0.782			
Uncertainty of a	0.224			
Expanded meas. uncertainty W <sub>CM</sub>	11.34			%

Comparison candidate with reference according to Guide "Demonstration of Equivalence Of Ambient Air Monitoring Methods", January 2010				
Candidate	FIDAS 200 S	SN	SN 0111 & SN 0112	
Status of measured values	Slope corrected	Limit value	30	µg/m <sup>3</sup>
		Allowed uncertainty	25	%
<b>Cologne, Summer</b>				
Uncertainty between Reference	0.66	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.11	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	81		82	
Slope b	1.053		1.050	
Uncertainty of b	0.032		0.033	
Ordinate intercept a	-0.850		-0.810	
Uncertainty of a	0.342		0.357	
Expanded meas. uncertainty W <sub>CM</sub>	10.46	%	10.77	%
<b>Cologne, Winter</b>				
Uncertainty between Reference	0.54	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.52	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	51		50	
Slope b	0.991		0.956	
Uncertainty of b	0.013		0.013	
Ordinate intercept a	0.656		0.645	
Uncertainty of a	0.296		0.307	
Expanded meas. uncertainty W <sub>CM</sub>	8.50	%	9.43	%
<b>Bonn</b>				
Uncertainty between Reference	0.62	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.66	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	50		50	
Slope b	1.050		1.008	
Uncertainty of b	0.024		0.026	
Ordinate intercept a	-0.723		-0.471	
Uncertainty of a	0.539		0.584	
Expanded meas. uncertainty W <sub>CM</sub>	12.32	%	12.33	%
<b>Bornheim</b>				
Uncertainty between Reference	0.42	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.47	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	45		45	
Slope b	1.142		1.115	
Uncertainty of b	0.051		0.050	
Ordinate intercept a	-1.370		-1.482	
Uncertainty of a	0.607		0.607	
Expanded meas. uncertainty W <sub>CM</sub>	22.40	%	17.49	%
<b>Teddington, Winter</b>				
Uncertainty between Reference	0.42	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.52	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	44		44	
Slope b	0.964		0.963	
Uncertainty of b	0.012		0.011	
Ordinate intercept a	-0.004		-0.143	
Uncertainty of a	0.223		0.208	
Expanded meas. uncertainty W <sub>CM</sub>	9.46	%	10.01	%
<b>Teddington, Summer</b>				
Uncertainty between Reference	0.25	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.35	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	44		44	
Slope b	0.934		0.926	
Uncertainty of b	0.020		0.020	
Ordinate intercept a	0.461		0.399	
Uncertainty of a	0.232		0.229	
Expanded meas. uncertainty W <sub>CM</sub>	11.50	%	13.40	%
<b>All comparisons, ≥ 18 µg/m<sup>3</sup></b>				
Uncertainty between Reference	0.60	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.80	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	67		67	
Slope b	0.999		0.965	
Uncertainty of b	0.020		0.021	
Ordinate intercept a	0.134		0.443	
Uncertainty of a	0.642		0.65	
Expanded meas. uncertainty W <sub>CM</sub>	12.67	%	13.39	%
<b>All comparisons, &lt; 18 µg/m<sup>3</sup></b>				
Uncertainty between Reference	0.51	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.31	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	248		248	
Slope b	1.083		1.052	
Uncertainty of b	0.023		0.023	
Ordinate intercept a	-0.841		-0.744	
Uncertainty of a	0.227		0.226	
Expanded meas. uncertainty W <sub>CM</sub>	13.84	%	9.97	%
<b>All comparisons</b>				
Uncertainty between Reference	0.53	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.45	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	315		315	
Slope b	1.014	not significant	0.985	not significant
Uncertainty of b	0.008		0.008	
Ordinate intercept a	-0.225	not significant	-0.137	not significant
Uncertainty of a	0.137		0.137	
Expanded meas. uncertainty W <sub>CM</sub>	9.50	%	10.17	%

Summary of the results for equivalence testing, SN 0111 & SN 0112

Measured component PM<sub>10</sub> after correction of the slope and intercept, evaluation algorithm PM\_ENVIRO\_0011

Comparison candidate with reference according to Guide "Demonstration of Equivalence Of Ambient Air Monitoring Methods", January 2010			
Candidate	FIDAS 200 S	SN	SN 0111 & SN 0112
Status of measured values	Slope & offset corrected	Limit value	50 $\mu\text{g}/\text{m}^3$
		Allowed uncertainty	25 %
<b>All comparisons</b>			
Uncertainty between Reference	0.58	$\mu\text{g}/\text{m}^3$	
Uncertainty between Candidates	0.65	$\mu\text{g}/\text{m}^3$	
<b>SN 0111 &amp; SN 0112</b>			
Number of data pairs	316		
Slope b	1.000	not significant	
Uncertainty of b	0.009		
Ordinate intercept a	0.010	not significant	
Uncertainty of a	0.208		
Expanded measured uncertainty WCM	7.33	%	
<b>All comparisons, <math>\geq 30 \mu\text{g}/\text{m}^3</math></b>			
Uncertainty between Reference	0.68	$\mu\text{g}/\text{m}^3$	
Uncertainty between Candidates	1.15	$\mu\text{g}/\text{m}^3$	
<b>SN 0111 &amp; SN 0112</b>			
Number of data pairs	44		
Slope b	0.955		
Uncertainty of b	0.034		
Ordinate intercept a	2.060		
Uncertainty of a	1.490		
Expanded measured uncertainty WCM	10.68	%	
<b>All comparisons, <math>&lt; 30 \mu\text{g}/\text{m}^3</math></b>			
Uncertainty between Reference	0.56	$\mu\text{g}/\text{m}^3$	
Uncertainty between Candidates	0.55	$\mu\text{g}/\text{m}^3$	
<b>SN 0111 &amp; SN 0112</b>			
Number of data pairs	272		
Slope b	1.006		
Uncertainty of b	0.018		
Ordinate intercept a	-0.122		
Uncertainty of a	0.300		
Expanded measured uncertainty WCM	6.63	%	

Comparison candidate with reference according to Guide "Demonstration of Equivalence Of Ambient Air Monitoring Methods", January 2010				
Candidate	FIDAS 200 S	SN	SN 0111 & SN 0112	
Status of measured values	Slope & offset corrected	Limit value	50	µg/m <sup>3</sup>
		Allowed uncertainty	25	%
<b>Cologne, Summer</b>				
Uncertainty between Reference	0.80	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.26	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	81		82	
Slope b	1.007		0.990	
Uncertainty of b	0.027		0.027	
Ordinate intercept a	-0.221		-0.112	
Uncertainty of a	0.473		0.471	
Expanded measured uncertainty W <sub>CM</sub>	6.59	%	7.00	%
<b>Cologne, Winter</b>				
Uncertainty between Reference	0.53	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.64	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	51		50	
Slope b	1.026		0.990	
Uncertainty of b	0.014		0.014	
Ordinate intercept a	0.130		0.107	
Uncertainty of a	0.385		0.384	
Expanded measured uncertainty W <sub>CM</sub>	8.19	%	5.89	%
<b>Bonn</b>				
Uncertainty between Reference	0.38	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.87	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	50		50	
Slope b	1.005		0.968	
Uncertainty of b	0.026		0.028	
Ordinate intercept a	1.279		1.419	
Uncertainty of a	0.792		0.834	
Expanded measured uncertainty W <sub>CM</sub>	10.60	%	9.15	%
<b>Bornheim</b>				
Uncertainty between Reference	0.54	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.84	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	47		47	
Slope b	1.086		1.043	
Uncertainty of b	0.038		0.038	
Ordinate intercept a	-0.555		-0.731	
Uncertainty of a	0.707		0.694	
Expanded measured uncertainty W <sub>CM</sub>	16.74	%	9.15	%
<b>Teddington, Winter</b>				
Uncertainty between Reference	0.48	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.73	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	44		44	
Slope b	0.963		0.934	
Uncertainty of b	0.017		0.016	
Ordinate intercept a	-0.195		-0.179	
Uncertainty of a	0.426		0.405	
Expanded measured uncertainty W <sub>CM</sub>	10.41	%	15.18	%
<b>Teddington, Summer</b>				
Uncertainty between Reference	0.46	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.54	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	45		45	
Slope b	0.912		0.910	
Uncertainty of b	0.028		0.029	
Ordinate intercept a	1.264		0.868	
Uncertainty of a	0.457		0.489	
Expanded measured uncertainty W <sub>CM</sub>	13.68	%	15.62	%
<b>All comparisons, ≥30 µg/m<sup>3</sup></b>				
Uncertainty between Reference	0.68	µg/m <sup>3</sup>		
Uncertainty between Candidates	1.15	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	44		44	
Slope b	0.983		0.928	
Uncertainty of b	0.035		0.034	
Ordinate intercept a	1.474		2.590	
Uncertainty of a	1.518		1.50	
Expanded measured uncertainty W <sub>CM</sub>	11.17	%	11.47	%
<b>All comparisons, &lt;30 µg/m<sup>3</sup></b>				
Uncertainty between Reference	0.56	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.56	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	274		274	
Slope b	1.025		0.990	
Uncertainty of b	0.018		0.017	
Ordinate intercept a	-0.172		-0.102	
Uncertainty of a	0.309		0.297	
Expanded measured uncertainty W <sub>CM</sub>	8.05	%	6.99	%
<b>All comparisons</b>				
Uncertainty between Reference	0.58	µg/m <sup>3</sup>		
Uncertainty between Candidates	0.65	µg/m <sup>3</sup>		
	SN 0111		SN 0112	
Number of data pairs	318		318	
Slope b	1.016	not significant	0.983	not significant
Uncertainty of b	0.009		0.009	
Ordinate intercept a	-0.019	not significant	0.043	not significant
Uncertainty of a	0.212		0.209	
Expanded measured uncertainty W <sub>CM</sub>	8.16	%	8.01	%